

Product: TRACK-TYPE TRACTOR

Model: D3C II TRACK-TYPE TRACTOR 4HJ

Configuration: D3C & D3C LGP SERIES II TRACTORS / POWER SHIFT / 4HJ00001-UP (MACHINE) POWERED BY 3204 ENGINE

Disassembly and Assembly

D3C & D3C SA TRACTORS, 931C TRACK-TYPE LOADER POWER TRAIN

Media Number -SEN3807-01

Publication Date -01/10/2004

Date Updated -15/02/2017

SEN38070021

Final Drive Pinions


SMCS - 4055-010

Remove And Install Final Drive Pinions


Tools Needed		A	B
5P9736	Link Bracket	1	
1P520	Driver Group		1

Start By:

- a. separation of tracks
 - b. remove pinion flanges
1. Drain the oil from the final drive case.




2. Install tool (A) and fasten a hoist as shown. Remove nuts (1) and bolts that hold the final drive cover to the steering clutch case.




Typical Example

3. Install two 3/8" - 16 NC forcing screws (3) in the final drive cover. Tighten the forcing screws evenly and remove final drive (2) and the sprocket hub as a unit. The weight is 158 kg (350 lb.).

4. Remove the race and roller assembly for the pinion shaft from the final drive cover. See the topic, Remove Sprocket Shaft Gear And Cover.




5. Remove pinion (4).




6. Remove bearing races (5) and (6) from pinion (4).




7. Remove nuts (7) that hold bearing cage (8) to the steering clutch case.



8. Install two 3/8" - 16 NC forcing screws (9). Tighten the forcing screws evenly and remove bearing cage (8).



9. Remove O-ring seal (11) and lip-type seal (10) from bearing cage (8).




10. Remove race and roller assembly (12) from bearing cage (8).

NOTE: The following steps are for installation of the final drive pinions.

11. Inspect all parts for damage and make replacements if needed.

12. Lower the temperature of race and roller assembly (12). Install race and roller assembly (12) in bearing cage (8).



13. Use tooling (B) and install the lip-type seal in bearing cage (8) with the lip of the seal toward the final drive cover as shown. Put oil on the lip of the seal.

14. Install O-ring seal (11) on the bearing cage.

15. Put bearing cage (8) on the steering clutch case. Install the nuts that hold the bearing cage in place.

16. Heat bearing races (5) and (6) to a maximum temperature of 135°C (275°F). Install bearing races (5) and (6) on pinion (4).

17. Install pinion (4) in the bearing cage.

18. Install the race and roller assembly for the pinion shaft in the final drive cover. See the topic, Install Sprocket Shaft, Gear And Cover.

19. Put 7M7260 Liquid Gasket Material on the machined surfaces of the final drive cover and steering clutch case.

20. Install tool (A) and fasten a hoist to the final drive and sprocket hub. Put the final drive and sprocket hub in position on the steering clutch case.

21. Install nuts (1) and bolts that hold the final drive in place.

22. Fill the final drive with oil to the correct level. See the Operation And Maintenance Manual.

End By:

a. install pinion flanges

b. connection of tracks

Product: TRACK-TYPE TRACTOR

Model: D3C II TRACK-TYPE TRACTOR 4HJ

Configuration: D3C & D3C LGP SERIES II TRACTORS / POWER SHIFT / 4HJ00001-UP (MACHINE) POWERED BY 3204 ENGINE

Disassembly and Assembly

D3C & D3C SA TRACTORS, 931C TRACK-TYPE LOADER POWER TRAIN

Media Number -SEN3807-01

Publication Date -01/10/2004

Date Updated -15/02/2017

SEN38070022

Bevel Gear And Pinion


SMCS - 3254; 3256-011; 3256-012

Remove Bevel Gear And Pinion


Tools Needed		A
8B7548	Puller Assembly	1
8B7560	Step Plate	1
8H684	Ratchet Box Wrench	1
8H663	Bearing Puller Attachment	1

Start By:


- a. remove steering clutch hub couplings
 - b. remove pinion flanges
 - c. remove drive shaft
1. Remove the cover for the bevel gear compartment.



2. Remove nuts (1) from the bolts that hold the bevel gear on the shaft.




3. Remove the bolts that hold bearing cages (2) on the right and left sides of the bevel gear shaft. Install two 3/8" - 16 NC forcing screws in the bearing cages. Tighten the forcing screws evenly and remove bearing cages (2) and shims. Keep the shims with their respective bearing cages for installation.



4. Remove the bolts that hold the pinion bearing cage assembly to the bevel gear case.


5. Install two 3/8" - 16 NC forcing screws in the pinion bearing cage assembly. Tighten the forcing screws evenly and remove pinion bearing cage assembly (3) and shims. Keep the shims with the pinion bearing cage assembly for installation.




7. Move the bevel gear shaft away from the bevel gear.

8. Remove bevel gear (5) and bevel gear shaft (4).

9. Remove the bearing cups, O-ring seals and lip-type seals from the two bevel gear bearing cages.




10. Remove the bearing cones from the bevel gear shaft with tooling (A).



Typical Example

11. Remove bolts (7) that hold the retainer on the pinion shaft flange (6).


NOTE: Keep the shims with the retainer for correct installation.



Typical Example

12. Remove pinion bearing cage (8) from the pinion with tooling (A).

NOTE: Keep the puller attachment away from the inner bearing cone when tooling (A) is installed.




Typical Example


13. Remove the O-ring seal and lip-type seal from pinion bearing cage (8).
14. Remove the bearing cups from pinion bearing cage (8).
15. Remove inner bearing cone (9) from pinion shaft (10) with tooling (A).

Install Bevel Gear And Pinion


Tools Needed		B
8S2328	Dial Test Indicator Group	1



1. Lower the temperature of bearing cups (11). Install bearing cups (11) in the pinion bearing cage.




2. Lower the temperature of bearing cups (12). Install bearing cups (12) in bevel gear bearing cages (2).




3. Heat bearing cone (9) to a maximum temperature of 135°C (275°F). Install bearing cone (9) on the pinion shaft. Install the pinion shaft in pinion bearing cage (8). Install bearing cone (13) on the pinion shaft. Install O-ring seal (14). Install the lip-type seal in the pinion bearing cage with the lip of the seal toward the oil that is to be sealed.

4. Install the flange, retainer and bolts. Tighten the bolts which will pull the bearing cone on to the pinion shaft. Turn the pinion shaft while the bolts are tightened until a small preload is felt.




5. Install tooling (B) as shown and check the end play in the pinion shaft. Add enough shims behind the retainer to get 0 to 0.05 mm (0 to .002 in.) end play in the pinion shaft. Install the O-ring, retainer, lock and bolts.



6. Heat bearing cones (15) to a maximum temperature of 135°C (275°F). Install bearing cones (15) on the bevel gear shaft.


7. Put the bevel gear into position in the bevel gear case.

8. Install the bevel gear shaft through the bevel gear.




9. Install the O-ring seal and lip-type seal (17) in the left bearing cage. The spring loaded lip of the lip-type seal must be toward the bevel gear.

10. Install the left bearing cage with original amount of shims (16) behind the bearing cage.




11. Put bevel gear shaft (4) into position in bevel gear (5). Install the bolts and nuts that hold the bevel gear to the bevel gear shaft.



12. Install the O-ring seal and lip-type seal (19) in the right bearing cage. The spring loaded lip of the lip-type seal must be toward the bevel gear.

13. Install two 1/2"- 13 NC guide bolts (18). Install the right bearing cage on the shaft without shims. Install the bolts and tighten the bolts evenly, while the bevel gear shaft is turned, until a small amount of bearing preload is felt.




14. Tighten nuts (1) on the bevel gear to a torque of $142 \pm 14 \text{ N}\cdot\text{m}$ ($106 \pm 10 \text{ lb}\cdot\text{ft.}$).

15. Install tooling (B) on the end of the bevel gear shaft. Loosen the bolts around the right bearing cage evenly until there is no end play or preload on the bevel gear shaft.

16. Make a measurement of the clearance between the right bearing cage and the bevel gear case with a feeler gauge. The clearance must be the same at all bolt locations.


17. Remove tooling (B) and the right bearing cage. Install shims equal to the thickness measured minus 0.18 mm (.007 in.). Install the right bearing cage.

18. Check the amount of torque needed to turn the bevel gear shaft constantly for two or three turns. The torque must be 3.9 to 5.6 N·m (35 to 50 lb.in.). Add or remove shims as necessary if the torque is not correct.



19. Slide pinion bearing cage assembly (3), with the large oil hole in the bearing cage up, into the bevel gear case.

20. Install original shims (20) behind the pinion bearing cage. If the original shims are not available, install enough shims behind the pinion bearing cage to get the heel of the bevel gear in alignment with the pinion gear.




21. Install tooling (B) to check the gear clearance (backlash) between the bevel gear and pinion. Turn the gears and check the gear clearance (backlash) at several places to find out the place where there is the least amount of gear clearance (backlash). The correct gear clearance (backlash) for a power shift machine is $0.20 + 0.10$ or $- .08$ mm ($.008 + .004$ or $- .003$ in.). The correct gear clearance (backlash) for a direct drive machine is $0.25 + 0.10$ or $- 0.8$ mm ($.010 + .004$ or $- .003$ in.).

22. The gear clearance (backlash) can be increased, or decreased by removal of shims from one bearing cage and installation behind the other.

23. Preload on the bearings of the bevel gear shaft will not be changed if shims are moved from one side to the other and the thickness of the shims is kept the same.


24. After the gear clearance (backlash) and bearing preload adjustments have been made, check the tooth contact between the bevel gear and pinion as follows:

a. Put Prussian blue, red lead or paint with a brush on the bevel gear teeth. Turn the pinion and check the contact area of the teeth on the drive side of the bevel gear. When the tooth contact on the drive side is correct, reverse side must also be correct.




Correct Tooth Contact Setting

b. With no load, the correct tooth setting will be as shown. The area of contact starts near the toe of the gear and goes about 30% up the length of the tooth with this setting. When a load is put on the gear, it will be over the correct area of the teeth.



Short Toe Contact Setting

c. If the bevel pinion shaft is too far away from the bevel gear, short toe contact will be the result as shown. The teeth of the pinion will be in contact with toe end of convex faces (part that makes a curve toward the outside) and top edge of heel end of concave faces (part that makes a curve toward inside). To correct this, move the pinion shaft closer to the bevel gear. To do this, remove shims between pinion bearing cage and bevel gear case. Check gear clearance (backlash) and tooth contact again.



Short Heel Contact Setting

d. If the pinion shaft is too near to the center of the bevel gear, short heel contact will be the result as shown. The teeth of the pinion shaft will be in contact with the toe ends of concave faces (part that makes a curve toward the inside) and the heel end of convex faces (part that makes a curve toward the outside). To correct this, move the pinion shaft away from the bevel gear. To do this, add shims between pinion bearing cage and bevel gear case. Check gear clearance (backlash) and tooth contact again.

NOTE: Several adjustments must be made for the correct tooth contact setting. If the gear clearance (backlash) is changed, the tooth contact setting will change.

e. Remove all of the Prussian blue, red lead or paint from the bevel gear and pinion.

End By

a. install drive shaft

b. install pinion flanges

c. install steering clutch hub couplings

Product: TRACK-TYPE TRACTOR

Model: D3C II TRACK-TYPE TRACTOR 4HJ

Configuration: D3C & D3C LGP SERIES II TRACTORS / POWER SHIFT / 4HJ00001-UP (MACHINE) POWERED BY 3204 ENGINE

Disassembly and Assembly

D3C & D3C SA TRACTORS, 931C TRACK-TYPE LOADER POWER TRAIN

Media Number -SEN3807-01

Publication Date -01/10/2004

Date Updated -15/02/2017

SEN38070023

Engine And Transmission (3F/1R Power Shift)

SMCS - 1004-010; 1004-029

Remove And Install Engine And Transmission (3F/1R Power Shift)

Tools Needed		A	B
5P9736	Bracket-Link	1	
5P9694	Ratchet Hoist		1


Start By:

- a. remove radiator and guard*
- b. remove air cleaner group*
- c. remove muffler*
- d. remove drive shaft


*These operations are in the disassembly and Assembly Module, 3204 Vehicular Engine Supplement For D3C, D3C SA And 931C, Form No. SENR3803.

NOTE: This operation is done on a 931C with a 3F/1R power shift transmission and a ROPS.


1. Drain the oil from the hydraulic tank.
2. Turn the valve on the bottom of the fuel tank to the "OFF" position.




3. Disconnect wire harness (1) at the firewall. Remove bolts (4) that hold clips (2) in place.
4. Disconnect oil pressure gauge oil line (3) from the fitting in the cylinder block.




5. Disconnect air cleaner indicator line (5) from the fitting in the air inlet manifold.
6. Disconnect water temperature sensing unit (6). Remove clips (7) that hold the water temperature sensing line in place.




7. Disconnect wire (8) for the lights. Disconnect battery cable (9) from the starting motor.




8. Disconnect oil line (10) from oil line (12). Remove bolt (11) that holds the clips to the bracket.



9. Disconnect wire (13) for the bucket positioner kickout.




10. Disconnect governor linkage (15) from the governor lever. Disconnect fuel supply line (14). Put plugs in the openings.




11. Loosen nut (16) and remove the governor linkage from the bracket.


12. Disconnect oil line (17) from oil line (18).



13. Remove the floor plates from the cab or the operator's platform.
14. Disconnect transmission control linkage (19) from the lever on the transmission.
15. Disconnect wire harness (20). Disconnect wires (22) for the back-up warning alarm.
16. Disconnect oil line (23) from the transmission.
17. Remove clamps (21) that hold the battery cable to the transmission.



18. Remove bolt (25) and nut that hold clip (24) to bracket (26).
19. Disconnect oil line (27) from the steering clutch control valve.



20. Disconnect torque converter oil temperature sensing unit (29) from the transmission.
21. Remove transmission oil filler tube (30) from the transmission.

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.
You can download the most
perfect and complete manual in
the world immediately.

Our support email:
ebooklibonline@outlook.com