



E16 - E18

**WORKSHOP MANUAL
ENGLISH**

Print No. 604.13.396

Edition: 01/2005
English - Printed in Italy

Printed by Studio ti - 12105

AVOID ACCIDENTS

Most accidents, whether they occur in industry, on the farm, at home or on the highway, are caused by the failure of some individuals to follow simple and fundamental safety rules or precautions. For this reason **MOST ACCIDENTS CAN BE PREVENTED** by recognising the real cause and doing something about it before the accident occurs.

Regardless of the care used in the design and construction of any type of equipment there are conditions that cannot be completely safeguarded against without interfering with reasonable accessibility and efficient operation.

Carefully read indications, cautions and safety warning quoted in the "SAFETY RULES" section.

A careful operator is the best insurance against an accident.

The complete observance of one simple rule would prevent many thousand serious injuries each year.

That rule is:

Never attempt to clean, oil or adjust a machine while it is in motion.



ATTENTION

On machines having hydraulically, mechanically and/or cable controlled equipment (such as showels, loaders, dozers, scrapers etc.) be certain the equipment is lowered to the ground before servicing, adjusting and/or repairing.

If it is necessary to have the equipment partially or fully raised to gain access to certain items, be sure the equipment is suitably supported by means other than the hydraulic lift cylinders, cable and/or mechanical device used for controlling the equipment.

COPYRIGHT BY NEW HOLLAND KOBELCO CONSTRUCTION MACHINERY S.p.A.

Product Support - Documentation Centre

Strada di Settimo, 323 - 10099 - S. Mauro T.SE (TO) ITALY

All rights reserved. Reproduction of text and illustrations in whole or in part, is strictly prohibited.

E16 - E18

SECTION 1	HOW TO USE
------------------	-------------------

INDEX

Sections index 1-1

Introduction 1-4

Manual handling 1-4

Symbols and indications 1-5

Features of the manual 1-6

Manual composition 1-6

Brief information for manual consultation 1-8

SECTIONS INDEX	PAGES
SECTION 1 - HOW TO USE	
Sections index	1-1
Introduction	1-4
Features of the manual	1-5
SECTION 2 - SAFETY RULES	
Safety rules	2-1
Safety signs	2-38
SECTION 3 - PRELIMINARY	
General precautions for repairs	3-1
Escaping procedure in case of emergency	3-6
International unit conversion system	3-7
SECTION 4 - SPECIFICATION	
Foreword	4-1
Identification data	4-2
Noise levels (2000/14/EC)	4-3
Summary plate for maintenance operations	4-4
Basic components of the mini excavator	4-5
Technical specifications	4-7
Digging performances (canopy)	4-8
Digging performances (cab)	4-9
Transport dimensions (canopy)	4-10
Transport dimensions (cab)	4-11
Lifting capacities (cab)	4-12
Lifting capacities (canopy)	4-13
Machine and components weight (dry)	4-14
Buckets application	4-15
Filling chart	4-16
SECTION 5 - TOOLS	
Tools of cylinders	5-1
Tool of hydraulic pump	5-4
Tool of pilot valve track	5-4
Tool of roller track	5-4
Tool of idler adjuster	5-5
Tools of engine	5-5
Tools of travel motor	5-8
SECTION 6 - STANDARD MAINTENANCE TIME TABLE	
Preface	6-1
Standard working time table for the maintenance	6-2
SECTION 7 - MAINTENANCE STANDARDS AND TEST PROCEDURES	
How to use maintenance standards and precautions	7-1
Performance inspection standard table	7-2
Measuring engine speed	7-4
Measuring hydraulic oil pressure	7-5
Measuring travel performances	7-8
Measuring slew performances	7-10
Measuring attachment operating performances	7-12
Measuring slew bearing performances	7-14
Measuring crawler tension	7-15

SECTION 8 - HYDRAULIC SYSTEM

Function and features of hydraulic circuit	8-1
Hydraulic circuits and components	8-2
Hydraulic circuit operation	8-6

SECTION 9 - ELECTRICAL SYSTEM

How to read circuit diagram	9-1
-----------------------------------	-----

SECTION 10 - ATTACHMENT

Attachment assy and name	10-1
Bucket	10-2
Arm	10-5
Boom	10-10
Swing	10-15
Dozer	10-22
Hydraulic cylinders	10-26

SECTION 11 - UPPER STRUCTURE

Canopy	11-1
Cab	11-4
Guard	11-6
Floor plate	11-10
Battery	11-13
Counterweight	11-14
Fuel tank	11-17
Hydraulic oil tank	11-20
Air cleaner	11-25
Muffler	11-27
Hydraulic pump	11-28
Radiator	11-43
Engine	11-47
Control valve	11-49
Solenoid valve	11-84
Pilot valve	11-86
Pilot valve travel	11-96
Slew motor	11-105
Joint swivel	11-139
Selector valve	11-154
Upper frame	11-159

SECTION 12 - TRAVEL SYSTEM

Low structure	12-1
Crawler	12-3
Slide plate	12-12
Roller tracks	12-14
Idler adjuster	12-19
Sprocket	12-28
Travel motor	12-29
Slew bearing	12-71
Lower frame	12-76

SECTION 13 - TROUBLESHOOTING HYDRAULIC SYSTEM

General precautions	13-1
Trouble diagnosis: Hydraulic	13-2
Troubleshooting	13-3

SECTION 14 - TROUBLESHOOTING ELECTRICAL SYSTEM

Trouble diagnosis: Electrical	14-1
Troubleshooting	14-2

SECTION 15 - TROUBLESHOOTING ENGINE

Trouble diagnosis: Engine	15-1
Troubleshooting	15-2

SECTION 16 - ENGINE

Specifications and Performance	16-1
Cross Sectional Views	16-15
Cooling water, lubricating oil and fuel oil	16-17
Troubleshooting	16-21
Measuring instruments	16-25
Measurement, inspection and adjustment	16-29
Adjustment the valve head clearance	16-31
Checking the v-belt tension	16-32
Measuring and checking the injection pressure and spray patterns of the fuel injection valve	16-32
Checking and adjustment the fuel injection timing	16-36
Adjustment the no-load maximum (or minimum) revolutions	16-38
Checking the cooling water system and radiator for water leakage	16-38
Checking the battery	16-39
Checking the sensors	16-41
Checking the oil cooler	16-42
Checking the piston cooling nozzle	16-43
Measuring Procedure, Service Data and Corrective Action	16-45
Disassembly and reassembly	16-73
Service data	16-83
Tightening torque	16-89
Fuel injection pump for indirect injection system	16-91
Fuel Injection Pump for Direct Injection System	16-97
Governor	16-111
Turbocharger	16-123

INTRODUCTION


INTRODUCTION

This service manual has been prepared in order to increase repair quality, providing to the technicians the elements for a good knowledge of the product and showing the proper procedures to carry out the maintenance operations. We recommend to thoroughly read the content and follow it when necessary.

It is a concise guide. It covers construction features, operation principle, troubleshooting, disassembly and assembly of components and repair action.

Using this manual in systematic and rational way it is possible to reduce the repairing errors and delay that could cause machine stop with a detriment of cost management.

The information quoted in this service manual are supplied also to be used for training aids. Therefore it is advisable to be used in the training of new personnel that will be employed in the machine maintenance.



All the information, illustrations and specifications contained in this service manual are based on the latest product information available at the time of publication.

The dealer reserves the right to makes changes at any time without notice to this service manual for technical or trading reasons.

MANUAL HANDLING

CHANGES AND SUPPLEMENTS

This service manual is carried out in loose-leaf and therefore can be easily kept up-to-date.

The personnel in charge is responsible for updating the manual and will insert the changes or supplements that the Dealer will issue to its service organisation.

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com