

AMT600, AMT622 and AMT626 All Material Transporters

For complete service information also see:

**John Deere K Series Air Cooled
Engines CTM5**

**John Deere Horicon Works
TM1363 (15AUG91)**

**LITHO IN U.S.A.
ENGLISH**

Contents

SECTION 10—GENERAL INFORMATION

- Group 05—Safety
- Group 10—General Specifications
- Group 15—Repair Specifications
- Group 20—Fuels and Lubricants
- Group 25—Serial Number Locations
- Group 30—Features and Attachments

SECTION 20—ENGINE REPAIR

- Group 05—Remove and Install Engine

SECTION 30—FUEL SYSTEM REPAIR

- Group 05—Fuel Pump
- Group 10—Fuel Tank
- Group 15—Fuel Filter

SECTION 40—ELECTRICAL REPAIR

- Group 05—Starting System
- Group 10—Charging System
- Group 15—Lighting and Controls
- Group 20—Battery Cable and Wiring Harness

SECTION 50—POWER TRAIN REPAIR

- Group 05—Drive Belt
- Group 10—Drive Chains and Sprockets
- Group 15—Drive Pulley
- Group 20—Driven Pulley
- Group 25—Transaxle
- Group 30—Drive Axles

SECTION 60—STEERING AND BRAKE REPAIR

- Group 05—Front Wheel Bearings, Steering Yoke, and Fork
- Group 10—Steering Quadrant—AMT622/626
- Group 15—Brakes

SECTION 80—MISCELLANEOUS REPAIR

- Group 05—Seat, Shroud, and Fenders—AMT600
- Group 10—Seat, Shroud, and Fenders—AMT622/626

- Group 15—Cargo Box, Frame Panels, and Platform
- Group 20—Drive Wheels
- Group 25—Throttle Cable
- Group 30—Hydraulic Lift Pump

SECTION 210—TEST & ADJUSTMENT SPECIFICATIONS/OPERATIONAL CHECKOUT PROCEDURE

- Group 05—Test and Adjustment Specifications
- Group 10—Operational Checkout Procedure—AMT600
- Group 11—Operational Checkout Procedure—AMT622/626

SECTION 220—ENGINE OPERATION, TESTS & ADJUSTMENTS—AMT600

- Group 05—Component Location
- Group 10—Theory of Operation
- Group 15—Diagnosis, Tests & Adjustments

SECTION 225—ENGINE OPERATION, TESTS & ADJUSTMENTS—AMT622/626

- Group 05—Component Location
- Group 10—Theory of Operation
- Group 15—Diagnosis, Tests & Adjustments

SECTION 240—ELECTRICAL OPERATION, TESTS & ADJUSTMENTS

- Group 05—Component Location
- Group 10—Theory of Operation
- Group 15—Diagnosis, Tests & Adjustments
- Group 20—Wiring Schematics

SECTION 250—POWER TRAIN OPERATION, TESTS & ADJUSTMENTS

- Group 05—Component Location
- Group 10—Theory of Operation
- Group 15—Diagnosis, Tests & Adjustments

Continued on next page

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

TM1363-19-15AUG91

COPYRIGHT©1991
DEERE & COMPANY
Moline, Illinois
All rights reserved
A John Deere ILLUSTRATION™ Manual
Previous Editions
Copyright 1990, 1987 Deere & Company

**SECTION 260—STEERING & BRAKES
OPERATION, TESTS &
ADJUSTMENTS—AMT600**

- Group 05—Component Location
- Group 10—Theory of Operation
- Group 15—Diagnosis, Tests & Adjustments

**SECTION 265—STEERING & BRAKES
OPERATION, TESTS &
ADJUSTMENTS—AMT622/626**

- Group 05—Component Location
- Group 10—Theory of Operation
- Group 15—Diagnosis, Tests & Adjustments

**SECTION 270—HYDRAULIC OPERATION, TESTS
& ADJUSTMENTS**

- Group 05—Component Location
- Group 10—Theory of Operation
- Group 15—Diagnosis, Tests & Adjustments
- Group 20—Hydraulic Schematic

Index

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com