



omar152156 - 8110, 8210, 8310, and 8410 Tractors (-010000) Controlling Air Flow

Controlling Air Flow



RW55204A-UN: Air Flow Knob



RW55236A-UN: Windshield and Dash Control Positions


LEGEND:

- A - Air Flow Knob
- B - Windshield
- C - Windshield and Dash
- D - Dash

Turn knob (A) to direct air flow between windshield and dash or a combination of both.

omar152156 - 8110, 8210, 8310, and 8410 Tractors (-010000) Adjusting Blower Speed

Adjusting Blower Speed



RW26651-UN: Turn Knob to Adjust Blower Speed

LEGEND:

- A - Blower Knob
- B - Off
- C - Low
- D - Medium
- E - High
- F - Purge

Turn knob (A) to desired blower speed.


NOTE:

The purge position is designed to exhaust hot air rapidly from the cab.

The pressurization blower operates whenever the blower switch is in the ON position.

omar152156 - 8110, 8210, 8310, and 8410 Tractors (-010000) Controlling Temperature

Controlling Temperature



RW26652-UN: Temperature Control Knobs and Switch


Blower knob (C) and air conditioning switch (A) must be in the ON position before the air conditioning system will operate.

Knob (B) controls the heater and defroster temperature.

Put switch (A) in the ON position to defog the windows, and adjust knob (B) to desired temperature.

omar152156 - 8110, 8210, 8310, and 8410 Tractors (-010000) Using ClimaTrak ® Temperature Control- *Optional*

Using ClimaTrak ® Temperature Control- *Optional*



RW26835-UN: Temperature Control Switches

LEGEND:

- A - Automatic Temperature Control Position
- B - Temperature Control
- C - Fan Speed Control
- D - DEFOG Position
- E - OFF Position
- F - System Indicator

Set switch to automatic position (A).

Select desired temperature by turning control knob (B).

Set fan speed control (C) to AUTO position.

NOTE:

Fan speed adjusts automatically in AUTO position. Turning speed control (C) to manual mode settings provides continuous fan speed.


Select DEFOG setting (D) to reduce condensation inside the cab.

NOTE:


If system indicator (F) flashes during operation, see your John Deere Dealer.

omar152156 - 8110, 8210, 8310, and 8410 Tractors (-010000) Operating Windshield Wiper

Operating Windshield Wiper



RW26636-UN: Rotate Switch



RW26654-UN: Windshield Wash Reservoir

Rotate switch (A) to activate four wiper positions:

- Off
- Intermittent
- Slow
- Fast

Push switch in to operate optional windshield washer.

Fill washer reservoir (B) with non-freezing solvent to prevent damage to washer system in cold temperatures.

Insert a small pin in washer nozzles to adjust direction of spray.

**omar152156 - 8110, 8210, 8310, and 8410 Tractors (-010000)
Operating Rear Windshield Wiper and Washer- *Optional***

Operating Rear Windshield Wiper and Washer- *Optional*



RW26656-UN: Rear Windshield Wiper and Washer Switch

Switch (A) has three operating positions:

Top **WASHER** position-hold switch down to activate washer

Center **ON** position-windshield wiper is activated


Bottom **OFF** position

omar152156 - 8110, 8210, 8310, and 8410 Tractors (-010000) Adjusting Steering Wheel

Adjusting Steering Wheel



RW26609-UN: Telescope and Tilt Adjustments



RW55481A-UN: Steering Column Foot Pedal

Telescope

Rotate knob (A) counter-clockwise to extend or retract the steering wheel. Rotate knob clockwise to lock.

Tilt

Pull up on lever (B) and move the steering column to the desired position. Release lever to lock.

Memory

Push down on foot pedal (C) to permit steering column to automatically move up, out of operator's way for easy entry or exit.

Push down on foot pedal and pull down on steering wheel to return steering column back to previous setting.

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com