


omar178344 - 8110T, 8210T, 8310T and 8410T Tractors (902001-) Operating Road Lights

Operating Road Lights



RW26853-UN: Light Controls



RW27093-UN: Front Light Locations



RW56480A-UN: Rear Light Locations

LEGEND:

- A - Road Light Switch
- B - Off Position
- C - Park Position
- D - Road Position
- E - Field Position
- F - Field Light Switch
- G - Position Lights
- H - Head Lights
- I - Amber Tail Lights
- J - Red Tail Lights



CAUTION:

Avoid injury caused by accidental collision with another vehicle. Always comply with traffic regulations when driving tractor on a road. Dim headlights to low-beam for oncoming vehicles. Avoid using flood lights which could blind or confuse other drivers.

The road light switch (A) has four positions and operates regardless of the key position.

-: Lights-Positions

OFF POSITION-(B)

Switches Off All Lights

PARK POSITION-(C)

Upper Side Flood Lights

Red Tail Lights

ROAD POSITION-(D)

Upper Side Flood Lights

High or Low Beam Head Lights

Amber Tail Lights

FIELD POSITION-(E)

Activates field lights. Use switch (F) to select field light combinations. (See Operating Field Lights.)


RX15494,0000F64-19-31AUG00

omar178344 - 8110T, 8210T, 8310T and 8410T Tractors (902001-) Operating Field Lights

Operating Field Lights



RW26851-UN: Road and Field Light Switches



RW27092-UN: Working Lights, Front Roof Flood Lights



RW56482A-UN: Rear Roof and Fender Flood, Tail Lights

LEGEND:

- A - Road Light Switch
- B - Field Light Switch
- C - Front Roof Flood Lights
- D - Upper Side Flood Lights
- E - Working Lights
- F - Lower Side Flood Lights
- G - Head Lights
- H - Rear Roof Flood Lights
- I - Rear Fender Flood Lights
- J - Tail Lights



CAUTION:

Avoid injury caused by accidental collision with another vehicle. Avoid using Field lights while driving on roads which could blind or confuse other drivers.

Field light switch (B) has four positions and operates when the road light switch (A) is in the field position.

POSITION 1

- Head Lights
- Red Tail Lights
- Working Lights

POSITION 2 [All Field Lights ON]

- Head Lights
- Red Tail Lights
- Working Lights
- Front Roof Floods
- Rear Roof Floods
- Rear Fender Floods
- Upper Side Floods
- Lower Side Floods

POSITION 3

- Head Lights
- Red Tail Lights
- Working Lights
- Front Roof Floods
- Upper Side Floods
- Lower Side Floods


POSITION 4

- Head Lights
- Red Tail Lights
- Rear Roof Floods
- Rear Fender Floods
- Working Lights

RX15494,0000F65-19-31AUG00

omar178344 - 8110T, 8210T, 8310T and 8410T Tractors (902001-) Operating Turn Signals, Horn and High/Low Beam

Operating Turn Signals, Horn and High/Low Beam



RW55225A-UN: Push Lever

Turn Signals

Push lever (A) up for a right turn, or pull down for a left turn. Return lever to center position after completing turn.

Horn

Push inward on end of lever (A) to activate horn.

High/Low Beam

Push lever (A) forward to activate high beam head lights. Pull lever into center position to operate low beam. Pull lever toward you and release to flash high beam.

Dim head lights for oncoming vehicles.

omar178344 - 8110T, 8210T, 8310T and 8410T Tractors (902001-) Using Delayed Egress Lighting- *Optional*

Using Delayed Egress Lighting- *Optional*



RW26837-UN: Delayed Egress Lighting

Momentarily turn light switch (A) counterclockwise from the OFF position to activate delayed egress lighting.

Entry and flood lights will remain on for 90 seconds. Lights will then automatically shut off.

omar178344 - 8110T, 8210T, 8310T and 8410T Tractors (902001-) Operating Hazard Light

Operating Hazard Light



RW56047A-UN: Hazard Switch

Push top of switch (A) to activate lights.

Turn signals operate as hazard lights regardless of key position.

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com