SERVICE MANUAL

T7.290 AutoCommand™
T7.315 AutoCommand™
TIER 4B (FINAL)

Tractor

PIN ZFEA01001 and above

Part number 48193174
English
November 2017

NEW HOLLAND
AGRICULTURE

SERVICE MANUAL

T7.290 AutoCommand™ Sidewinder II [ZFEA01001 - ZGEA02931], T7.290 AutoCommand™ Sidewinder II [ZGEA02932 - ZGEA04528], T7.290 AutoCommand™ Sidewinder II [ZGEA04529 -], T7.315 AutoCommand™ Sidewinder II [ZFEA01001 - ZGEA02931], T7.315 AutoCommand™ Sidewinder II [ZGEA02932 - ZGEA04528], T7.315 AutoCommand™ Sidewinder II [ZGEA04529 -]

48193174 30/11/2017

EN

Link Product / Engine

Product	Market Product	Engine
T7.290 AutoCommand™ Sidewinder II [ZFEA01001 - ZGEA02931]	North America	F4DFE617M*B001
T7.290 AutoCommand™ Sidewinder II [ZGEA02932 - ZGEA04528]	North America	F4DFE617M*B001
T7.290 AutoCommand™ Sidewinder II [ZGEA04529 -]	North America	F4DFE617M*B001
T7.315 AutoCommand™ Sidewinder II [ZFEA01001 - ZGEA02931]	North America	F4DFE617L*B002
T7.315 AutoCommand™ Sidewinder II [ZGEA02932 - ZGEA04528]	North America	F4DFE617L*B002
T7.315 AutoCommand™ Sidewinder II [ZGEA04529 -]	North America	F4DFE617L*B002

Contents

INTRODUCTION

Engine 10

[10.001] Engine and crankcase 10.1

[10.216] Fuel tanks 10.2

[10.202] Air cleaners and lines 10.3

[10.254] Intake and exhaust manifolds and muffler 10.4

[10.500] Selective Catalytic Reduction (SCR) exhaust treatment 10.5

[10.400] Engine cooling system 10.6

[10.414] Fan and drive 10.7

[10.310] Aftercooler 10.8

Clutch 18

[18.112] Slip clutch or flywheel damper 18.1

Transmission 21

[21.504] Continuously Variable Transmission (CVT) 21.1

[21.505] Continuously Variable Transmission (CVT) external controls 21.2

[21.506] Continuously Variable Transmission (CVT) hydraulic components 21.3

[21.507] Continuously Variable Transmission (CVT) internal components 21.4

Four-Wheel Drive (4WD) system 23

[23.202] Electro-hydraulic control 23.1

[23.314] Drive shaft 23.2

Front axle system 25

[25.100] Powered front axle 25.1

[25.102] Front bevel gear set and differential 25.2

[25.108] Final drive hub, steering knuckles, and shafts 25.3

[25.122] Axle suspension control 25.4

Rear axle system 27

[27.100] Powered rear axle 27.1
[27.106] Rear bevel gear set and differential 27.2
[27.120] Planetary and final drives 27.3
Power Take-Off (PTO) 31
[31.104] Rear electro-hydraulic control 31.1
[31.119] Four-speed rear Power Take-Off (PTO) 31.2
[31.142] Front Power Take-Off (PTO) control 31.3
[31.146] Front Power Take-Off (PTO) 31.4
Brakes and controls 33
[33.202] Hydraulic service brakes 33.1
[33.110] Parking brake or parking lock 33.2
[33.240] Emergency brake 33.3
[33.220] Trailer brake hydraulic control 33.4
[33.224] Trailer brake pneumatic control 33.5
[33.204] Front axle brake 33.6
[33.200] Brake cooling 33.7
[33.350] Anti-lock Brake System (ABS) 33.8
Hydraulic systems 35
[35.000] Hydraulic systems 35.1
[35.300] Reservoir, cooler, and filters 35.2
[35.106] Variable displacement pump 35.3
[35.230] Priority valves 35.4
[35.204] Remote control valves 35.5
[35.220] Auxiliary hydraulic pump 35.6
[35.114] Three-point hitch control valve 35.7
[35.116] Three-point hitch cylinder 35.8
[35.124] Three-point hitch hydraulic adjustment 35.9
[35.160] Front hitch controls and lines 35.10

[35.162] Front hitch cylinders and lines 35.11

Hitches, drawbars, and implement couplings 37

[37.100] Drawbars and towing hitches 37.1

[37.106] Automatic pickup hitch 37.2

[37.162] Front hitch 37.3

Frames and ballasting 39

[39.100] Frame 39.1

[39.140] Ballasts and supports 39.2

Steering 41

[41.101] Steering control 41.1

[41.106] Tie rods 41.2

[41.200] Hydraulic control components 41.3

[41.216] Cylinders 41.4

[41.432] Autoguidance steering 41.5

Wheels 44

[44.511] Front wheels 44.1

[44.520] Rear wheels 44.2

Cab climate control 50

[50.100] Heating 50.1

[50.104] Ventilation 50.2

[50.200] Air conditioning 50.3

Electrical systems 55

[55.045] Front axle control system 55.1

[55.000] Electrical system 55.2

[55.100] Harnesses and connectors 55.3

[55.015] Engine control system 55.4

[55.301] Alternator 55.5

[55.302] Battery 55.6
[55.988] Selective Catalytic Reduction (SCR) electrical system 55.7
[55.640] Electronic modules 55.8
[55.513] Cab transmission controls 55.9
[55.024] Transmission control system 55.10
[55.020] Transmission speed sensors 55.11
[55.021] Transmission pressure sensors 55.12
[55.022] Transmission temperature sensors 55.13
[55.023] Transmission position sensors and switches 55.14
[55.048] Rear Power Take-Off (PTO) control system 55.15
[55.049] Front Power Take-Off (PTO) control system 55.16
[55.519] Cab brake controls 55.17
[55.031] Parking brake electrical system 55.18
[55.512] Cab controls 55.19
[55.035] Remote control valve electric control 55.20
[55.051] Cab Heating, Ventilation, and Air-Conditioning (HVAC) controls 55.21
[55.050] Heating, Ventilation, and Air-Conditioning (HVAC) control system 55.22
[55.047] Steering control system 55.23
[55.130] Rear three-point hitch electronic control system 55.24
[55.160] Front hitch electronic control system 55.25
[55.911] Satellite navigation systems 55.26
[55.404] External lighting 55.27
[55.510] Cab or platform harnesses and connectors 55.28
[55.408] Warning indicators, alarms, and instruments 55.29
[55.550] Tire Pressure Monitoring System (TPMS) 55.30
[55.350] Anti-lock Brake System (ABS) electrical system 55.31
[55.DTC] FAULT CODES 55.32

Platform, cab, bodywork, and decals 90

[90.150] Cab 90.1

[90.156] Cab windshield and windows 90.2
[90.100] Engine hood and panels 90.3

Thank you so much for reading.

Please click the “Buy Now!” button below to download the complete manual.

Buy Now

After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email:

ebooklibonline@outlook.com