AXIAL-FLOW® 5130
AXIAL-FLOW® 6130
AXIAL-FLOW® 7130
Tier 4a
Combine

SERVICE MANUAL

Part number 84564628
1st edition English
October 2012

CASE IH
AGRICULTURE

SERVICE MANUAL

AXIAL-FLOW 5130 [YCG007403 -] , AXIAL-FLOW 5130 [YCG008901 -] , AXIAL-FLOW 6130 [YCG007403 -] , AXIAL-FLOW 6130 [YCG008901 -] , AXIAL-FLOW 7130 [YCG007403 -] , AXIAL-FLOW 7130 [YCG008901 -]

84564628 15/10/2012

EN

Contents

INTRODUCTION

Engine 10

Engine and crankcase 10.001

Air cleaners and lines 10.202

Aftercooler 10.310

Engine cooling system 10.400

Rotary screen 10.418

Main gearbox and drive 14

Main gearbox and drive 14.100

Transmission 21

Mechanical transmission 21.114

Gearbox internal components 21.145

Differential 21.182

Front axle system 25

Final drives 25.310

Rear axle system 27

Powered rear axle 27.100

Final drive hub, steering knuckles, and shafts 27.124

Hydrostatic drive 29

Transmission and steering hydrostatic control 29.100

Hydrostatic transmission 29.202

Reservoir, cooler, and lines 29.204

Pump and motor components 29.218

Brakes and controls 33

Parking brake / Parking lock 33.110

Hydraulic service brakes 33.202

Hydraulic systems 35
Hydraulic systems 35.000
Pump control valves 35.102
Variable displacement pump 35.106
Auxiliary hydraulic pump and lines 35.220
Reservoir, cooler, and filters 35.300
Regulated/Low pressure system 35.322
Main control valve 35.359
Header/Attachment height system 35.410
Grain tank unload system 35.440
Crop processor system 35.536
Header reverser drive 35.760
Chaff spreader control 35.796
Steering 41
Steering control 41.101
Tie rods 41.106
Hydraulic control components 41.200
Pump 41.206
Wheels 44
Front wheels 44.511
Cab climate control 50
Cab pressurizing system 50.300
Electrical systems 55
Electrical system 55.000
Fuel injection system 55.010
Engine cooling system 55.012
Engine oil system 55.013
Engine intake and exhaust system 55.014
Engine control system 55.015

Parking brake electrical system 55.031
Hydraulic system control 55.036
Heating, Ventilation, and Air-Conditioning (HVAC) control system 55.050
Harnesses and connectors 55.100
Engine starting system 55.201
Cold start aid 55.202
Alternator 55.301
Battery 55.302
External lighting switches and relays 55.405
Warning indicators, alarms, and instruments 55.408
Feeding control system 55.421
Cleaning control system 55.423
Harvest material flow control system 55.426
Cab controls 55.512
Wiper/Washer system 55.518
Cab harvesting controls 55.520
Ground speed control 55.610
Threshing electrical control 55.628
Electronic modules 55.640
Cab header controls 55.661
Header height control 55.662
Sieve electric control 55.834
Rotary separator control 55.836
Selective Catalytic Reduction (SCR) electrical system 55.988
FAULT CODES 55.DTC

Attachments/Headers 58

Attachment/Header reel control system 58.105

Product feeding 60

Floating roll, feed chain, and drive 60.105

Feeder housing 60.110
Length-of-cut gearbox 60.122
Feeder drive system 60.150
Threshing 66
Concave 66.105
Concave control system 66.110
Threshing mechanism drive system 66.260
Rotor 66.331
Separation 72
Rotary separator drive system 72.410
Rotary separator 72.420
Residue handling 73
Straw chopper drive system 73.210
Straw chopper 73.230
Chaff spreader 73.335
Cleaning 74
Cleaning 74.000
Cleaning drive systems 74.101
Upper shaker shoe 74.114
Lower shaker shoe 74.118
Fan housing 74.130
Tailings return system 74.140
Crop storage / Unloading 80
Clean grain elevator 80.101
Grain tank 80.150
Grain tank unload drive system 80.175
Grain tank unload 80.180
Platform, cab, bodywork, and decals 90

Machine shields and guards 90.105
Pneumatically-adjusted operator seat 90.124
Cab interior 90.151

Thank you so much for reading.

Please click the “Buy Now!” button below to download the complete manual.

Buy Now

After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email:

ebooklibonline@outlook.com