CX37C
Mini Excavator

SERVICE MANUAL

Part number 48127449
English
May 2017

CASE
CONSTRUCTION

SERVICE MANUAL

CX37C Cab - Tier IV final engine
CX37C Canopy - Tier IV final engine

Contents

INTRODUCTION

Engine..... 10

[10.001] Engine and crankcase 10.1

[10.106] Valve drive and gears 10.2

[10.101] Cylinder heads 10.3

[10.105] Connecting rods and pistons..... 10.4

[10.103] Crankshaft and flywheel..... 10.5

[10.216] Fuel tanks 10.6

[10.206] Fuel filters 10.7

[10.218] Fuel injection system..... 10.8

[10.202] Air cleaners and lines 10.9

[10.501] Exhaust Gas Recirculation (EGR) exhaust treatment..... 10.10

[10.400] Engine cooling system 10.11

[10.414] Fan and drive 10.12

[10.304] Engine lubrication system..... 10.13

Hydraulic systems..... 35

[35.000] Hydraulic systems..... 35.1

[35.106] Variable displacement pump 35.2

[35.359] Main control valve..... 35.3

[35.357] Pilot system 35.4

[35.355] Hydraulic hand control 35.5

[35.356] Hydraulic foot control..... 35.6

[35.352] Hydraulic swing system 35.7

[35.353] Hydraulic travel system 35.8

[35.354] Hydraulic central joint 35.9

[35.736] Boom hydraulic system 35.10

[35.737] Dipper hydraulic system..... 35.11

[35.738] Excavator and backhoe bucket hydraulic system 35.12
[35.739] Swing arm hydraulic system 35.13
[35.741] Dozer blade cylinders 35.14
Frames and ballasting 39
[39.140] Ballasts and supports 39.1
Tracks and track suspension 48
[48.130] Track frame and driving wheels 48.1
[48.100] Tracks 48.2
[48.134] Track tension units 48.3
[48.138] Track rollers 48.4
Electrical systems 55
[55.000] Electrical system 55.1
[55.100] Harnesses and connectors 55.2
[55.525] Cab engine controls 55.3
[55.015] Engine control system 55.4
[55.201] Engine starting system 55.5
[55.301] Alternator 55.6
[55.302] Battery 55.7
[55.011] Fuel tank system 55.8
[55.014] Engine intake and exhaust system 55.9
[55.012] Engine cooling system 55.10
[55.013] Engine oil system 55.11
[55.512] Cab controls 55.12
[55.524] Cab controls (Lift arm, Boom, Dipper, Bucket) 55.13
[55.518] Wiper and washer system 55.14
[55.404] External lighting 55.15
[55.405] External lighting switches and relays 55.16
[55.514] Cab lighting 55.17

[55.408] Warning indicators, alarms, and instruments 55.18

Booms, dippers, and buckets 84

[84.114] Boom pivoting support 84.1

[84.910] Boom 84.2

[84.912] Dipper arm 84.3

[84.100] Bucket 84.4

Platform, cab, bodywork, and decals 90

[90.100] Engine hood and panels 90.1

[90.105] Machine shields and guards 90.2

Thank you so much for reading.

Please click the “Buy Now!” button below to download the complete manual.

Buy Now

After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email:

ebooklibonline@outlook.com