Combines

932, 942, 952, 955, 965-H, 968-H, 975, 975 Hydro/4, 985, 985 Hydro/4, 1065, 1068-H, 1072, 1075, 1075 Hydro/4, 1085, 1085 Hydro/4

JOHN DEERE

John Deere Werke Zweibrücken
TM-4387
Printed in Germany (English) Rev.

Combines 932, 942, 952, 955, 965, 965-H, 968-H, 975 975 Hydro/4, 985, 985 Hydro/4, 1065, 1068-H, 1072, 1075, 1075 Hydro/4, 1085 and 1085 Hydro/4

Technical Manual TM-4387 (1989)

CONTENTS

SECTION 10 – GENERAL

Group 00 – Specifications and special tools
Group 05 – General information
Group 10 – Pre-delivery inspection, delivery service and after-sales inspection
Group 15 – Lubrication and periodic service
Group 20 – Engine and combine tune-up and adjustments
Group 25 – Combine separation

SECTION 20 – ENGINE REPAIR

Group 00 – Specifications and special tools
Group 05 – Cylinder head, valves, camshaft and balancer shafts (Engines 3179, 4239, 6359)*
Group 06 – Cylinder head, valves and camshaft (Engine 6466)**
Group 10 – Cylinder block, liners, pistons and connecting rods (Engines 3179, 4239, 6359)*
Group 11 – Cylinder block, liners, pistons and connecting rods, (Engine 6466)**
Group 15 – Crankshaft, main bearings and flywheel (Engines 3179, 4239, 6359)*
Group 16 – Crankshaft, main bearings and flywheel (Engine 6466)**
Group 20 – Lubrication system (Engines 3179, 4239, 6359)*
Group 21 – Lubrication system (Engine 6466)**
Group 25 – Cooling system (Engines 3179, 4239, 6359)*
Group 27 – Fan drive contershaft
Group 26 – Cooling system (Engine 6466)**
Group 30 – Timing gear train (Engines 3179, 4239, 6359)*

SECTION 30 – FUEL AND AIR REPAIR

Group 00 – Specifications and special tools
Group 05 – Air intake system
Group 10 – Fuel system
Group 11 – Fuel filter with water trap and electrical fuel transfer pump from serial no. 041201
Group 15 – Roto Diesel fuel injection pump
Group 20 – Roosa Master fuel injection pump
Group 25 – Robert Bosch fuel injection pump
Group 30 – Roosa Master fuel injection nozzles
Group 35 – Robert Bosch fuel injection nozzles KDEL (21 mm)
Group 40 – Speed control linkage

SECTION 40 – ELECTRICAL SYSTEM

Group 00 – Specifications and special tools
Group 05 – Diagnosing malfunctions
Group 10 – Electrical system components
Group 15 – Wiring diagrams and wiring harnesses
Group 20 – Starting motor (Bosch)
Starting motor (John Deere)
Group 30 – Alternator (Bosch)
Group 35 – Alternator (Delcotron)
Group 40 – Electrical leveling control system (sidehill combines)

SECTION 41 – MODIFIED ELECTRICAL EQUIPMENT ON COMBINES FROM SERIAL NO. 041201
Group 05 – Wiring harnesses and connectors
Group 06 – Electrical circuits and wiring diagrams
Group 07 – Testing individual circuits
Group 10 – Starting motor
Group 15 – Alternator
Group 20 – Components
Group 25 – Shaft low speed monitor system
Group 30 – Harvestrak combine monitor – Functional description and tests
Group 35 – Harvestrake combine monitor – Repair
Group 40 – Electromagnetic transmission brake

SECTION 50 – POWER TRAIN
Group 00 – Specifications and special tools
Group 05 – Variable ground speed drive
Group 10 – "Posi Torq" ground drive
Group 15 – Engine clutch and clutch linkage (932, 942, 952)
Group 20 – Engine clutch and clutch linkage (955)
Group 25 – Engine Clutch (955 to 1085)
Group 26 – Clutch from Ser. No. 044137
Group 30 – Reverser clutch, control and linkage
Group 35 – Hydrostatic drive
Group 40 – Front axle (932, 942, 952)
Group 45 – Transmission and differential (955 to 1085 Hydro/4)
Group 50 – Final drives (955, 965, 975 to 1085 Hydro/4)
Group 51 – Rice drives
Group 55 – Final drive (sidehill combines)
Group 60 – Track system

SECTION 60 – BRAKES AND REAR AXLE
Group 00 – Specifications and special tools
Group 05 – Parking brake (932, 942, 952)
Group 10 – Parking brake (955 to 1085 Hydro/4)
Group 15 – Footbrakes (disk brakes acting on transmission)
Group 16 – Footbrakes (with integrated slave cylinder)
Group 20 – Footbrakes (disk brakes acting on front wheels)
Group 25 – Rear axle
Group 30 – Rear axle (sidehill combines)
Group 35 – V-support for wide rear axle

SECTION 70 – HYDRAULIC SYSTEM

Group 00 – Specifications and special tools
Group 05 – General information, diagnosing malfunctions
Group 06 – Hydraulic symbols and system layout
Group 10 – Pressure tests
Group 15 – Hydraulic oil reservoir, filter, suction and pressure lines
Group 20 – Hydraulic pump and flow divider
Group 25 – Tandem (dual-gear) hydraulic pump
Group 30 – Triple hydraulic pump
Group 35 – Single and three spool control valves
Group 40 – Seven spool control valve
Group 41 – Seven spool control valve (from serial no. 041201)
Group 45 – Hydraulic cylinders (up to a certain serial no.)
Group 50 – Hydraulic cylinders (from a certain serial no.)
Group 55 – Nitrogen accumulators
Group 60 – Hydrostatic steering
Group 65 – Hydraulic brakes
Group 70 – Hydraulic clutch control
Group 71 – Clutch operation with integrated slave cylinder
Group 75 – Transmission brake
Group 80 – Hydraulic components (sidehill combines)
Group 85 – Hydraulic drive reel or belt pick-up system
Group 90 – Hydraulic reverser motor

SECTION 80 – MISCELLANEOUS

Group 00 – Specifications and special tools
Group 05 – General information
Group 10 – Bearings and shafts
Group 15 – Belts and chains

SECTION 90 – OPERATOR'S CAB

Group 00 – Specifications and special tools
Group 05 – Cab ventilation
Group 10 – Air conditioning system
Group 15 – Air conditioning system components
Group 20 – Heater

SECTION 95 – OPERATOR'S PLATFORM WITH SG-2 CAB (– 044136)

Group 00 – Specifications and special tools
Group 05 – Cab ventilation
Group 10 – Air conditioning system
Group 15 – Compressor
Group 20 – System components
Group 25 – Cab heating system
Group 30 – Operator's seat
Group 35 – SG2 cab

SECTION 96 – OPERATOR'S PLATFORM WITH SG-2 CAB (044137 –)

Group 05 – Cab ventilation
Group 10 – Air conditioning system
Group 15 – System service
Group 20 – System testing
Group 25 – Compressor
Group 30 – System components
Group 35 – Cab heating system
Group 40 – Operator's seat
Group 45 – SG2 cab

SECTION 100 – CUTTING PLATFORM AND CORN HEAD

Group 00 – Specifications and special tools
Group 05 – General information, diagnosing malfunctions
Group 10 – Cutting platform and knife drive
Group 11 – 200-Series Platform
Group 15 – Variable reel speed drive
Group 20 – Corn head
Group 25 – Corn head gear case

SECTION 110 – FEEDER HOUSE

Group 05 – General information, diagnosing malfunctions
Group 10 – Feeder drive
Group 15 – Feeder house (with integrated cutting platform)
Group 20 – Feeder house (with quick-tach cutting platform)
Group 21 – Feeder house (with quick-tach cutting platform; from serial no. 041201)
Group 25 – Chain transmission – cutting platform drive
Group 30 – Hydraulic reverser

SECTION 120 – SEPARATOR AND CLEANING UNIT

Group 00 – Specifications and special tools
Group 05 – General information, diagnosing malfunctions
Group 10 – Separator drive
Group 15 – Threshing cylinder, variable cylinder drive
Group 20 – Cylinder drive reduction gear (up to serial no. 039 866)
Group 21 – Cylinder drive reduction gear (from serial no. 039 867)
Group 25 – Concave
Group 30 – Beater, beater variable drive
Group 35 – Cross shaker
Group 40 – Straw walkers, cleaning shoe with sieves and fan

SECTION 130 – ELEVATORS, GRAIN TANK AND GRAIN TANK UNLOADING AUGERS

Group 05 – General information, diagnosing malfunctions
Group 10 – Elevator and auger drives
Group 15 – Clean grain auger and elevator
Group 20 – Lower tailings auger, elevator and upper auger
Group 25 – Grain tank leveling auger and unloading auger
Group 30 – Outer unloading auger and housing

SECTION 140 – SPECIAL EQUIPMENT

Group 00 – Specifications and special tools
Group 05 – Straw chopper with centrifugal and electric clutch
Group 10 – Straw chopper with direct drive
Group 15 – Straw spreader

Thank you so much for reading.

Please click the “Buy Now!” button below to download the complete manual.

Buy Now

After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email:

ebooklibonline@outlook.com