2355, 2555, 2755 and 2855N Tractors

TECHNICAL MANUAL



John Deere Werke Mannheim
TM4434
Litho in U.S.A. (Nov-89)

2355, 2555, 2755 AND 2855N TRACTORS TECHNICAL MANUAL TM4434 (NOV-89)

SECTION CONTENTS IN GROUPS – REPAIR

05 – SAFETY

10 – GENERAL

05 – Specifications
10 – Predelivery, delivery and after-sales inspections
15 – Lubrication and service
20 – Tune-up
25 – Tractor separation

20 – ENGINE

05 – Radiator, viscous fan drive and fan

30 – FUEL AND AIR INTAKE SYSTEM

05 – Fuel tank, auxiliary fuel tank and water trap
10 – Cold weather starting aids
15 – Speed control linkage
20 – Air cleaner

40 – ELECTRICAL SYSTEM

05 – Wiring harnesses
10 – Controls and instruments (without SOUND-GARD body)
15 – Controls and instruments (with SOUND-GARD body)
20 – Lighting system
25 – Starting motor
30 – Alternator

50 – POWER TRAIN

05 – Clutch operating systems
10 – Engine single-stage clutch (without Reverser)
15 – Engine single-stage clutch (with Reverser)
20 – Engine dual-stage clutch
25 – Hi-Lo shift unit
30 – Reverser
35 – Creeper transmission
40 – Transmission – console shift
45 – Transmission – center shift
50 – Synchronized transmission and transmission oil pump
55 – Collar-shift transmission and transmission oil pumps
60 – Differential
65 – Final drives
70 – Independent PTO shafts
75 – Continuous-running PTO's
80 – Front PTO
85 – Front wheel drive u.j. drive shaft and disk clutch

60 – STEERING SYSTEM AND BRAKES

05 – Hydrostatic steering
10 – Steering cylinder (without front wheel drive)
15 – Power steering
20 – Hydraulic brakes
25 – Handbrake

INHALT-LB701AE-011088

SECTION CONTENTS IN GROUPS – REPAIR

70 – HYDRAULIC SYSTEM

05 – Valves
10 – Hydraulic pumps
15 – Rockshaft
25 – Selective control valves (spool type)
30 – Selective control valves (poppet valve type)
35 – ISO breakaway couplers
40 – ISO quick couplers
45 – Remote cylinder

80 – MISCELLANEOUS

05 – Front axle
10 – Front and rear wheels

90 – OPERATOR'S STATION

05 – Safe handling of refrigerants
06 – Servicing air conditioning system
07 – Compressor (up to tractor Serial No. 663 473L)
08 – Compressor (from tractor Serial No. 663 474L)
09 – Components of air conditioning system
10 – Cab ventilation and heating
15 – Operator's seats
20 – SOUND-GARD Body
25 – 2-post roll guard
30 – 2-post telescopic roll guard

INHALT-LB702AE-011088

Thank you so much for reading.

Please click the “Buy Now!” button below to download the complete manual.

Buy Now

After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email:

ebooklibonline@outlook.com