

AXIAL-FLOW® 7240
AXIAL-FLOW® 8240
AXIAL-FLOW® 9240
Tier 2
Combine

SERVICE MANUAL

Part number 47800120

1st edition English

December 2014



Link Product / Engine

Product	Market Product	Engine
AXIAL-FLOW® 8240 Tier 2 engine, for INT and LAR markets	Latin America	F3HFA613A*E001
AXIAL-FLOW® 8240 Tier 2 engine, for INT and LAR markets	Asia Pacific	F3HFA613A*E001
AXIAL-FLOW® 8240 Tier 2 engine, for INT and LAR markets	Middle East Africa	F3HFA613A*E001
AXIAL-FLOW® 8240 Tier 2 engine, for INT and LAR markets	Australia New Zealand	F3HFA613A*E001
AXIAL-FLOW® 9240 Tier 2 engine, for INT and LAR markets	Latin America	F3JFA613D*E001
AXIAL-FLOW® 9240 Tier 2 engine, for INT and LAR markets	Asia Pacific	F3JFA613D*E001
AXIAL-FLOW® 9240 Tier 2 engine, for INT and LAR markets	Australia New Zealand	F3JFA613D*E001
AXIAL-FLOW® 9240 Tier 2 engine, for INT and LAR markets	Middle East Africa	F3JFA613D*E001

Contents

INTRODUCTION

Engine.....	10
[10.001] Engine and crankcase	10.1
[10.202] Air cleaners and lines	10.2
[10.210] Lift pump and lines	10.3
[10.216] Fuel tanks	10.4
[10.254] Intake and exhaust manifolds and muffler	10.5
[10.310] Aftercooler.....	10.6
[10.400] Engine cooling system	10.7
[10.414] Fan and drive	10.8
[10.418] Rotary screen	10.9
[10.419] Stationary air screen	10.10
[10.450] Engine air compressor	10.11
[10.500] Selective Catalytic Reduction (SCR) exhaust treatment.....	10.12
Main gearbox and drive	14
[14.100] Main gearbox and drive	14.1
Transmission.....	21
[21.100] Mechanical transmission lubrication system	21.1
[21.114] Mechanical transmission	21.2
[21.130] Mechanical transmission external controls.....	21.3
[21.145] Gearbox internal components.....	21.4
[21.182] Differential.....	21.5
Front axle system	25
[25.100] Powered front axle	25.1
[25.108] Final drive hub, steering knuckles, and shafts	25.2
[25.310] Final drives	25.3

Rear axle system.....	27
[27.100] Powered rear axle.....	27.1
[27.124] Final drive hub, steering knuckles, and shafts	27.2
[27.550] Non-powered rear axle.....	27.3
Hydrostatic drive.....	29
[29.100] Transmission and steering hydrostatic control	29.1
[29.202] Hydrostatic transmission	29.2
[29.218] Pump and motor components.....	29.3
[29.300] Rear hydrostatic transmission.....	29.4
Brakes and controls	33
[33.110] Parking brake or parking lock	33.1
[33.202] Hydraulic service brakes	33.2
Hydraulic systems.....	35
[35.000] Hydraulic systems.....	35.1
[35.102] Pump control valves.....	35.2
[35.106] Variable displacement pump	35.3
[35.220] Auxiliary hydraulic pump and lines	35.4
[35.300] Reservoir, cooler, and filters.....	35.5
[35.350] Safety and main relief valves	35.6
[35.359] Main control valve	35.7
[35.440] Grain tank unload system	35.8
[35.518] Reel control system	35.9
[35.536] Crop processor system	35.10
[35.752] Hydraulic fan drive cooling system.....	35.11
Steering.....	41
[41.101] Steering control	41.1
[41.200] Hydraulic control components.....	41.2
[41.216] Cylinders	41.3

[41.432] Autoguidance steering	41.4
Wheels	44
[44.511] Front wheels.....	44.1
Tracks and track suspension	48
[48.100] Tracks	48.1
[48.130] Track frame and driving wheels	48.2
[48.134] Track tension units	48.3
[48.138] Track rollers	48.4
Cab climate control	50
[50.100] Heating	50.1
[50.104] Ventilation	50.2
[50.200] Air conditioning.....	50.3
Electrical systems	55
[55.000] Electrical system	55.1
[55.050] Heating, Ventilation, and Air-Conditioning (HVAC) control system.....	55.2
[55.100] Harnesses and connectors.....	55.3
[55.201] Engine starting system	55.4
[55.421] Feeding control system	55.5
[55.426] Harvest material flow control system.....	55.6
[55.628] Threshing electrical control	55.7
[55.780] Shaker shoe leveling system control.....	55.8
[55.988] Selective Catalytic Reduction (SCR) electrical system	55.9
[55.DTC] FAULT CODES.....	55.10
Product feeding	60
[60.105] Floating roll, feed chain, and drive	60.1
[60.110] Feeder housing.....	60.2
[60.112] Stone trapping system	60.3
[60.150] Feeder drive system	60.4

Threshing	66
[66.000] Threshing	66.1
[66.101] Concave conveyor plate	66.2
[66.110] Concave control system.....	66.3
[66.260] Threshing mechanism drive system	66.4
[66.331] Rotor	66.5
Separation	72
[72.430] Separator grates	72.1
Residue handling.....	73
[73.210] Straw chopper drive system.....	73.1
[73.215] Straw chopper electro-magnetic clutch support.....	73.2
[73.230] Straw chopper.....	73.3
[73.430] Straw spreader	73.4
Crop storage / Unloading	80
[80.101] Clean grain elevator.....	80.1
[80.150] Grain tank	80.2
[80.175] Grain tank unload drive system	80.3
[80.180] Grain tank unload	80.4
Platform, cab, bodywork, and decals.....	90
[90.100] Engine hood and panels	90.1
[90.105] Machine shields and guards	90.2
[90.150] Cab.....	90.3

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com