

SERVICE MANUAL

H9870 / H9880

Bale Wagon

Part number 47918070

English

December 2015

Replaces part number 84175489



Link Product / Engine

Product	Market Product	Engine
H9870	North America	F4GE9684
H9880	North America	F4GE9684

Contents

INTRODUCTION

Engine	10
[10.001] Engine and crankcase	10.1
[10.202] Air cleaners and lines	10.2
[10.250] Turbocharger and lines.....	10.3
[10.254] Intake and exhaust manifolds and muffler	10.4
[10.310] Aftercooler.....	10.5
[10.400] Engine cooling system	10.6
Power coupling	19
[19.100] Drive shaft.....	19.1
Transmission	21
[21.114] Mechanical transmission	21.1
Front axle system	25
[25.400] Non-powered front axle	25.1
Rear axle system	27
[27.100] Powered rear axle.....	27.1
[27.106] Rear bevel gear set and differential	27.2
Brakes and controls	33
[33.110] Parking brake or parking lock	33.1
[33.202] Hydraulic service brakes	33.2
Hydraulic systems	35
[35.000] Hydraulic systems.....	35.1
[35.102] Pump control valves.....	35.2
[35.104] Fixed displacement pump.....	35.3
[35.106] Variable displacement pump	35.4
[35.300] Reservoir, cooler, and filters.....	35.5

[35.359] Main control valve	35.6
[35.752] Hydraulic fan drive cooling system	35.7
[35.913] Bale loading hydraulic system	35.8
[35.914] Bale storing and handling hydraulic system	35.9
[35.915] Bale unloading hydraulic system	35.10
Frames and ballasting	39
[39.100] Frame	39.1
Steering	41
[41.101] Steering control	41.1
[41.106] Tie rods	41.2
[41.200] Hydraulic control components	41.3
Wheels	44
[44.511] Front wheels	44.1
[44.520] Rear wheels	44.2
Cab climate control	50
[50.100] Heating	50.1
[50.104] Ventilation	50.2
[50.200] Air conditioning	50.3
Electrical systems	55
[55.000] Electrical system	55.1
[55.012] Engine cooling system	55.2
[55.036] Hydraulic system control	55.3
[55.046] Rear axle control system	55.4
[55.050] Heating, Ventilation, and Air-Conditioning (HVAC) control system	55.5
[55.051] Cab Heating, Ventilation, and Air-Conditioning (HVAC) controls	55.6
[55.100] Harnesses and connectors	55.7
[55.201] Engine starting system	55.8
[55.301] Alternator	55.9

[55.302] Battery.....	55.10
[55.404] External lighting	55.11
[55.405] External lighting switches and relays	55.12
[55.408] Warning indicators, alarms, and instruments	55.13
[55.512] Cab controls.....	55.14
[55.514] Cab lighting	55.15
[55.518] Wiper and washer system.....	55.16
[55.525] Cab engine controls.....	55.17
[55.640] Electronic modules	55.18
Bale wagons	69
[69.100] Bale loading	69.1
[69.200] Bale storing and handling	69.2
Lubrication system.....	71
[71.460] Grease lubrication system	71.1
Platform, cab, bodywork, and decals.....	90
[90.105] Machine shields and guards	90.1
[90.116] Fenders and guards.....	90.2
[90.118] Protections and footboards.....	90.3
[90.124] Pneumatically-adjusted operator seat.....	90.4
[90.150] Cab.....	90.5
[90.151] Cab interior	90.6
[90.154] Cab doors and hatches	90.7
[90.160] Cab interior trim and panels.....	90.8

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com