

SERVICE MANUAL

9090LT3ROW Grape Harvester

Part number 51575409

English
December 2018





SERVICE MANUAL

High Capacity TIER 3

Link Product / Engine

Product	Market Product	Engine
9090L TIER 3	Middle East Africa	F4HE9687

Contents

INTRODUCTION

Engine	10
[10.001] Engine and crankcase	10.1
[10.216] Fuel tanks	10.2
[10.206] Fuel filters	10.3
[10.218] Fuel injection system.....	10.4
[10.202] Air cleaners and lines	10.5
[10.254] Intake and exhaust manifolds and muffler	10.6
[10.400] Engine cooling system	10.7
[10.414] Fan and drive	10.8
[10.310] Aftercooler.....	10.9
[10.304] Engine lubrication system.....	10.10
Hydrostatic drive	29
[29.204] Reservoir, cooler, and lines	29.1
[29.218] Pump and motor components.....	29.2
[29.202] Hydrostatic transmission	29.3
Brakes and controls	33
[33.202] Hydraulic service brakes	33.1
Hydraulic systems	35
[35.000] Hydraulic systems	35.1
[35.300] Reservoir, cooler, and filters.....	35.2
[35.104] Fixed displacement pump.....	35.3
[35.106] Variable displacement pump	35.4
[35.204] Remote control valves	35.5
[35.610] Machine leveling control system	35.6
[35.946] Frame positioning lifting	35.7

[35.948] Frame positioning extending	35.8
[35.903] Shaking hydraulic system	35.9
[35.904] Cleaning hydraulic system	35.10
[35.902] Harvesting hopper hydraulic system	35.11
[35.706] Fruit repartition system.....	35.12
[35.310] Distributor and lines	35.13
Frames and ballasting	39
[39.100] Frame	39.1
[39.110] Drawbar and hitch assembly	39.2
Steering.....	41
[41.101] Steering control	41.1
Wheels	44
[44.511] Front wheels.....	44.1
[44.520] Rear wheels.....	44.2
[44.000] Wheels	44.3
Cab climate control	50
[50.200] Air conditioning	50.1
[50.300] Cab pressurizing system.....	50.2
Electrical systems	55
[55.000] Electrical system	55.1
[55.100] Harnesses and connectors.....	55.2
[55.101] Chassis harness	55.3
[55.988] Selective Catalytic Reduction (SCR) electrical system	55.4
[55.640] Electronic modules.....	55.5
[55.019] Hydrostatic drive control system	55.6
[55.512] Cab controls.....	55.7
[55.408] Warning indicators, alarms, and instruments	55.8
[55.DTC] FAULT CODES.....	55.9

Fruit harvester shaking	56
[56.300] Shaking frame	56.1
[56.301] Shaking control	56.2
[56.304] Connecting rods, front plates, and shakers	56.3
[56.305] Adjustable width system	56.4
Product feeding	60
[60.304] Noria	60.1
[60.320] Fruit harvester conveyor belts	60.2
[60.324] Fruit harvester conveyor frame	60.3
Residue handling	73
[73.500] Stalk chopper	73.1
Cleaning	74
[74.200] Upper extractors	74.1
[74.204] Lower extractors	74.2
Secondary cleaning/Destemmer	76
[76.660] Destemmer	76.1
[76.200] Sorting table (Opti-grape™)	76.2
Crop storage / Unloading	80
[80.300] Fruit conveying system	80.1
Accessories	88
[88.100] Accessories	88.1
Tools	89
[89.165] Water kit	89.1

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com