

OPERATOR'S MANUAL

OVERHEAD FRAME RAKE

| WR3310

| WR3312

| WR3313

| WR3315



HSMFG0908

5HPOMR7

TABLE OF CONTENTS

TABLE OF CONTENTS.....	INSIDE COVER
WARRANTY & NOTES.....	1
DEALER PRE-DELIVERY & DELIVERY CHECKLIST.....	3
SPECIFICATIONS.....	5
BOLT TORQUE CHART.....	6
BE ALERT SYMBOL.....	7
SAFETY RULES.....	8-9
DANGER - WARNING DECALS.....	10
OPERATION WR3310, WR3312, WR3313 & WR3315.....	11-14
ADJUSTMENTS.....	14
LUBRICATION WR3310, WR3312, WR3013 & WR3315.....	15
DECAL LOCATION.....	16
OPTIONAL EQUIPMENT.....	17
TROUBLE SHOOTING.....	18
ORDERING PARTS - ABOUT IMPROVEMENTS.....	19
PARTS LISTS & DIAGRAMS WR3310, WR3312, WR3313 & WR3315.....	20-35
SERVICE RECORDS.....	36

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com