






1. Trim along dashed line.
2. Slide into pocket on Binder Spine.

TYPE 1-4




1. Trim along dashed line.
2. Slide into pocket on Binder Spine.

TYPE 1-4



1. Trim along dashed line.
2. Slide into pocket on Binder Spine.

TYPE 1-4



1. Trim along dashed line.
2. Slide into pocket on Binder Spine.

TYPE 1-4

2155 Cotton Picker Service Manual No.7-63243 Table of Contents

Description	PC Code	Section No.	Form No.
General		Tab 1	
LOCTITE® Product Chart	2		8-98902
Standard Torque Specifications	5	1001	8-71602
Fluid and Lubricants	4	1010	7-63272
Engine		Tab 2	
6TA-830 Engine			
Aftercooler	6	2011	8-91703
Specification Details	10	2403	8-28426
Cylinder Head and Valve Train	42	2415	8-28434
Cylinder Block	80	2425	8-28444
Lubrication System	14	2445	8-28453
Cooling System	12	2455	8-28464
Turbocharger	26	2465	8-28471
Fuel System		Tab 3	
Fuel System and Filters	4	3410	8-28482
Injection Pump	28	3412	8-28494
Fuel Injectors	22	3413	8-28503
Electrical		Tab 4	
Electrical Schematics and Troubleshooting	52	4002	7-62820
Electrical Schematic Prior to P.I.N. JJC0156231 (Refer to pocket at rear of Service Manual)			7-63750
Electrical Schematic P.I.N. JJC0156231 and after (Refer to pocket at rear of Service Manual)			7-66390
Starting Motor - Nippendoso	22	4011	8-95970
Battery Servicing and Testing	10	4235	8-20291
Alternator	24	4240	7-62451
Steering		Tab 5	
Steering Axle	16	5003	8-99061
Steering Hand Pump	14	5020	7-62571
Steering Cylinder	12	5030	8-62441

Description	PC Code	Section No.	Form No.
Power Train		Tab 6	
Foot - N - Inch Valve	4	6015	7-63830
Hydrostatic Drive Pump Service	14	6018	7-64341
Hydrostatic Drive Motor Service	10	6030	7-64121
Transmission Service	40	6040	7-63351
Drum Drive	16	6051	8-82772
Final Drives	14	6060	7-63491
Cable Adjustment	6	6080	7-89540
Brakes		Tab 7	
Brake Assemblies	13	7010	7-62541
Master Brake Valve	13	7020	7-62550
Hydraulics		Tab 8	
Hydraulic Schematic and Troubleshooting	28	8002	7-62810
Hydraulic Schematic (Refer to pocket at rear of Service Manual)			7-63750
Hydraulic Oil Filter	4	8030	7-63291
Hydraulic Pump and Compensator	33	8040	8-62480
Hydraulic Gear Pump	10	8045	7-86310
Hydraulic Manifold Valve	6	8051	8-99022
Height Control Valves and Cylinders	12	8062	8-99111
Chassis		Tab 9	
Air Conditioning Troubleshooting	21	9010	7-86210
Air Conditioning System Gauges and Testing	24	9020	7-63310
Air Conditioning System Service for R134A	12	9030	7-85540
Air Conditioning Components Service	30	9040	7-63331
Air Suspension Seat	8	9065	7-60911
Fan Assembly	22	9070	8-62222
Pressure Moistener System	10	9075	7-64011
Picker Drum Removal and Installation	8	9081	8-99191
Picker Drum Service	54	9091	6-11951
Picker Bar and Spindle Lubrication System	6	9092	8-98611
Drum Gearboxes and Input Driveshaft	12	9093	8-99101

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com