

# 8575 Baler & Accumulator

## Table of Contents

DIVISION / SECTION	SECTION NO.	FORM NO.
<b>1 GENERAL</b>		
Index		Rac 7-81770-1
Introduction .....	1001	Rac 7-81780
Safety Rules, General Machine Specifications, and Standard Torque Specifications .....	1002	Rac 7-81790
Maintenance and Lubrication .....	1003	Rac 7-81800
Decals .....	1004	Rac 7-81810
<b>2 DRIVE SYSTEM</b>		
Index		Rac 7-81770-2
Connecting the Tractor, Implement Drive Line, Main Drive Shaft, and Main Drive Clutch .....	2001	Rac 7-81820
Flywheel, Flywheel Brake, and Gearbox .....	2002	Rac 7-81830
Auxiliary Drives .....	2003	Rac 7-81840
<b>3 PICKUP</b>		
Index		Rac 7-81770-3
Pickup Operation, Adjustments, Gauge Wheels, and Troubleshooting .....	3001	Rac 7-81850
<b>4 ELECTRICAL SYSTEM</b>		
Index		Rac 7-81770-4
Electrical Schematics and Troubleshooting .....	4001	Rac 7-81860
<b>5 FEEDER AND PLUNGER</b>		
Index		Rac 7-81770-5
Packer .....	5001	Rac 7-81870
Stuffer and Charge Chamber .....	5002	Rac 7-81880
Plunger .....	5003	Rac 7-81890
<b>6 KNOTTER SYSTEM</b>		
Index		Rac 7-81770-6
Knotter .....	6001	Rac 7-81900



<b>7</b>	<b>MAINFRAME, BALE TENSION, AND WHEELS</b>	
	Index	Rac 7-81770-7
	Mainframe and Bale Tension .....	7001 Rac 7-81910
	Axle, Wheels, and Tires .....	7002 Rac 7-81920
<b>8</b>	<b>HYDRAULIC SYSTEM</b>	
	Index	Rac 7-81770-8
	Hydraulic System Operation, Schematics, and Troubleshooting .....	8001 Rac 7-81930
	Control Valves .....	8002 Rac 7-81940
	Cylinders .....	8003 Rac 7-81950
<b>9</b>	<b>OPTIONAL EQUIPMENT</b>	
	Index	Rac 7-81770-9
	Centralized Lubrication System .....	9001 Rac 7-81960
	Accumulator, Bale Chutes, Bale Ejector, and Selector Valve .....	9002 Rac 7-81970

# DIVISION 1

## INDEX

1

SECTION TITLE	SECTION NUMBER
Introduction .....	1001
Safety Rules, General Machine Specifications, and Standard Torque Specifications .....	1002
Maintenance and Lubrication .....	1003
Decals .....	1004

# Section 1001

## INTRODUCTION

### TABLE OF CONTENTS

General Information .....	1001-2
To Our Customer .....	1001-2
Introduction .....	1001-2
Serial Number Location .....	1001-3
Replacement Parts .....	1001-3
U. S. and Metric Units .....	1001-3
Table of Contents .....	1001-3
Page Numbers .....	1001-3

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)