

# 8840 Windrower

## Table of Contents

DIVISION / SECTION	SECTION NO.	FORM NO.
<b>1 GENERAL</b>		
Index		Rac 8-97500-1
Introduction .....	1001	Rac 8-97130
Safety Rules, General Machine Specifications, and Standard Torque Specifications .....	1002	Rac 8-97141
Maintenance and Lubrication .....	1003	Rac 8-97151
Decals .....	1004	Rac 8-97160
Specification Details .....	1024	Rac 8-24162
<b>2 ENGINE</b>		
Index		Rac 8-97500-2
Engine Removal and Installation and Radiator Removal and Installation .....	2001	Rac 8-97170
Engine Accessories .....	2002	Rac 8-97180
Cylinder Head and Valve Train .....	2415	Rac 8-24172
Cylinder Block .....	2425	Rac 8-24182
Lubrication System .....	2445	Don 8-24192
Cooling System .....	2455	Don 8-24202
Turbocharger .....	2465	Rac 8-25550
Turbocharger Failure Analysis .....	2565	Rac 9-78235
<b>3 FUEL SYSTEM</b>		
Index		Rac 8-97500-3
Fuel System and Engine Controls .....	3001	Rac 8-97190
Fuel System and Filters .....	3410	Rac 8-24212
Fuel Injectors .....	3413	Don 8-24232
Bosch Fuel Injection .....	3415	Don 7-37140
<b>4 ELECTRICAL SYSTEM</b>		
Index		Rac 8-97500-4
Removal and Installation of Electrical Components .....	4001	Rac 8-97200
Specifications, Schematics, Troubleshooting, and Using Booster Batteries to Start the Engine .....	4002	Rac 8-97210
Instruments .....	4004	Rac 8-97220
<b>5 STEERING</b>		
Index		Rac 8-97500-5
Removal and Installation of Steering Components .....	5001	Rac 8-97231
Steering Control Linkage Troubleshooting and Adjustments .....	5002	Rac 8-97240

<b>6</b>	<b>POWER TRAIN</b>	
	Index	Rac 8-97500-6
	Ground Drive Hydraulic System Specifications, Operation, Schematics, Troubleshooting, and Tests .....	6001 Rac 8-97250
	Charge Pump .....	6010 Rac 8-97260
	Tandem Pump.....	6011 Rac 8-97270
	Drive Motors .....	6020 Rac 8-97280
	Two Speed Control Valve and Two Speed Cylinder .....	6030 Rac 8-97290
	Drive Controls .....	6031 Rac 8-97300
	Drive Shafts.....	6050 Rac 8-97310
	Chain Cases.....	6051 Rac 8-97321
	Wheels and Tires .....	6052 Rac 8-97330
<b>7</b>	<b>BRAKES</b>	
	Index	Rac 8-97500-7
	Parking Brake.....	7001 Rac 8-97340
<b>8</b>	<b>HYDRAULIC SYSTEM</b>	
	Index	Rac 8-97500-8
	Hydraulic System Specifications, Operation, Schematics, Troubleshooting, and Tests .....	8001 Rac 8-97350
	Cleaning the Hydraulic System .....	8003 Rac 8-97360
	Header Drive Pump.....	8010 Rac 8-97370
	Header Drive Motor .....	8020 Rac 8-97380
	Header Lift and Flotation Valve, Guard Angle Control Valve, and Bypass Valve .....	8030 Rac 8-97390
	Accumulator .....	8040 Rac 8-97400
	Cylinders .....	8090 Rac 8-97410
<b>9</b>	<b>CHASSIS</b>	
	Index	Rac 8-97500-9
	Removal and Installation of Air Conditioning Components .....	9000 Rac 8-97420
	Air Conditioning Troubleshooting and System Checks ...	9001 Rac 8-97430
	Air Conditioning System.....	9002 Rac 8-97440
	Cab .....	9003 Rac 8-97450
	Header .....	9011 Rac 8-97460
	Removal and Installation of Double Windrow Hydraulic Components .....	9012 Rac 8-97470
	Double Windrow Attachment.....	9013 Rac 8-97480
	Walking Beam .....	9020 Rac 8-97490

# DIVISION 1

## INDEX

SECTION TITLE	SECTION NUMBER
Introduction .....	1001
Safety Rules, General Machine Specifications, and Standard Torque Specifications .....	1002
Maintenance and Lubrication .....	1003
Decals .....	1004
Detailed Engine Specifications .....	1024

# Section 1001

## INTRODUCTION

### TABLE OF CONTENTS

General Information .....	1001-2
To Our Customer .....	1001-2
Serial Number Location .....	1001-2
Replacement Parts .....	1001-3
U. S. and Metric Units .....	1001-3
Table of Contents .....	1001-3
Page Numbers .....	1001-3

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)