

SERVICE MANUAL

**CR6090 / CR7090 / CR8080 /
CR8090 / CR9090**

**Tier 4a
Combine**

Part number 84561155
1st edition English
July 2012



Contents

INTRODUCTION

Engine.....	10
Fuel filters	10.206
Aftercooler.....	10.310
Engine cooling system	10.400
Oil cooler and lines	10.408
Fan and drive.....	10.414
Rotary screen.....	10.418
Engine air compressor	10.450
Selective Catalytic Reduction (SCR) exhaust treatment	10.500
Main gearbox and drive	14
Main gearbox and drive	14.100
Transmission.....	21
Mechanical transmission	21.114
Mechanical transmission external controls	21.130
Gearbox internal components	21.145
Differential	21.182
Front axle system	25
Powered front axle	25.100
Final drives	25.310
Rear axle system.....	27
Powered rear axle	27.100
Hydrostatic drive.....	29
Transmission and steering hydrostatic control	29.100
Two-speed assembly	29.134
Hydrostatic transmission	29.202
Reservoir, cooler, and lines.....	29.204

Pump and motor components	29.218
Rear hydrostatic transmission	29.300
Brakes and controls	33
Parking brake / Parking lock	33.110
Hydraulic service brakes	33.202
Hydraulic systems.....	35
Hydraulic systems	35.000
Pump control valves	35.102
Variable displacement pump	35.106
Auxiliary hydraulic pump and lines	35.220
Reservoir, cooler, and filters	35.300
Main control valve	35.359
Header/Attachment height system	35.410
Header/Attachment tilting system	35.415
Grain tank unload system	35.440
Traction variator system	35.450
Reel control system	35.518
Crop processor system.....	35.536
Header/Attachment leveling system.....	35.602
Header reverser drive	35.760
Chaff spreader control.....	35.796
Stone trapping system.....	35.992
Steering.....	41
Steering control.....	41.101
Hydraulic control components.....	41.200
Pump	41.206
Cylinders	41.216
Autoguidance steering.....	41.432
Tracks and track suspension.....	48

Tracks	48.100
Track frame and driving wheels	48.130
Track tension units	48.134
Cab climate control	50
Heating	50.100
Ventilation	50.104
Air conditioning	50.200
Electrical systems	55
Electrical system	55.000
Fuel injection system	55.010
Fuel tank system	55.011
Engine cooling system	55.012
Engine oil system.....	55.013
Engine intake and exhaust system	55.014
Engine control system	55.015
Hydrostatic drive control system	55.019
Transmission control system	55.024
Gearbox electric system.....	55.029
Service brake electrical system	55.030
Parking brake electrical system	55.031
Hydraulic system control	55.036
Heating, Ventilation, and Air-Conditioning (HVAC) control system	55.050
Cab Heating, Ventilation, and Air-Conditioning (HVAC) controls.....	55.051
Harnesses and connectors	55.100
Engine starting system	55.201
Cold start aid	55.202
Alternator	55.301
External lighting	55.404
Warning indicators, alarms, and instruments.....	55.408

Feeding control system.....	55.421
Cleaning control system.....	55.423
Harvest material flow control system.....	55.426
Cab controls.....	55.512
Wiper/Washer system.....	55.518
Cab brake controls.....	55.519
Cab harvesting controls.....	55.520
Ground speed control.....	55.610
Reverser electric control.....	55.618
Residue handling control.....	55.624
Threshing electrical control.....	55.628
Electronic modules.....	55.640
Cab header controls.....	55.661
Header height control.....	55.662
Header leveling control.....	55.670
Shaker shoe leveling system control.....	55.780
Precision farming system.....	55.785
Rotary screen drive and cleaning.....	55.830
Sieve electric control.....	55.834
Rotary separator control.....	55.836
Global Positioning System (GPS).....	55.911
Selective Catalytic Reduction (SCR) electrical system.....	55.988
FAULT CODES.....	55.DTC
Product feeding.....	60
Floating roll, feed chain, and drive.....	60.105
Feeder housing.....	60.110
Stone trapping system.....	60.112
Feeder housing shafts.....	60.130
Feeder drive system.....	60.150

Threshing	66
Threshing	66.000
Concave conveyor plate	66.101
Concave	66.105
Concave control system	66.110
Threshing mechanism drive system	66.260
Drum/Rotor variator with electrical control	66.321
Rotor	66.331
Drum/Rotor housing	66.360
Residue handling	73
Straw chopper drive system	73.210
Straw chopper frame	73.220
Straw chopper	73.230
Positive Straw Discharge (PSD)	73.300
Chaff spreader	73.335
Cleaning	74
Cleaning	74.000
Self-leveling frame	74.100
Cleaning drive systems	74.101
Grain pan	74.110
Upper shaker shoe	74.114
Lower shaker shoe	74.118
Fan housing	74.130
Fan drive system	74.136
Tailings return system	74.140
Crop storage / Unloading	80
Clean grain elevator	80.101
Grain tank	80.150
Grain tank unload drive system	80.175

Grain tank unload.....	80.180
Platform, cab, bodywork, and decals.....	90
Machine shields and guards.....	90.105
Protections and footboards.....	90.118
Pneumatically-adjusted operator seat.....	90.124
Cab.....	90.150
Cab interior.....	90.151
Cab doors and hatches.....	90.154

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com