





Bobcat®

Service Manual Tree Spade

TS24T Convertible S/N A9SK00101 & Above
TS24T (Bobcat Only) S/N A9U200101 & Above
TS24M Convertible S/N A9SN00101 & Above
TS24M (Bobcat Only) S/N A9U500101 & Above
TS24C Convertible S/N A9UW00101 & Above
TS24C (Bobcat Only) S/N A9VC00101 & Above
TS28T Convertible S/N A8WG00101 & Above
TS28T (Bobcat Only) S/N A9U800101 & Above
TS28M Convertible S/N A9RT00101 & Above
TS28M (Bobcat Only) S/N A9UB00101 & Above
TS28C Convertible S/N A9V000101 & Above
TS28C (Bobcat Only) S/N A9VE00101 & Above
TS32T Convertible S/N A9TS00101 & Above
TS32T (Bobcat Only) S/N A9UE00101 & Above

TS32M Convertible S/N A9TV00101 & Above
TS32M (Bobcat Only) S/N A9UH00101 & Above
TS32C Convertible S/N A9V300101 & Above
TS32C (Bobcat Only) S/N A9VG00101 & Above
TS36T Convertible S/N A9SA00101 & Above
TS36T (Bobcat Only) S/N A9UL00101 & Above
TS36M Convertible S/N A9TZ00101 & Above
TS36M (Bobcat Only) S/N A9UP00101 & Above
TS36C Convertible S/N A9V600101 & Above
TS36C (Bobcat Only) S/N A9VJ00101 & Above
TS44 Convertible S/N A9SG00101 & Above
TS44 (Bobcat Only) S/N A9UT00101 & Above
TS44C Convertible S/N A9V900101 & Above
TS44C (Bobcat Only) S/N A9VL00101 & Above



CONTENTS

SAFETY & MAINTENANCE	10-01
HYDRAULIC SYSTEM	20-01
MAINFRAME	30-01
SPECIFICATIONS	SPEC-01
ALPHABETICAL INDEX	INDEX-01

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com