





Page Number	Page Title	Page Reference
01-000-TOC	ENGINE, FUEL AND EXHAUST SYSTEM	01-000-TOC
02-000-TOC	AXLES	02-000-TOC
03-000-TOC	DRIVE TRAIN SYSTEM	03-000-TOC
04-000-TOC	HYDRAULIC SYSTEM	04-000-TOC
05-000-TOC	ELECTRICAL SYSTEM	05-000-TOC
06-000-TOC	CAB	06-000-TOC
07-000-TOC	PLATFORM	07-000-TOC
08-000-TOC	CHASSIS	08-000-TOC
09-000-TOC	WHEELS	09-000-TOC
10-000-TOC	IMPLEMENT DRIVE SYSTEM	10-000-TOC
11-000-TOC	LINKAGE	11-000-TOC
12-000-TOC	ACCESSORIES	12-000-TOC



Massey Ferguson**MF 455XTRA TRACTOR (BR)****C045501****ENGINE INSTALLATION****Page01-0001****4 WHEELS DRIVE - WITH OPERATOR PLATAFORM UP TO SERIAL NUMREM - BC002499**

Item	Part Number	Qty	Description Comments	Technical Specification
1	6262835M91	1	KIT, MOTOR SEE PAGE 01-0009 Perkins	TIER 2
2	048498N1	1	FASTENER SEE PAGE 02-0037	
3	054571N1	1	FASTENER SEE PAGE 03-0030	

MF 455XTRA TRACTOR (BR)
6262835M91




Item	Part Number	Qty	Description Comments	Technical Specification
1	6209160M91	1	KIT, MOTOR SEE PAGE 01-0082 SEE PAGE 01-0010 SEE PAGE 01-0011 SEE PAGE 01-0012 SEE PAGE 01-0013 SEE PAGE 01-0014 SEE PAGE 01-0015 SEE PAGE 01-0016 SEE PAGE 01-0017 SEE PAGE 01-0018 SEE PAGE 01-0019 SEE PAGE 01-0020 SEE PAGE 01-0021 SEE PAGE 01-0022 SEE PAGE 01-0024 SEE PAGE 01-0023 SEE PAGE 01-0025 SEE PAGE 01-0026 SEE PAGE 01-0027 SEE PAGE 01-0028 SEE PAGE 01-0029 SEE PAGE 01-0030 SEE PAGE 01-0031 SEE PAGE 01-0032 SEE PAGE 01-0033 SEE PAGE 01-0034 SEE PAGE 01-0035 SEE PAGE 01-0036 SEE PAGE 01-0037 SEE PAGE 01-0038 SEE PAGE 01-0039 SEE PAGE 01-0040 SEE PAGE 01-0041 SEE PAGE 01-0042 SEE PAGE 01-0043	TIER 2 100 HP



Item	Part Number	Qty	Description Comments	Technical Specification
1			SEE PAGE 01-0044	
1			SEE PAGE 01-0045	
1			SEE PAGE 01-0046	
1			SEE PAGE 01-0047	
1			SEE PAGE 01-0048	
1			SEE PAGE 01-0049	
1			SEE PAGE 01-0050	
1			SEE PAGE 01-0051	
1			SEE PAGE 01-0052	
1			SEE PAGE 01-0053	
			SEE PAGE 01-0054	
1			SEE PAGE 01-0055	
1			SEE PAGE 01-0056	
1			SEE PAGE 01-0057	
1			SEE PAGE 01-0058	
1			SEE PAGE 01-0059	
1			SEE PAGE 01-0060	
1			SEE PAGE 01-0061	
1			SEE PAGE 01-0062	
1			SEE PAGE 01-0063	
1			SEE PAGE 01-0064	
1			SEE PAGE 01-0065	
1			SEE PAGE 01-0066	
1			SEE PAGE 01-0067	
1			SEE PAGE 01-0068	
1			SEE PAGE 01-0069	
1			SEE PAGE 01-0070	
1			SEE PAGE 01-0071	
1			SEE PAGE 01-0072	
1			SEE PAGE 01-0073	
1			SEE PAGE 01-0074	
1			SEE PAGE 01-0075	
1			SEE PAGE 01-0076	
1			SEE PAGE 01-0077	
1			SEE PAGE 01-0078	

Item	Part Number	Qty	Description Comments	Technical Specification
2	3821818M94	1	STARTERMOTOR SEE PAGE 01-0219 ISKRA	
2	6306847M91	1	STARTERMOTOR LETRIKA FROM SERIAL OR ENGINE NUMBER EC005680 SEE PAGE 01-0220	
3	339402X1	3	HEX NUT	M10 (1.5) ISO 8 ZN
4	339376X1	3	LOCKWASHER	M10 ZN
5	6227381M1	1	TURNBUCKLE	
6	3408222M1	1	BOLT	7/16" X 20UNC X 31/8"
7	339369X1	1	LOCKWASHER	M12 ZN
8	1441516X1	1	FLAT WASHER	?11-21 X 1,5 MM PL
9	353426X1	1	NUT	7/16"-20 SAE 5 ZN
11	391388X1	1	FLAT WASHER	?10,5-18 X 2,5 MM ZN
12	339376X1	1	LOCKWASHER	M10 ZN
13	3002369X1	1	SCREW	M10X2510.9
14	6203323M91	1	KIT, BELT	
15	739800M1	1	FAN	
16	6200897M1	1	FAN SPACER HUB	
17	339368X1	4	HEXAGONAL HEAD BOLT	M8 X 60 (1.25) ISO 8.8 ZN
18	339374X1	4	LOCKWASHER	M8 ZN
35	6200883M91	1	ALTERNATOR BRACKET	
36	1442487X1	1	HEXAGONAL HEAD BOLT	M10 X 130 ISO 8.8 ZN
37	353432X1	1	LOCK WASHER	7/16"
38	339402X1	1	HEX NUT	M10 (1.5) ISO 8 ZN
39	6200887M1	1	BUSH	
40	6283266M91	1	ALTERNATOR SEE PAGE 01-0221 ISKRA	12V 55A
40	6306845M91	1	ALTERNATOR LETRIKA FROM SERIAL OR ENGINE NUMBER EC005680 SEE PAGE 01-0222	12V 55A
42	3408222M1	2	BOLT	7/16" X 20UNC X 31/8"
43	353426X1	2	NUT	7/16"-20 SAE 5 ZN
44	339369X1	2	LOCKWASHER	M12 ZN

MF 455XTRA TRACTOR (BR)
6201003M91AA




Item	Part Number	Qty	Description Comments	Technical Specification
1	4227015M91	1	KIT,CYL.BLOCK	
7	733072M1	10	THIMBLE	
8	1476108X1	10	HEX CAP SCREW	
9	4224829M1	1	BUSH	
10	4224874M1	1	PLUG	
11	4224873M1	2	PLUG	
12	733067M1	1	PLUG	
13	731354M1	1	PLUG	
14	4224863M1	1	PLUG	
15	4224009M1	2	DOWEL	
16	4224866M1	2	PLUG	
18	4224865M1	1	PLUG	
19	3641648M1	4	HEXAGON FLANGE BOLT	
20	4224717M1	4	JET	
21	3638435M1	4	HEX CAP SCREW	M8 X 20
22	4224936M1	1	BLANKING PLATE	
23	4224973M1	1	GASKET	




Massey Ferguson**MF 455XTRA TRACTOR (BR)****C045501****STARTER MOTOR ISKRA****Page01-0219**

Item	Part Number	Qty	Description Comments
1	6230902M1	1	SUPPORT
2	3903761M1	2	BUSH
4	6230905M91	1	KIT, SOLENOID
6	3904360M1	1	DRIVE GEAR
7	6230908M1	1	LEVER
8	6230909M1	1	REDUCER
9	6230919M1	1	ARMATURE
10	3904362M91	1	KIT, BEARING
11	3904363M91	1	PARTS PACK
12	6230913M1	1	STATOR
13	3904364M91	1	HOLDER
14	3904365M91	1	KIT, BRUSH
15	6230916M1	1	COVER
18	3821818M94	1	STARTERMOTOR 12V - 4,2 kW




Massey Ferguson**MF 455XTRA TRACTOR (BR)****C045501****STARTER****Page01-0220**

Item	Part Number	Qty	Description Comments
1	6306858M1	1	HOUSING
2	3903761M1	1	BUSH
4	6230905M91	1	KIT, SOLENOID
6	6306859M1	1	IMPELLER
7	6306860M1	1	LEVER
8	6230909M1	1	REDUCER
9	6230919M1	1	ARMATURE
10	3904362M91	1	KIT, BEARING
11	3904363M91	1	PARTS PACK
12	6306861M1	1	STATOR
13	3904364M91	1	HOLDER
14	3904365M91	1	KIT, BRUSH
15	6230916M1	1	COVER




Massey Ferguson**MF 455XTRA TRACTOR (BR)****C045501****ALTERNATOR****Page01-0221****14V 55A ISKRA**

Item	Part Number	Qty	Description Comments
1	6230922M1	1	FAN
2	6269002M1	1	ASSEMBLE IN FACTORY BEARING CARRIER
3	6284438M91	1	OVERALL (54)
4	6230925M1	1	STATOR
5	6284439M1	1	KIT, BOLT
6	6284440M1	1	ROTOR
7	6284449M91	1	KIT, PULLEY
8	6284446M91	1	KIT, BRUSH
9	6230930M91	1	BEARING
10	6230950M91	1	RECTIFIER
11	6284441M1	1	PILLOW BLOCK
12	6284442M1	1	CAPACITOR
13	6284443M1	1	PROTECTIVE COVER
14	6284445M91	1	REGULATOR
15	6284444M1	1	SEAL




Massey Ferguson**MF 455XTRA TRACTOR (BR)****C045501****ALTERNATOR****Page01-0222****14V 55A LETRIKA**

Item	Part Number	Qty	Description Comments
1	6230922M1	1	FAN
2	6269002M1	1	ASSEMBLE IN FACTORY BEARING CARRIER
3	6284438M1	1	KIT, BEARING
4	6230925M1	1	STATOR
5	6284439M1	1	KIT, BOLT
6	6305882M1	1	ROTOR
7	6284449M91	1	KIT, PULLEY
9	6230930M91	1	BEARING
10	6306868M1	1	RECTIFIER
11	6284441M1	1	PILLOW BLOCK
12	6284442M1	1	CAPACITOR
13	6284443M1	1	PROTECTIVE COVER
14	6306869M1	1	PROTECTION
15	6284445M91	1	REGULATOR






Item	Part Number	Qty	Description Comments	Technical Specification
FRONT AXLE				
1	368748X1	6	NUT UNF	5/8-18-SAE 8-PH
2	894825M1	X	SHIM THICKNESS 0.25MM	TH. .010? 0,25MM
	894826M1	X	SHIM THICKNESS 0.50MM	TH. .020? 0,50MM
3	1484677M1	2	SPACER	
4	036660P1	2	STUD BOLT	5/8 -18UNF X M16-2
5	048507P1	2	STUD BOLT	
6	043962P1	1	SPACER RIGHT HAND	RH / LD
7	043961P1	1	SPACER LEFT HAND	LH / LE
8	2801086M1	2	STUD BOLT	5/8" X 5/8"



Item	Part Number	Qty	Description Comments	Technical Specification
TRANSMISSION				
1	353565X1	1	HEXAGONAL HEAD BOLT	7/16-20 X 1.75-SAE 5-ZN
2	048512P1	1	BOLT	M12X30 11.9
3	191314M1	2	LOCATOR	
4	3589413M1	5	STUD BOLT	7/16"
5	069676T1	5	NUT	7/16 X 20
6	353711X1	4	HEXAGONAL HEAD BOLT	7/16-14 X 2.62-SAE 5-ZN
7	069676T1	3	NUT	7/16 X 20
8	3589413M1	3	STUD BOLT	7/16"
9	069676T1	1	NUT	7/16 X 20
10	353432X1	1	LOCK WASHER	7/16"

MF 455XTRA TRACTOR (BR)
T0218387



Massey Ferguson

MF 455XTRA TRACTOR (BR)

C045501


ENGINE

Page01-0002

2 WHEELS DRIVE - WITH OPERATOR PLATAFORM UP TO SERIAL NUMBER - BC002499

Item	Part Number	Qty	Description Comments	Technical Specification
1	6262835M91	1	KIT, MOTOR SEE PAGE 01-0009 Perkins	TIER 2
2	048500N1	1	FASTENER SEE PAGE 02-0036	
3	054571N1	1	FASTENER SEE PAGE 03-0030	

MF 455XTRA TRACTOR (BR)
6262835M91



Item	Part Number	Qty	Description Comments	Technical Specification
1	6209160M91	1	KIT, MOTOR SEE PAGE 01-0082 SEE PAGE 01-0010 SEE PAGE 01-0011 SEE PAGE 01-0012 SEE PAGE 01-0013 SEE PAGE 01-0014 SEE PAGE 01-0015 SEE PAGE 01-0016 SEE PAGE 01-0017 SEE PAGE 01-0018 SEE PAGE 01-0019 SEE PAGE 01-0020 SEE PAGE 01-0021 SEE PAGE 01-0022 SEE PAGE 01-0024 SEE PAGE 01-0023 SEE PAGE 01-0025 SEE PAGE 01-0026 SEE PAGE 01-0027 SEE PAGE 01-0028 SEE PAGE 01-0029 SEE PAGE 01-0030 SEE PAGE 01-0031 SEE PAGE 01-0032 SEE PAGE 01-0033 SEE PAGE 01-0034 SEE PAGE 01-0035 SEE PAGE 01-0036 SEE PAGE 01-0037 SEE PAGE 01-0038 SEE PAGE 01-0039 SEE PAGE 01-0040 SEE PAGE 01-0041 SEE PAGE 01-0042 SEE PAGE 01-0043	TIER 2 100 HP

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com