

**PUMA 170 / 170 CVT  
PUMA 185 / 185 CVT  
PUMA 200 / 200 CVT  
PUMA 215 / 215 CVT  
PUMA 230 CVT**  
Tractor

**SERVICE MANUAL**

**Part number 47524345**

English

June 2013

Replaces part number 84476208A



## Link Product / Engine

---

<b>Product</b>	<b>Market Product</b>	<b>Engine</b>
PUMA 185	North America	F4DFE613K*A
PUMA 200	North America	F4DFE613J*A
PUMA 215	North America	F4DFE613H*A
PUMA 170 CVT	North America	F4DFE613L*A
PUMA 185 CVT	North America	F4DFE613K*A
PUMA 200 CVT	North America	F4DFE613J*A
PUMA 215 CVT	North America	F4DFE613H*A
PUMA 230 CVT	North America	F4DFE613G*A
PUMA 170	North America	F4DFE613L*A

# Contents

---

## INTRODUCTION

Engine.....	10
[10.001] Engine and crankcase .....	10.1
[10.102] Pan and covers .....	10.2
[10.216] Fuel tanks .....	10.3
[10.210] Lift pump and lines .....	10.4
[10.218] Fuel injection system.....	10.5
[10.250] Turbocharger and lines.....	10.6
[10.254] Intake and exhaust manifolds and muffler .....	10.7
[10.500] Selective Catalytic Reduction (SCR) exhaust treatment.....	10.8
[10.400] Engine cooling system .....	10.9
[10.414] Fan and drive .....	10.10
[10.408] Oil cooler and lines.....	10.11
Transmission.....	21
[21.113] Powershift transmission .....	21.1
[21.155] Powershift transmission internal components.....	21.2
[21.160] Creeper .....	21.3
[21.166] Overdrive.....	21.4
[21.504] Continuously Variable Transmission (CVT) .....	21.5
[21.505] Continuously Variable Transmission (CVT) external controls.....	21.6
[21.506] Continuously Variable Transmission (CVT) lubrication system .....	21.7
[21.507] Continuously Variable Transmission (CVT) internal components .....	21.8
[21.109] Transmission cooler and lines.....	21.9
Four-Wheel Drive (4WD) system .....	23
[23.202] Electro-hydraulic control .....	23.1
[23.314] Drive shaft.....	23.2
Front axle system .....	25

[25.100] Powered front axle .....	25.1
[25.102] Front bevel gear set and differential .....	25.2
[25.108] Final drive hub, steering knuckles, and shafts .....	25.3
[25.122] Axle suspension control .....	25.4
<b>Rear axle system.....</b>	<b>27</b>
[27.100] Powered rear axle.....	27.1
[27.106] Rear bevel gear set and differential .....	27.2
[27.120] Planetary and final drives .....	27.3
<b>Power Take-Off (PTO).....</b>	<b>31</b>
[31.101] Rear mechanical control .....	31.1
[31.104] Rear electro-hydraulic control.....	31.2
[31.114] Two-speed rear Power Take-Off (PTO) .....	31.3
[31.116] Three-speed rear Power Take-Off (PTO) .....	31.4
[31.119] Four-speed rear Power Take-Off (PTO).....	31.5
[31.146] Front Power Take-Off (PTO) .....	31.6
<b>Brakes and controls .....</b>	<b>33</b>
[33.202] Hydraulic service brakes .....	33.1
[33.110] Parking brake or parking lock .....	33.2
[33.220] Trailer brake hydraulic control.....	33.3
[33.224] Trailer brake pneumatic control .....	33.4
[33.350] Anti-lock Brake System (ABS) .....	33.5
<b>Hydraulic systems.....</b>	<b>35</b>
[35.000] Hydraulic systems.....	35.1
[35.300] Reservoir, cooler, and filters.....	35.2
[35.106] Variable displacement pump .....	35.3
[35.102] Pump control valves.....	35.4
[35.105] Charge pump.....	35.5
[35.322] Regulated/Low pressure system .....	35.6

[35.204] Remote control valves .....	35.7
[35.220] Auxiliary hydraulic pump and lines .....	35.8
[35.114] Three-point hitch control valve .....	35.9
[35.162] Front hitch cylinders and lines .....	35.10
<b>Pneumatic system .....</b>	<b>36</b>
[36.100] Pneumatic system .....	36.1
<b>Hitches, drawbars, and implement couplings .....</b>	<b>37</b>
[37.120] Rear three-point hitch linkage .....	37.1
[37.162] Front hitch .....	37.2
[37.110] Rear three-point hitch .....	37.3
[37.106] Automatic pickup hitch .....	37.4
<b>Frames and ballasting .....</b>	<b>39</b>
[39.100] Frame .....	39.1
<b>Steering .....</b>	<b>41</b>
[41.101] Steering control .....	41.1
[41.106] Tie rods .....	41.2
[41.200] Hydraulic control components .....	41.3
[41.216] Cylinders .....	41.4
[41.432] Autoguidance steering .....	41.5
<b>Wheels .....</b>	<b>44</b>
[44.511] Front wheels .....	44.1
[44.520] Rear wheels .....	44.2
<b>Cab climate control .....</b>	<b>50</b>
[50.100] Heating .....	50.1
[50.104] Ventilation .....	50.2
[50.200] Air conditioning .....	50.3
<b>Electrical systems .....</b>	<b>55</b>
[55.610] Ground speed control .....	55.1

[55.000] Electrical system ..... 55.2

[55.100] Harnesses and connectors..... 55.3

[55.015] Engine control system..... 55.4

[55.301] Alternator..... 55.5

[55.302] Battery..... 55.6

[55.988] Selective Catalytic Reduction (SCR) electrical system ..... 55.7

[55.640] Electronic modules..... 55.8

[55.513] Cab transmission controls..... 55.9

[55.024] Transmission control system..... 55.10

[55.020] Transmission speed sensors..... 55.11

[55.021] Transmission pressure sensors..... 55.12

[55.022] Transmission temperature sensors ..... 55.13

[55.045] Front axle control system ..... 55.14

[55.048] Rear Power Take-Off (PTO) control system ..... 55.15

[55.049] Front Power Take-Off (PTO) control system ..... 55.16

[55.031] Parking brake electrical system ..... 55.17

[55.035] Remote control valve electric control ..... 55.18

[55.051] Cab Heating, Ventilation, and Air-Conditioning (HVAC) controls..... 55.19

[55.050] Heating, Ventilation, and Air-Conditioning (HVAC) control system..... 55.20

[55.047] Steering control system ..... 55.21

[55.523] Cab hitch controls ..... 55.22

[55.130] Rear three-point hitch electronic control system ..... 55.23

[55.911] Global Positioning System (GPS) ..... 55.24

[55.680] Autopilot/Autoguidance ..... 55.25

[55.408] Warning indicators, alarms, and instruments ..... 55.26

[55.350] Anti-lock Brake System (ABS) electrical system..... 55.27

[55.032] Trailer brake electrical system ..... 55.28

[55.030] Service brake electrical system ..... 55.29

[55.DTC] FAULT CODES..... 55.30

Platform, cab, bodywork, and decals .....	90
[90.100] Engine hood and panels .....	90.1
[90.150] Cab.....	90.2

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)