






010 COMPLETE ENGINE

Pos.	Part No.	Description	Dimension	Quantity	Conditions
1	00 2195 419 0	ENGINE		1	1)
1	00 2195 425 0	ENGINE		1	2)
1	00 2195 433 0	ENGINE		1	3)
1	00 2195 431 0	ENGINE		1	4)
1)	Equipment	TH_100_0005	4-cylinder engine, 74 hp / rated output ECE R24		
2)	Equipment	TH_100_0006	4-cylinder engine, 86 hp / rated output ECE R24		
3)	Equipment	TH_100_0007	4-cylinder engine, 90 hp / rated output ECE R24		
4)	Equipment	TH_100_0008	4-cylinder engine, 100 hp / rated output ECE R24		




100 CRANKCASE

Pos.	Part No.	Description	Dimension	Quantity	Conditions
1	00 1136 979 0	PLUG		1	
2	00 1136 980 0	PLUG		1	
3	00 1136 981 0	NOZZLE		4	
4	00 1136 983 0	SCREW		4	
5	00 1136 984 0	PLUG		1	
6	00 1136 985 0	SCREW		1	
7	00 1136 986 0	FLAT GASKET		1	
8	77 0103 156 7	SCREW		10	
9	77 0103 156 6	SPACER		10	
10	00 1143 775 0	BEARING		1	
11	00 1136 989 0	FLAT GASKET		1	
12	00 1136 990 0	PLATE		1	
13	00 1136 991 0	SCREW		4	
14	00 1153 834 0	COVER		1	
15	00 1136 993 0	LOCATING PIN		2	
16	00 1136 994 0	PLUG		2	
17	01 2268 100 0	PLUG		1	
18	00 1136 995 0	PLUG		1	
19	01 2268 100 0	PLUG		1	
20	00 2486 700 7	PLUG		1	




100 CRANKCASE

Pos.	Part No.	Description	Dimension	Quantity	Conditions
1	00 1141 817 0	SHORT BLOCK		1	




120 TIMING CASE

Pos.	Part No.	Description	Dimension	Quantity	Conditions
1	00 1136 997 0	HOUSING		1	
2	00 1136 998 0	GASKET		1	
3	00 1137 003 0	PLUG		1	
4	00 1136 991 0	SCREW		4	
5	00 1137 004 0	SEALING RING		1	
6	77 0103 164 0	SCREW		2	
7	60 0500 503 4	SCREW		6	
8	00 1137 006 0	O-RING	61,6 X 2,4 ACM	1	
9	00 1137 007 0	PLATE		1	




120 TIMING CASE

Pos.	Part No.	Description	Dimension	Quantity	Conditions
1	00 1137 008 0	COVER		1	
2	00 1137 009 0	SEALING RING		1	
3	77 0103 163 9	SCREW		5	
4	00 1137 010 0	SCREW		9	




120 TIMING CASE

Pos.	Part No.	Description	Dimension	Quantity	Conditions
1	00 1137 011 0	TUBE		1	
2	00 1137 012 0	O-RING		1	
3	00 1137 013 0	PLUG		1	
4	00 1137 014 0	SCREW		1	
5	00 1137 015 0	SCREW		1	
6	01 2261 970 0	PLUG		1	




140 FLYWHEEL HOUSING

Pos.	Part No.	Description	Dimension	Quantity	Conditions
1	00 1109 215 0	CASING		1	
2	00 1137 017 0	SCREW		2	
3	00 1137 018 0	SCREW		4	
4	00 1137 019 0	SCREW		2	
5	00 1137 019 0	SCREW		1	
6	60 0500 010 0	CENTRING PIN		2	
7	00 1137 020 0	NUT		5	
8	00 1137 021 0	STUD BOLT		5	
9	00 1137 017 0	SCREW		1	




160 OIL PAN

Pos.	Part No.	Description	Dimension	Quantity	Conditions
1	00 1110 949 0	CASING		1	
2	00 1137 042 0	PLUG		1	
3	00 1137 043 0	SEALING RING		1	
4	00 1137 044 0	SCREW		2	
5	00 1137 045 0	BRACE		1	
6	00 1137 046 0	STUD		2	
7	00 1137 047 0	GAUGE		1	
8	00 1137 048 0	DIPSTICK		1	
9	00 1137 049 0	SEALING RING		1	
10	00 1137 050 0	NUT		2	
11	60 0500 010 7	PLUG		2	
12	00 1137 051 0	O-RING		1	
13	00 1137 053 0	SCREW		12	
14	00 1137 052 0	SCREW		1	
15	00 1137 471 0	SCREW		5	




180 PLUGS

Pos.	Part No.	Description	Dimension	Quantity	Conditions
1	00 1136 996 0	PLUG		1	



100 CYLINDER LINER, PISTON

Pos.	Part No.	Description	Dimension	Quantity	Conditions
1	00 1137 054 0	PLUNGER		4	
2	00 1137 055 0	ENGINE PISTON RING		4	
3	00 1137 056 0	CIRCLIP		8	



Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com