

Fig. 025 INLET MANIFOLD




Fig. 025 INLET MANIFOLD

Key No	Part No	Description	Qty	S.C	Serial No	ICA	Replacable	Qty
1	240203-00111	MANIFOLD,INTAKE	1					
7	400602-00537	GASKET;IN MANIFOLD	6					
20	120312-00102	NUT	12					
30	400601-00010	CUP;SEALING OD=32	2					
50A	420209-00187	PIPE,INLET	1					
50B	420209-00186	PIPE,INLET	1					
53A	120112-00325	BOLT M8X80	3					
53B	120112-00277	BOLT M10X60	2					
53C	120112-00285	BOLT M10X90	1					
97	301308-00004	SENSOR;AIR TEMP INLET	1					
104	120112-00885	BOLT	4					
122A	120112-00272	BOLT M10X35	1					
122B	120112-00256	BOLT M10X100	1					
122C	120112-00865	BOLT;BRACKET	2					
122D	120112-00258	BOLT M10X110	1					
153	400602-00226	GASKET;PLUG	1					
170	120112-00262	BOLT M10X20	1					
172	110413-00046	BRACKET;HARNESS	2					
247	110406-02002	BRACKET	1					
298	420209-00188	PIPE,INLET	1					
340	110406-02012	BRACKET	1					
341	120112-00314	BOLT M8X16	4					
372	120402-00291	CLIP,HOSE	1					
373	410139-00067	THROTTLE;INTAKE	1					
496	120501-02228	PIN,KNOCK	2					
562A	120112-00270	BOLT M10X30	1					
562B	120112-00278	BOLT M10X65	2					
568A	120112-00270	BOLT M10X30	5					
568B	120112-00282	BOLT M10X80	1					
723A	110406-02015	BRACKET	1					
723B	110406-02016	BRACKET	1					
756	400602-00538	GASKET;INTAKE	2					
761	301308-00270	SENSOR;MANIFOLD	1					
779	120112-00884	BOLT;SENSOR	2					
781	400602-00543	GASKET;SENSOR	1					
782	430201-00657	ADAPTER;SENSOR	1					

Fig. 027 EXHAUST MANIFOLD




Fig. 027 EXHAUST MANIFOLD

Key No	Part No	Description	Qty	S.C	Serial No	ICA	Replacable	Qty
2	400602-00200A	GASKET;EX MANIFOLD	6					
5	240102-00180	MANIFOLD,EXHAUST;FRONT	1					
6	240102-00181	MANIFOLD,EXHAUST;REAR	1					
18	120312-00107	NUT	18					
34	110917-00073	COLLAR L=28	14					
47	240102-00179	MANIFOLD,EXHAUST;CENTER	1					
49	120408-00025	STUD:M10X25 L=47	4					
155A	401107-00654	SEAL,RING;EXH MANIFOLD	4					
155B	401107-00653	SEAL,RING;EXH MANIFOLD	2					

Fig. 028 BREATHER SYSTEM




Fig. 028 BREATHER SYSTEM

Key No	Part No	Description	Qty	S.C	Serial No	ICA	Replacable	Qty
1	400811-00018	BREATHER;AIR	1					
9	400602-00185	GASKET;AIR BREATHER	2					
10	120402-00120	CLIP;AIR BREATHER	1					
11	420108-00654	HOSE,RUBBER	1					
24A	120402-00305	CLIP,HOSE	1					
24B	120402-00306	CLIP,HOSE	2					
84	120112-00316	BOLT M8X20	3					
91A	120112-00262	BOLT M10X20	2					
91B	120112-00266	BOLT M10X25	2					
145	430201-00656	ADAPTER;AIR BREATHER	1					

Fig. 030 WATER PUMP AND CORROSION




Fig. 030 WATER PUMP AND CORROSION

Key No	Part No	Description	Qty	S.C	Serial No	ICA	Replacable	Qty
1	400921-00210	PUMP ASSY,WATER	1					
3	400602-00229	GASKET;PUMP-CYLINDER	1					
4	101529-00273	KIT,REPAIR;WATER PUMP	1					
10A	140105-00095	BEARING;WATER PUMP	1					
10B	140105-00096	BEARING;WATER PUMP	1					
16	401106-00134	SEAL;OIL;WATER PUMP	1					
17	401107-00655	SEAL;WATER PUMP	1					
18	400902-00034	IMPELLER	1					
19	400602-00190	GASKET;COVER- BODY	1					
20	110508-10268	COVER,WATER PUMP	1					
24A	120112-00266	BOLT M10X25	2					
24B	120112-00285	BOLT M10X90	4					
29	130712-00307	SHAFT,PUMP;WATER	1					
45A	430216-00083	JOINT;HEATER HOSE	2					
45B	430216-00082	JOINT	1					
104	400602-00237	GASKET;WATER PUMP	1					
119A	120112-00321	BOLT M8X40	4					
119B	120112-00262	BOLT M10X20	1					
139	130412-00053	GEAR,DRIVE;WATER PUMP	1					

Fig. 031 THERMOSTAT AND HOUSING




Fig. 031 THERMOSTAT AND HOUSING

Key No	Part No	Description	Qty	S.C	Serial No	ICA	Replacable	Qty
1	300738-00101	THERMOSTAT	2					
2	110980-00076	HOUSING,THERMOSTAT	1					
12	120112-00266	BOLT M10X25	5					
20	401107-00652	SEAL;RING	2					
26	2.453-00013	CAP;SEALING	1					
50A	120112-00280	BOLT M10X70	2					
50B	120112-00284	BOLT M10X85	2					
50C	120112-00285	BOLT M10X90	2					
58	430221-00225	PLUG M16X12	2					
59	400602-00214	GASKET;JOINT BOLT	2					
60A	400602-00221	GASKET;OUTLET PIPE ID=55.6	1					
60B	400602-00222	GASKET;OUTLET PIPE ID=62.6	1					
66A	400627-00003	GASKET,THERMOSTAT;HSG	1					
66B	400627-00002	GASKET,THERMOSTAT;HSG	1					
79A	120402-00301	CLIP,HOSE	1					
79B	120402-00291	CLIP,HOSE	1					
112	430221-00652	PLUG	1					
193	110910-00510	CAP,RUBBER	1					
207	400602-00174	GASKET	2					
266	109675-0860	BOLT;EYE M14X27	1					
267	400602-00174	GASKET	2					
287	430201-00260	ADAPTER	2					
292	410202-00021	COCK;AIR	1					
299	515411-2231	EYE JOINT;SEDIMENTER	1					

Fig. 032 WATER PIPING




Fig. 032 WATER PIPING

Key No	Part No	Description	Qty	S.C	Serial No	ICA	Replacable	Qty
1	420210-00338A	PIPE;WATER PUMP,INLET	1					
24A	110406-02021	BRACKET	1					
24B	110406-02022	BRACKET	1					
24C	110406-02023	BRACKET	1					
24D	110406-02024	BRACKET	1					
24E	110406-02025	BRACKET	1					
24F	110406-02026	BRACKET	1					
24G	110406-02027	BRACKET	1					
24H	110406-02028	BRACKET	1					
24I	110406-02029	BRACKET	1					
24J	110406-02030	BRACKET	4					
24K	110406-02031	BRACKET	1					
24L	110406-02032	BRACKET	1					
31A	120112-00321	BOLT M8X40	14					
31B	120112-00324	BOLT M8X70	7					
33A	120112-00314	BOLT M8X16	6					
33B	120112-00322	BOLT M8X60	2					
33C	120112-00256	BOLT M10X100	1					
33D	120112-00262	BOLT M10X20	7					
35A	120402-00302	CLIP,HOSE	24					
35B	120402-00303	CLIP,HOSE	56					
48	400602-00223	GASKET;PIPE-PUMP	1					
50C	120112-00270	BOLT M10X30	1					
50D	120112-00282	BOLT M10X80	1					
50E	120112-00300	BOLT M14X25	1					
56	420211-00159	PIPE;WATER OUTLET	1					
108	110406-02020	BRACKET	1					
113A	420108-00267	HOSE	1					
113B	420108-00267	HOSE	1					
113C	420108-00655	HOSE,RUBBER	1					
113D	420108-00267	HOSE	1					
113E	420108-00267	HOSE	1					
115A	420108-00271	HOSE;RUBBER	2					
115B	420108-00649	HOSE,RUBBER	1					
115C	420108-00650	HOSE,RUBBER	2					
115D	420108-00651	HOSE,RUBBER	2					

Key No	Part No	Description	Qty	S.C	Serial No	ICA	Replacable	Qty
115E	420108-00652	HOSE,RUBBER	6					
115F	420108-00653	HOSE,RUBBER	1					
126A	400602-00174	GASKET	2					
126B	2.180-00661	PACKING,PLUG	4					
126C	400602-00531	GASKET	1					
127A	120112-00309	BOLT M16X30	2					
127B	120112-00879	BOLT:EYE	2					
206A	420211-00309	PIPE,WATER:EGR COOLER	1					
206B	420211-00310	PIPE,WATER:EGR COOLER	1					
206C	420211-00311	PIPE,WATER:EGR COOLER	1					
206D	420211-00312	PIPE,WATER:EGR COOLER	1					
206E	420211-00313	PIPE,WATER:EGR COOLER	1					
206F	420211-00314	PIPE,WATER:EGR COOLER	1					
206G	420211-00315	PIPE,WATER:EGR COOLER	1					
206H	420211-00316	PIPE,WATER:EGR COOLER	1					
805	430208-00096	CONNECTER:AIR LEAK	1					
806	120402-00301	CLIP,HOSE	10					

Fig. 033 IDLE PULLEY





Fig. 033 IDLE PULLEY

Key No	Part No	Description	Qty	S.C	Serial No	ICA	Replacable	Qty
86	120112-00249	BOLT	1					
126	130710-00010	PULLEY;IDLE	1					
126B	130710-00011	PULLEY;IDLE	1					
130A	110951-00239	SPACER,BEARING;IDLE PULLEY	1					
130B	110951-00240	SPACER,BEARING;IDLE PULLEY	1					
132	110508-01739	COVER:DUST	2					
133	110413-00048	BRACKET;IDLE PULLEY	1					
134	130713-00227	SPINDLE;IDLE PULLEY	1					
140	120312-00109	NUT M18	1					
221	120112-00282	BOLT M10X80	4					
224	140105-00094	BEARING;IDLE PULLEY	2					

Fig. 036 TURBO CHARGER & OIL PIPE



Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com