

5220, 5320, 5420, and 5520 Tractor Repair

TECHNICAL MANUAL 5220, 5320, 5420, and 5520 Tractor Repair

TM2048 15MAR02 (ENGLISH)

For complete service information also see:

5220, 5320, 5420, and 5520 Tractor Operation and Test	TM2049
Component Technical Manual 4045 Engine	CTM104
Component Technical Manual 4045 Mechanical Fuel System	CTM207
Component Technical Manual 3029 Engine	CTM125
Alternators and Starting Motors.....	CTM77

John Deere Augusta Works
LITHO IN U.S.A.

Contents

SECTION 10—General Information

- Group 05—Safety
- Group 10—General Specifications
- Group 20—Fuel and Lubricants
- Group 25—Serial Number Locations
- Group 30—Features and Accessories

SECTION 20—Engine Repair

- Group 05—Engine
- Group 10—Cooling System

SECTION 30—Fuel and Air Repair

- Group 05—Fuel System
- Group 10—Air Intake System
- Group 15—Speed Control Linkage

SECTION 40—Electrical Repair

- Group 05—Battery, Starter and Alternator
- Group 10—Electrical System Components
- Group 15—Wiring Harness

SECTION 50—Power Train Repair

- Group 05—Clutch Housing
- Group 10—Clutch Assembly—
CollarShift/SyncShuttle™ Transmissions
- Group 11—Clutch Assembly—PowrReverser™
Transmission
- Group 12—PowrReverser™
- Group 15—CollarShift/SyncShuttle™ Transmission
- Group 16—PowrReverser™ Transmission
- Group 20—Rear PTO Drive Shaft
- Group 25—Differential
- Group 30—Final Drives
- Group 31—Hi-Crop Final Drives
- Group 35—Mechanical Front Wheel Drive
- Group 40—Creeper Assembly

SECTION 60—Steering and Brake Repair

- Group 05—Steering Repair
- Group 10—Brake Repair

SECTION 70—Hydraulic Repair

- Group 05—Hydraulic Pump and Filter
- Group 06—Hydraulic Oil Cooler

- Group 10—Rockshaft
- Group 15—Selective Control Valve
- Group 20—Hydraulic Mid Mount Control Valve

SECTION 80—Miscellaneous Repair

- Group 05—Front Axle—2WD
- Group 10—Wheels
- Group 15—3-Point Hitch
- Group 20—Fenders

SECTION 90—Operator Station Repair

- Group 05—Seat and Support
- Group 06—Control Console and Panel
- Group 10—ROLL-GARD
- Group 15—Cab Components
- Group 16—Isolated Open Operator Station
Components
- Group 20—Air Conditioning System
- Group 25—Heating System

10

20

30

40

50

60

70

80

90

INDX

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com