

RX and SX Series Riding Mowers

TECHNICAL MANUAL

**John Deere
Lawn & Grounds Care Division
TM1391 (JUN-88)**

Contents

SECTION 10—SAFETY AND SPECIFICATIONS

- Group 05—Safety
- Group 10—Repair Specifications

SECTION 20—ENGINE

- Group 01—Engine Repair
- Group 05—Engine Removal and Installation

SECTION 30—FUEL AND AIR SYSTEM REPAIR

- Group 01—Air Cleaner, Breather and Carburetor
- Group 05—Fuel Transfer System
- Group 10—Fuel and Air System

SECTION 50—POWER TRAIN REPAIR

- Group 05—Clutch Linkage and Belts
- Group 10—Variable Speed System
- Group 15—Transaxle
- Group 20—PTO Linkage

SECTION 60—STEERING AND BRAKE REPAIR

- Group 05—Steering System Repair
- Group 10—Brake Repair

SECTION 80—MISCELLANEOUS REPAIR

- Group 05—Mower Spindles
- Group 10—Mower Deck and Lift Linkage
- Group 15—Engine Shroud

SECTION 210—SPECIFICATIONS AND OPERATIONAL CHECKOUT

- Group 01—Specifications
- Group 05—Operational Checkout Procedure

SECTION 220—ENGINE/FUEL SYSTEM OPERATION AND TESTS

- Group 05—Engine/Fuel System Checkout
- Group 10—Engine/Fuel System Diagnosis

SECTION 240—ELECTRICAL OPERATION AND TESTS

- Group 05—Electrical System Checkout
- Group 10—Electrical System Diagnosis

Group 15—Component Locations/Wiring Diagrams

SECTION 250—POWER TRAIN OPERATION AND TESTS

- Group 05—Power Train System Checkout
- Group 10—Power Train System Diagnosis

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

TM1391-19-17APR90

COPYRIGHT© 1989
DEERE & COMPANY
Moline, Illinois
All rights reserved
A John Deere ILLUSTRATION™ Manual

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com