

# Instructions for Parts Books

The heading at the top of the page will be the same for the picture of the parts at it is for the page with the part numbers.

Definition of column headings on part number pages:

**REF.No** → The number referring to the part on the picture page of the parts book.

**Part No.** → The number assigned to this part at the time of printing the parts book.

**Description** → Discription of part.

**Q'ty** → Quantity of part used on that page.

**S.No.** → Serial number range of the equipment that this part will fit.

>= Your serial number should be greater than or equal to the number shown.

<= Your serial number should be lesser than or equal to the serial number shown.

**I/C** → Interchangeability of part shown.

↔ The part shown will work for the older and later serial number.

# The part shown is not interchangeable with the other serial number.

← new for old

→ old for new

**Remarks** → Notes about this particulart part. Sometimes this may say except [FR] or [CA]


## Note about Country Codes:

The parts books we use in the United States of America may also contain information about a part that would be different in another country. It is important that you are aware of the country codes in some instances.

| Symbol | Country                  |
|--------|--------------------------|
| A      | United States of America |
| CA     | Canada                   |
| FR     | France                   |
| GR     | Greece                   |
| PO     | Portugal                 |
| AU     | Australia                |

If the remarks column says for example EXCEPT [FR] this part works in all countries except France. That means it will work here in the USA.


ALL PRODUCT INDEX  
L355SS



| Item          | Part No. | Description                      | Book     |
|---------------|----------|----------------------------------|----------|
| ENGINE        | 01001    | CRANKCASE                        | 100K0347 |
|               | 01002    | OIL PAN                          | 100K0347 |
|               | 01003    | CYLINDER HEAD                    | 100K0347 |
|               | 01004    | GEAR CASE                        | 100K0347 |
|               | 01005    | MAIN BEARING CASE                | 100K0347 |
|               | 01006    | AIR CLEANER                      | 100K0347 |
|               | 01007    | EXHAUST MANIFOLD                 | 100K0347 |
|               | 01008    | VALVE,ROCKER ARM                 | 100K0347 |
|               | 01009    | HEAD COVER                       | 100K0347 |
|               | 01010    | CAMSHAFT                         | 100K0347 |
|               | 01011    | PISTON,CRANKSHAFT                | 100K0347 |
|               | 01012    | FLYWHEEL                         | 100K0347 |
|               | 01013    | STARTER SECTION PARTS            | 100K0347 |
|               | 01014    | FUEL CAMSHAFT                    | 100K0347 |
|               | 01015    | GOVERNOR                         | 100K0347 |
|               | 01016    | SPEED CONTROL PLATE              | 100K0347 |
|               | 01017    | ENGINE STOP LEVER                | 100K0347 |
|               | 01018    | DYNAMO                           | 100K0347 |
|               | 01019    | DYNAMO SECTION PARTS             | 100K0347 |
|               | 01020    | RADIATOR                         | 100K0347 |
|               | 01021    | WATER PUMP                       | 100K0347 |
|               | 01022    | INJECTION PUMP                   | 100K0347 |
|               | 01023    | INJECTION PUMP SECTION PARTS     | 100K0347 |
|               | 01024    | NOZZLE HOLDER                    | 100K0347 |
|               | 01025    | NOZZLE HOLDER SECTION PARTS      | 100K0347 |
|               | 01026    | OIL HYDRAULIC PUMP               | 100K0347 |
|               | 01027    | OIL HYDRAULIC PUMP SECTION PARTS | 100K0347 |
| BODY ASSEMBLY | 01028    | AIR CLEANER SUPPORT              | 100K0347 |
|               | 01029    | FLYWHEEL HOUSING                 | 100K0347 |
|               | 01030    | CLUTCH HOUSING                   | 100K0347 |
|               | 01031    | OIL HYDRAULIC MANIFOLD           | 100K0347 |
|               | 01032    | CLUTCH SHAFT UPPER               | 100K0347 |
|               | 01033    | CLUTCH SHAFT LOWER               | 100K0347 |
|               | 01034    | REVERSE SHAFT                    | 100K0347 |
|               | 01035    | CLUTCH                           | 100K0347 |
|               | 01036    | CLUTCH PEDAL                     | 100K0347 |
|               | 01037    | HAND ACCELERATOR                 | 100K0347 |
|               | 01038    | HOOD 1                           | 100K0347 |
|               | 01039    | HOOD 2                           | 100K0347 |
|               | 01040    | TRANSMISSION CASE                | 100K0347 |
|               | 01041    | MAIN SHAFT                       | 100K0347 |
|               | 01042    | COUNTER SHAFT                    | 100K0347 |
|               | 01043    | PTO COUNTER SHAFT                | 100K0347 |
|               | 01044    | SPIRAL BEVEL PINION              | 100K0347 |
|               | 01045    | POWER TAKE-OFF SHAFT             | 100K0347 |
|               | 01046    | MAIN SHIFT LEVER                 | 100K0347 |
|               | 01047    | MAIN SHIFT FORK                  | 100K0347 |
|               | 01048    | HI-LO GEAR SHIFT LEVER           | 100K0347 |
|               | 01049    | PTO GEAR SHIFT LEVER             | 100K0347 |
|               | 01050    | SHUTTLE LEVER                    | 100K0347 |
|               | 01051    | DIFFERENTIAL SYSTEM              | 100K0347 |
|               | 01052    | DIFF LOCK PEDAL                  | 100K0347 |
|               | 01053    | DIFF YOKE SHAFT                  | 100K0347 |
|               | 01054    | REAR AXLE                        | 100K0347 |
|               | 01055    | AXLE CASE                        | 100K0347 |
|               | 01056    | BRAKE                            | 100K0347 |
|               | 01057    | BRAKE PEDAL                      | 100K0347 |

| Item                             | Part No. | Description                       | Book     |
|----------------------------------|----------|-----------------------------------|----------|
| BODY ASSEMBLY                    | 01058    | STEP                              | 100K0347 |
|                                  | 01059    | PANEL                             | 100K0347 |
|                                  | 01060    | HOUR METER AND SWITCH             | 100K0347 |
|                                  | 01061    | REGULATOR                         | 100K0347 |
|                                  | 01062    | BATTERY                           | 100K0347 |
|                                  | 01063    | HEAD LAMP                         | 100K0347 |
|                                  | 01064    | WIRING DIAGRAM                    | 100K0347 |
|                                  | 01065    | FUEL FILTER                       | 100K0347 |
|                                  | 01066    | FUEL FILTER SECTION PARTS         | 100K0347 |
|                                  | 01067    | OIL HYDRAULIC SYSTEM              | 100K0347 |
|                                  | 01068    | CONTROL VALVE SECTION PARTS       | 100K0347 |
|                                  | 01069    | RELIEF VALVE SECTION PARTS        | 100K0347 |
|                                  | 01070    | CONTROL LEVER                     | 100K0347 |
|                                  | 01071    | LEVER GUIDE                       | 100K0347 |
|                                  | 01072    | OIL HYDRAULIC CYLINDER            | 100K0347 |
|                                  | 01073    | OIL HYDRAULIC CYLINDER COVER      | 100K0347 |
|                                  | 01074    | LIFT ARM                          | 100K0347 |
|                                  | 01075    | OIL HYDRAULIC PIPING              | 100K0347 |
|                                  | 01076    | FRONT DIFF GEAR CASE              | 100K0347 |
|                                  | 01077    | FRONT DIFF CASE                   | 100K0347 |
|                                  | 01078    | FRONT AXLE SUPPORT                | 100K0347 |
|                                  | 01079    | AXLE CASE                         | 100K0347 |
|                                  | 01080    | BEVEL GEAR SHAFT                  | 100K0347 |
|                                  | 01081    | FRONT AXLE                        | 100K0347 |
|                                  | 01082    | TIE ROD                           | 100K0347 |
|                                  | 01083    | FRONT AXLE BRACKET                | 100K0347 |
|                                  | 01084    | CENTER PIN                        | 100K0347 |
|                                  | 01085    | PROPELLER SHAFT                   | 100K0347 |
|                                  | 01086    | DRIVE CASE                        | 100K0347 |
|                                  | 01087    | DRIVE SHAFT                       | 100K0347 |
| THREE-POINT LINK ASSEMBLY        | 01088    | 3-POINT LINK 1                    | 100K0347 |
|                                  | 01089    | 3-POINT LINK 2                    | 100K0347 |
| INTEGRAL POWER STEERING ASSEMBLY | 01090    | POWER STEERING                    | 100K0347 |
|                                  | 01091    | OIL TANK                          | 100K0347 |
|                                  | 01092    | FUEL TANK                         | 100K0347 |
| SWING DRAWBAR ASSEMBLY           | 01093    | SWING DRAWBAR                     | 100K0347 |
| TAIL LAMP ASSEMBLY               | 01094    | TAIL LAMP                         | 100K0347 |
| HAZARD LAMP ASSEMBLY             | 01095    | HAZARD LAMP                       | 100K0347 |
| LABEL ASSEMBLY                   | 01096    | LABEL                             | 100K0347 |
| BALUSTRIDE ASSEMBLY              | 01097    | BALUSTRIDE                        | 100K0347 |
| SEAT ASSEMBLY                    | 01098    | SEAT                              | 100K0347 |
| S.M.V. EMBLEM BRACKET            | 01099    | S.M.V. EMBLEM BRACKET             | 100K0347 |
| FENDER ASSEMBLY                  | 01100    | FENDER                            | 100K0347 |
| SHUTTLE CONTROL VALVE            | 01101    | CONTROL VALVE                     | 100K0347 |
|                                  | 01102    | CONTROL VALVE SECTION PARTS 1     | 100K0347 |
|                                  | 01103    | CONTROL VALVE SECTION PARTS 2     | 100K0347 |
| UPPER MUFFLER ASSEMBLY           | 01104    | UPPER MUFFLER                     | 100K0347 |
| POSITION CONTROL ASSEMBLY        | 01105    | TOP LINK HOLDER                   | 100K0347 |
| DRAFT CONTROL ASSEMBLY           | 01106    | DRAFT CONTROL VALVE               | 100K0347 |
|                                  | 01107    | DRAFT CONTROL VALVE SECTION PARTS | 100K0347 |
| SECTION PARTS GROUP              | 01108    | TOP LINK BRACKET                  | 100K0347 |
|                                  | 01109    | VALVE, FLOW PRIORITY              | 100K0347 |
|                                  | 01110    | INTEGRAL TYPE POWER STEERING      | 100K0347 |

## CRANKCASE






## CRANKCASE

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

| REF.No | Part No.    | Description         | Q'ty | S.No. | I/C | REMARKS             | Weight (kgf) | Weight (lb) |
|--------|-------------|---------------------|------|-------|-----|---------------------|--------------|-------------|
| 001    | 15424-01010 | ASSY CRANKCASE      | 1    |       |     |                     | 54.5         | 119.9       |
| 002    | 99999-99999 | BLANK               | 0    |       |     | ORDER BY REF.No.001 | 0            | 0           |
| 003    | 15521-96020 | PLUG                | 6    |       |     |                     | 0.003        | 0.0066      |
| 004    | 34150-27580 | PLUG                | 1    |       |     |                     | 0.001        | 0.0022      |
| 005    | 15521-96030 | PLUG                | 2    |       |     |                     | 0.007        | 0.0154      |
| 006    | 32210-27580 | PLUG                | 19   |       |     |                     | 0.001        | 0.0022      |
| 007    | 06311-75018 | PLUG,EXPANSION      | 3    |       |     |                     | 0.004        | 0.0088      |
| 008    | 06311-75045 | PLUG,EXPANSION      | 1    |       |     |                     | 0.026        | 0.0572      |
| 009    | 15221-03380 | CAP,SEALING         | 6    |       |     |                     | 0.017        | 0.0374      |
| 010    | 15221-03390 | CAP,SEALING         | 2    |       |     |                     | 0.03         | 0.066       |
| 011    | 05012-00408 | PIN,STRAIGHT        | 2    |       |     |                     | 0.001        | 0.0022      |
| 012    | 05012-00609 | PIN,STRAIGHT        | 2    |       |     |                     | 0.003        | 0.0066      |
| 013    | 05012-00612 | PIN,STRAIGHT        | 2    |       |     |                     | 0.003        | 0.0066      |
| 014    | 05012-01018 | PIN,STRAIGHT        | 3    |       |     |                     | 0.012        | 0.0264      |
| 015    | 15221-33650 | PIN,PIPE            | 1    |       |     |                     | 0.004        | 0.0088      |
| 016    | 15291-73160 | JOINT,DRAIN COCK    | 1    |       |     |                     | 0.04         | 0.088       |
| 017    | 15201-02310 | LINER,CYLINDER      | 4    |       |     |                     | 0.57         | 1.254       |
| 018    | 15575-73100 | COCK,DRAIN          | 1    |       |     |                     | 0.065        | 0.143       |
| 019    | 15471-35010 | ASSY PUMP,OIL       | 1    |       |     |                     | 0            | 0           |
| 020    | 15221-35150 | GASKET,OIL PUMP     | 1    |       |     |                     | 0            | 0           |
| 021    | 01053-50650 | BOLT                | 4    |       |     |                     | 0.011        | 0.0242      |
| 022    | 04512-50060 | WASHER,SPRING       | 4    |       |     |                     | 0            | 0           |
| 023    | 19202-35660 | GEAR,OIL PUMP DRIVE | 1    |       |     |                     | 0.23         | 0.506       |
| 024    | 05712-00410 | KEY,FEATHER         | 1    |       |     |                     | 0.001        | 0.0022      |
| 025    | 15221-35680 | NUT                 | 1    |       |     |                     | 0            | 0           |
| 026    | 15221-35670 | WASHER              | 1    |       |     |                     | 0.005        | 0.011       |
| 027    | 15221-39010 | SWITCH,OIL          | 1    |       |     |                     | 0            | 0           |
| 028    | 15221-33610 | PLUG                | 1    |       |     |                     | 0.009        | 0.0198      |
| 029    | 15021-33660 | GASKET              | 1    |       |     |                     | 0.001        | 0.0022      |
| 030    | 15221-33700 | O RING              | 1    |       |     |                     | 0.001        | 0.0022      |

## OIL PAN






## OIL PAN

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

| REF.No | Part No.    | Description    | Q'ty | S.No. | I/C | REMARKS | Weight (kgf) | Weight (lb) |
|--------|-------------|----------------|------|-------|-----|---------|--------------|-------------|
| 001    | 15415-01610 | OIL PAN        | 1    |       |     |         | 15.4         | 33.88       |
| 002    | 15401-01620 | GASKET,OIL PAN | 1    |       |     |         | 0            | 0           |
| 003    | 15411-91010 | BOLT           | 4    |       |     |         | 0            | 0           |
| 004    | 01133-51035 | BOLT           | 16   |       |     |         | 0.03         | 0.066       |
| 005    | 15415-91010 | BOLT           | 2    |       |     |         | 0.075        | 0.165       |
| 006    | 01133-51050 | BOLT           | 2    |       |     |         | 0.035        | 0.077       |
| 007    | 15415-04690 | SHIM           | 2    |       |     |         | 0.03         | 0.066       |
| 008    | 04512-50100 | WASHER         | 6    |       |     |         | 0            | 0           |
| 009    | 15221-33750 | PLUG           | 2    |       |     |         | 0.032        | 0.0704      |
| 010    | 15109-33660 | GASKET         | 2    |       |     |         | 0.001        | 0.0022      |
| 011    | 15411-32110 | FILTER,OIL 1   | 1    |       |     |         | 0.24         | 0.528       |
| 012    | 01123-50816 | BOLT           | 1    |       |     |         | 0.011        | 0.0242      |
| 013    | 04811-00160 | O RING         | 1    |       |     |         | 0.001        | 0.0022      |
| 014    | 19222-36410 | GAUGE,OIL      | 1    |       |     |         | 0.04         | 0.088       |
| 015    | 15411-94510 | PIN            | 2    |       |     |         | 0.01         | 0.022       |



## CYLINDER HEAD






## CYLINDER HEAD

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

| REF.No | Part No.    | Description          | Q'ty | S.No. | I/C | REMARKS             | Weight (kgf) | Weight (lb) |
|--------|-------------|----------------------|------|-------|-----|---------------------|--------------|-------------|
| 001    | 15221-01750 | HOOK,ENGINE          | 2    |       |     |                     | 0.04         | 0.088       |
| 002    | 01123-50816 | BOLT                 | 1    |       |     |                     | 0.011        | 0.0242      |
| 003    | 15471-91530 | STUD                 | 2    |       |     |                     | 0.01         | 0.022       |
| 004    | 02156-50080 | NUT                  | 1    |       |     |                     | 0.004        | 0.0088      |
| 005    | 04512-50080 | WASHER,SPRING        | 1    |       |     |                     | 0.001        | 0.0022      |
| 006    | 15422-03040 | ASSY CYLINDER HEAD   | 1    |       |     |                     | 0            | 0           |
| 007    | 99999-99999 | BLANK                | 0    |       |     | ORDER BY REF.No.006 | 0            | 0           |
| 008    | 15221-03370 | CAP,SEALING          | 12   |       |     |                     | 0.01         | 0.022       |
| 009    | 15221-03490 | CAP,SEALING          | 1    |       |     |                     | 0.02         | 0.044       |
| 010    | 15261-96010 | PLUG                 | 2    |       |     |                     | 0.002        | 0.0044      |
| 011    | 15221-13580 | GUIDE,VALVE          | 4    |       |     |                     | 0            | 0           |
| 012    | 15601-13560 | GUIDE,EXHAUST VALVE  | 4    |       |     |                     | 0            | 0           |
| 013    | 19202-03450 | BOLT,CYLINDER HEAD   | 16   |       |     |                     | 0.065        | 0.143       |
| 014    | 19202-03410 | STUD,CYLINDER HEAD   | 2    |       |     |                     | 0.065        | 0.143       |
| 015    | 19202-03510 | NUT,CYLINDER HEAD    | 2    |       |     |                     | 0.012        | 0.0264      |
| 016    | 15421-03310 | GASKET,CYLINDER HEAD | 1    |       |     |                     | 0            | 0           |
| 017    | 15421-03320 | SHIM,CYLINDER HEAD G | 1    |       |     |                     | 0.07         | 0.154       |
| 018    | 33400-75250 | SWITCH,THERMOMETER   | 1    |       |     |                     | 0.033        | 0.0726      |

## GEAR CASE






## GEAR CASE

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

| REF.No | Part No.    | Description          | Q'ty | S.No. | I/C | REMARKS             | Weight (kgf) | Weight (lb) |
|--------|-------------|----------------------|------|-------|-----|---------------------|--------------|-------------|
| 001    | 15521-04020 | ASSY CASE,GEAR       | 1    |       |     |                     | 0            | 0           |
| 002    | 99999-99999 | BLANK                | 0    |       |     | ORDER BY REF.No.001 | 0            | 0           |
| 003    | 15521-33630 | PLUG,PIN             | 2    |       |     |                     | 0.003        | 0.0066      |
| 004    | 04811-00150 | O RING               | 3    |       |     |                     | 0.001        | 0.0022      |
| 005    | 04811-00360 | O RING               | 1    |       |     |                     | 0.002        | 0.0044      |
| 006    | 15221-56280 | PIN,START SPRING     | 1    |       |     |                     | 0.006        | 0.0132      |
| 007    | 05012-00612 | PIN,STRAIGHT         | 2    |       |     |                     | 0.003        | 0.0066      |
| 008    | 15521-04130 | GASKET,GEAR CASE     | 1    |       |     |                     | 0            | 0           |
| 009    | 01123-50860 | BOLT                 | 2    |       |     |                     | 0.026        | 0.0572      |
| 010    | 01153-50870 | BOLT                 | 5    |       |     |                     | 0.026        | 0.0572      |
| 011    | 01153-50880 | BOLT                 | 3    |       |     |                     | 0.03         | 0.066       |
| 012    | 15521-91020 | BOLT                 | 3    |       |     |                     | 0.035        | 0.077       |
| 013    | 01153-50895 | BOLT                 | 2    |       |     |                     | 0.035        | 0.077       |
| 014    | 04512-50080 | WASHER,SPRING        | 13   |       |     |                     | 0.001        | 0.0022      |
| 015    | 04012-50080 | WASHER,PLAIN         | 1    |       |     |                     | 0.001        | 0.0022      |
| 016    | 15521-32290 | JOINT,PIPE           | 1    |       |     |                     | 0.05         | 0.11        |
| 017    | 04011-50180 | WASHER,PLAIN         | 1    |       |     |                     | 0.012        | 0.0264      |
| 018    | 15241-36950 | SPRING               | 1    |       |     |                     | 0.004        | 0.0088      |
| 019    | 15521-36930 | SEAT,VALVE           | 1    |       |     |                     | 0.015        | 0.033       |
| 020    | 07715-03213 | BALL                 | 1    |       |     |                     | 0.004        | 0.0088      |
| 021    | 15521-73320 | FLANGE,WATER RETURN  | 1    |       |     |                     | 0.04         | 0.088       |
| 022    | 15521-73330 | GASKET,WATER RETURN  | 1    |       |     |                     | 0            | 0           |
| 023    | 01023-50620 | BOLT                 | 3    |       |     |                     | 0.006        | 0.0132      |
| 024    | 15521-32430 | CARTRIDGE,OIL FILTER | 1    |       |     |                     | 0            | 0           |
| 025    | 15221-88130 | GASKET,HOUR METER    | 1    |       |     |                     | 0            | 0           |
| 026    | 15221-88210 | STUD                 | 4    |       |     |                     | 0.005        | 0.011       |
| 027    | 02056-50060 | NUT                  | 4    |       |     |                     | 0.002        | 0.0044      |
| 028    | 04512-50060 | WASHER,SPRING        | 4    |       |     |                     | 0            | 0           |
| 029    | 38240-34660 | ASSY GEAR CASE,HOUR  | 1    |       |     |                     | 0.335        | 0.737       |

## MAIN BEARING CASE






# MAIN BEARING CASE

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

| REF.No | Part No.    | Description          | Q'ty | S.No. | I/C | REMARKS             | Weight (kgf) | Weight (lb) |
|--------|-------------|----------------------|------|-------|-----|---------------------|--------------|-------------|
| 001    | 19202-04040 | ASSY CASE,MAIN BEARI | 1    |       |     |                     | 1.28         | 2.816       |
| 002    | 99999-99999 | BLANK                | 0    |       |     | ORDER BY REF.No.001 | 0            | 0           |
| 003    | 99999-99999 | BLANK                | 0    |       |     | ORDER BY REF.No.001 | 0            | 0           |
| 004    | 15521-04540 | BOLT,BEARING CASE 1  | 8    |       |     |                     | 0            | 0           |
| 005    | 15521-94010 | WASHER,PLAIN         | 8    |       |     |                     | 0.001        | 0.0022      |
| 006    | 15221-04360 | GASKET,BEARING       | 1    |       |     |                     | 0            | 0           |
| 007    | 19202-04810 | COVER,BEARING        | 1    |       |     |                     | 0.36         | 0.792       |
| 008    | 15221-04820 | GASKET,COVER         | 1    |       |     |                     | 0            | 0           |
| 009    | 01123-50825 | BOLT                 | 8    |       |     |                     | 0.013        | 0.0286      |
| 010    | 01123-50828 | BOLT                 | 8    |       |     |                     | 0.014        | 0.0308      |
| 011    | 19202-04460 | SEAL,OIL             | 1    |       |     |                     | 0.055        | 0.121       |
| 012    | 15521-04050 | ASSY CASE,MAIN BEARI | 1    |       |     |                     | 0            | 0           |
| 013    | 99999-99999 | BLANK                | 0    |       |     | ORDER BY REF.No.012 | 0            | 0           |
| 014    | 99999-99999 | BLANK                | 0    |       |     | ORDER BY REF.No.012 | 0            | 0           |
| 015    | 15521-04060 | ASSY CASE,MAIN BEARI | 1    |       |     |                     | 0            | 0           |
| 016    | 99999-99999 | BLANK                | 0    |       |     | ORDER BY REF.No.015 | 0            | 0           |
| 017    | 99999-99999 | BLANK                | 0    |       |     | ORDER BY REF.No.015 | 0            | 0           |
| 018    | 15411-04070 | ASSY CASE,MAIN BEARI | 1    |       |     |                     | 1.25         | 2.75        |
| 019    | 99999-99999 | BLANK                | 0    |       |     | ORDER BY REF.No.018 | 0            | 0           |
| 020    | 99999-99999 | BLANK                | 0    |       |     | ORDER BY REF.No.018 | 0            | 0           |
| 021    | 15291-04560 | BOLT 2               | 3    |       |     |                     | 0.06         | 0.132       |
| 022    | 15521-94020 | WASHER,PLAIN         | 3    |       |     |                     | 0.004        | 0.0088      |

## AIR CLEANER





## AIR CLEANER


↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

| REF.No | Part No.    | Description          | Q'ty | S.No. | I/C | REMARKS | Weight (kgf) | Weight (lb) |
|--------|-------------|----------------------|------|-------|-----|---------|--------------|-------------|
| 001    | 15401-11010 | ASSY CLEANER,AIR     | 1    |       |     |         | 2.9          | 6.38        |
| 002    | 15401-11150 | BODY,AIR CLEANER     | 1    |       |     |         | 1.15         | 2.53        |
| 003    | 15401-11160 | COVER,AIR CLEANER    | 1    |       |     |         | 0.38         | 0.836       |
| 004    | 15401-11410 | COVER,BAFFLE         | 1    |       |     |         | 0.05         | 0.11        |
| 005    | 15401-92620 | NUT,WING             | 1    |       |     |         | 0.01         | 0.022       |
| 006    | 15401-11070 | ASSY BAND,AIR CLEANE | 1    |       |     |         | 0.115        | 0.253       |
| 007    | 15401-11080 | ASSY ELEMENT,AIR CLE | 1    |       |     |         | 0.74         | 1.628       |
| 008    | 15222-87480 | LABEL                | 1    |       |     |         | 0.001        | 0.0022      |
| 009    | 15401-11090 | ASSY INDICATER       | 1    |       |     |         | 0.021        | 0.0462      |
| 010    | 15401-87750 | MARK,FORM            | 1    |       |     |         | 0.001        | 0.0022      |
| 011    | 15401-87450 | LABEL,AIR CLEANER    | 1    |       |     |         | 0.002        | 0.0044      |
| 012    | 15401-94430 | WASHER,SEAL          | 1    |       |     |         | 0.009        | 0.0198      |
| 013    | 15401-11720 | BAND,PIPE            | 2    |       |     |         | 0.05         | 0.11        |
| 014    | 15401-11700 | ASSY HOLDER,INLET PI | 1    |       |     |         | 0.08         | 0.176       |
| 015    | 03004-50812 | BOLT                 | 1    |       |     |         | 0.008        | 0.0176      |
| 016    | 15401-11620 | PIPE,INLET           | 1    |       |     |         | 0.84         | 1.848       |
| 017    | 15461-11760 | MANIFOLD,INLET       | 1    |       |     |         | 1.155        | 2.541       |
| 018    | 15471-11823 | GASKET,IN-MANIFOLD   | 1    |       |     |         | 0            | 0           |
| 019    | 01123-50822 | BOLT                 | 7    |       |     |         | 0.012        | 0.0264      |



## EXHAUST MANIFOLD

---



Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)