






KEY	PART NO.	PART NAME	QTY	REMARKS	
1	FGV41772145	PLUG	4		
2	FGV10012198	CRANKCASE	1		
3	FGV21770061	PLUG	4		
4	FGV21712068	PLUG	1		
5	FGV21842037	PIN	1		
6	FGV11382010	VALVE	1		
7	FGV41772059	PLUG	5		
8	FGV20302060	BUSHING	2		
9	FGV21770088	PLUG	2		
10	FGV21770088	PLUG	2		
11	FGV10302010	BUSHING	1		
12	FGV21712076	BUSHING	1		
13	FGV21762127	SCREW	2		
14	FGV46320514	VALVE	3		
15	FGV41901313	O-RING	4		




PY53464

KEY	PART NO.	PART NAME	QTY	REMARKS	
1	FGV21282731	DIPSTICK	1		
2	FGV46320006	O-RING	1		
3	FGV21282731	TUBE	1		
4	FGV31302026	WASHER	1		
5	FGV46320509	O-RING	1		
6	FGV11612012	CLAMP	1		




PY53439

KEY	PART NO.	PART NAME	QTY	REMARKS	
1	FGV10132087	COVER	1		
2	FGV41840108	PIN	2		
3	FGV41901203	SCREW	14		
4	FGV46340871	SEAL	1		
5	FGV21772104	PLUG	1		
6	FGV22032134	GASKET	1		




PY53435

KEY	PART NO.	PART NAME	QTY	REMARKS	
1	FGV22032300	GASKET	1		
2	FGV41762034	SCREW	9		
3	FGV11772003	FILLER CAP	1		
4	FGV41772080	PLUG	3		
5	FGV21332012	ELBOW FITTING	1		
6	FGV21772084	PLUG	1		
7	FGV20132389	COVER	1		
8	FGV22032176	GASKET	1		




PY53444

KEY	PART NO.	PART NAME	QTY	REMARKS	
1	FGV21320036	UNION FITTING	1		
2	FGV21282583	PIPE	1		
3	FGV41901102	SCREW	1		
4	FGV21612062	CLAMP	1		
5	FGV22030455	GASKET	1		




PY53433

KEY	PART NO.	PART NAME	QTY	REMARKS	
1	FGV40432003	TAPPET	8		
2	FGV20422014	ROD	8		
3	FGV20512670	BRACKET	4		
4	FGV22022289	ENGINE CYLINDER HEAD GASKET	1	1.41 MM, SUB FOR FGV22022182	
4	FGV22022290	ENGINE CYLINDER HEAD GASKET	1	1.51MM, SUB FOR FGV22022183	
4	FGV22022184	ENGINE CYLINDER HEAD GASKET	1	1.61 MM	
5	FGV10352067	CYLINDER HEAD	4	ASSEMBLY	
6	FGV10412019	ROCKER ARM	8		




PY54161

KEY	PART NO.	PART NAME	QTY	REMARKS	
1	FGV20442010	VALVE SEAT	4	+ 0.30 MM	
2	FGV20362006	INTAKE VALVE	4		
3	FGV20372006	EXHAUST VALVE	4		
4	FGV20442009	VALVE SEAT	4	+ 0.30 MM	
5	FGV21772061	PLUG	8		
6	FGV21782180	UNION FITTING	1		
7	FGV42020020	WASHER	5		
8	FGV45962031	TRANSMITTER	1		
9	FGV41770041	PLUG	1		
10	FGV41750888	STUD	8		
11	FGV41750354	STUD	4		
12	FGV20462069	SPRING	4		
13	FGV21792037	NUT	8		
14	FGV20400007	RETAINER	16		
15	FGV20390016	PLATE	8		
16	FGV20460099	SPRING	6		
17	FGV20390018	PLATE	8		
18	FGV46340866	SEAL	8		
19	FGV20382004	GUIDE	8	+ 0.00 MM	
19	FGV20382005	GUIDE	8	+ 0.10 MM	
20	FGV41750869	STUD	8		
21	FGV41750904	STUD	8		
22	FGV46072002	GLOW PLUG	4		
23	FGV28852013	CABLE	3		
24	FGV41880304	NUT	4		




PY53438

KEY	PART NO.	PART NAME	QTY	REMARKS	
1	FGV21650035	PLATE	1		
2	FGV20662149	GEAR	1		
3	FGV41901312	SCREW	2		
4	FGV20202117	PIN	1		
5	FGV10662016	GEAR	1		
6	FGV41830061	KEY	1		
7	FGV46241408	LOCK WASHER	2		
8	FGV41760231	SCREW	2		
9	FGV10182048	CAMSHAFT	1		



PY53431

KEY	PART NO.	PART NAME	QTY	REMARKS	
1	FGV42020020	WASHER	1		
2	FGV41770041	PLUG	1		
3	FGV21770088	PLUG	1		
4	FGV21782112	UNION FITTING	1		
5	FGV46060008	PRESSURE SWITCH	1		
6	FGV21320038	BOLT	1		
7	FGV21320036	UNION FITTING	1		
8	FGV21320039	BOLT	1		
9	FGV42020014	WASHER	4		
10	FGV20550011	LIFT ARM	1		
11	FGV41760327	SCREW	1		
12	FGV46240410	WASHER	1		
13	FGV46320230	O-RING	1		
14	FGV21762056	SCREW	6		
15	FGV41901407	SCREW	10		



PY53458

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com