





CYLINDER BLOCK



KEY	PART NO.	PART NAME	QTY	REMARKS	
1		CYLINDER BLOCK	1	NSEP (Marked R522413)	
2	34M7247	SPRING PIN	2	11 X 16 mm	
3	RE71255	PIPE PLUG	27	1/8"-27NPT, (Sub For RE42713 OR R104592)	
4	R48685	DOWEL PIN	2		
5	R504965	PLUG	1		
6	15H685	PIPE PLUG	1	1/4"	
7	R116466	PLUG	7		
8	R502725	PLUG	1	(Dipstick Tube)	
9	R515003	SCREW	12	M10 X 100	
10	R505135	ORIFICE	5		
11	T18891	PLUG	1	OD = 16MM	
12	RE518215	BALL BEARING	1		
13	R523409	SPUR GEAR	1		
14	R522976	WHEEL	1		
15	R515112	SHIM	1		
16	R516770	WASHER	1		
17	L157372	SCREW	2	M6 X 16	
18	R517240	SCREW	1		
19	19M7923	CAP SCREW	4	M6 X 12	
20		CAMSHAFT	1	(Marked R528331)	
21	R504808	BUSHING	5		



RE528949PCDA01


CRANKSHAFT / BEARINGS

KEY	PART NO.	PART NAME	QTY	REMARKS	
1	RE520626	BEARING KIT	5	STD	
2	RE520627	BEARING KIT	2		
3	R48685	DOWEL PIN	1		
4	RE527591	CRANKSHAFT	1		
4	SE502111	CRANKSHAFT REMAN	1	(With Bearings) (Reman For RE527591)	



CONNECTING RODS AND PISTONS

KEY	PART NO.	PART NAME	QTY	REMARKS	
1	R515084	PISTON RING	5	STD	
2	40M1855	SNAP RING	10		
3	R503480	PISTON PIN	5	OD = 30MM	
4		PISTON	5	STD (MARKED RE527622)	
5	R502503	SCREW	2	M10 X 49	
6	RE544411	CONNECTING ROD	5	(SUB FOR RE504544)	
6	RE504544	CONNECTING ROD	1	(SUB RE544411)	
6	SE501898	CONNECTING ROD REMAN	1	(REMAN FOR RE504544)	
7	RE520937	BEARING KIT	10	STD; SUB FORR522089	



Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.
You can download the most
perfect and complete manual in
the world immediately.

Our support email:
ebooklibonline@outlook.com