






KEY	PART NO.	PART NAME	QTY	REMARKS	
1		CASE	1	MIA882493 NLA	
4	M809565	DRAIN PLUG	1		
5	15H562	PIPE PLUG	1	1", SUB FOR CH18379	
6	M801189	BOLT	10		
9	MIU800573	BUSHING	1		
10	30M7023	PLUG	8	SUB FOR CH10642	
11	CH10314	PLUG	1		
12	CH10335	PLUG	2		
13	CH10335	PLUG	1		
14	M87801	PLUG	1		
24	MIA880555	BEARING	2		
27	M801186	BOLT	18		
28	MIU802736	GASKET	1		
29	MIA880554	BEARING	5	Spare	
32	MIA880550	BEARING	5	Spare, 0.25	




TX1128216

KEY	PART NO.	PART NAME	QTY	REMARKS	
1		GEAR CASE	1	MIU802098 NLA	
2	M802255	PIN	2		
3	M805710	CAP	1		
4	M800974	PIPE	2		
5	M810185	O-RING	2		
6	M809204	O-RING	1		
7	M805711	PACKING	1		
8	19M7865	SCREW	3	M8 X 16, SUB FOR CH18390	
9	MIU802743	SENSOR	1	Speed Sensor Cover	
10	19M7774	SCREW	2	M6 X 12, SUB FOR M87819	
11	MIA881991	COVER	1		
13	M811078	SEAL	1		
14	CH18096	COVER	1		
15	M806424	WASHER	1		
16	19M7865	SCREW	4	M8 X 16, SUB FOR CH18390	
17	CH19090	BOLT	1	SUB FORM87884	
18	19M8317	SCREW	7	M8 X 40, SUB FOR M89128	
19	19M7801	SCREW	3	M8 X 60, SUB FOR CH19097	
20	CH19136	BOLT	4		



KEY	PART NO.	PART NAME	QTY	REMARKS	
1	M802255	PIN	2		
2	MIU802741	HOUSING	1		
3	M88659	PLUG	1		
4	19M7402	CAP SCREW	6	M10 X 25, SUB FOR M800077	
5	19M7662	CAP SCREW	4	M10 X 30, SUB FOR M801201	
6	M801207	INTERMEDIATE HOUSING	1		
7	AM878611	RESERVOIR	1		
8	M806544	DRAIN PLUG	1		
10	M806545	WASHER	1		
11	19M7865	SCREW	4	M8 X 16, SUB FOR CH18390	
12	CH19085	BOLT	2		
13	CH19101	BOLT	20		
14	CH19086	BOLT	4		
15	M802255	PIN	2		
16	MIA881006	CASE	1		
18	MIU800955	SEAL	1		
19	M808308	BOLT	6		
20	CH19090	BOLT	3	SUB FOR M87884	
21	MIU802138	SENSOR	1	Flywheel	
22	19M8553	SCREW	1	M6 X 16, SUB FOR M800695	



Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com