



TP66838

KEY	PART NO.	PART NAME	QTY	REMARKS
0	5004208	FRAME	1	(SUB FOR TH5004208)(CONVENIENCE ASSEMBLY)
1	5004209	FRAME	1	(SUB FOR TH5004209)(CONVENIENCE ASSEMBLY)
2	5004210	FRAME	1	(SUB FOR TH5004210)(CONVENIENCE ASSEMBLY)
4	4218943	BOLT	36	(SUB FOR TH4218943)
5	4218944	SPACER	36	(SUB FOR TH4218944)
6	4242099	BOLT	8	(SUB FOR TH4242099)
7	4242098	SPACER	8	(SUB FOR TH4242098)
9	J833008	BOLT	8	(SUB FOR THM923003 OR M923003)
10	4218945	SPACER	8	(SUB FOR TH4218945)
11	4207766	LOCK PLATE	4	(SUB FOR AT131846)
12	4174859P	WASHER	16	(SUB FOR TH103498 OR 4174859)
14	J833002	BOLT	8	(SUB FOR THM923011 OR M923011)
15	4243157	SPACER	8	(SUB FOR TH4243157)
16	4333844	GUIDE	4	(SUB FOR TH4333844)
19	J833013	BOLT	40	(SUB FOR THJ833013)
20	4244172	GASKET	1	(SUB FOR AT202301)
21	4013896	COVER	1	(SUB FOR TH100633)
23	19M7938	CAP SCREW	2	M10 X 20
24	12M7066	LOCK WASHER	2	10 mm
26	19M7394	CAP SCREW	1	M16 X 25, (SUB FOR AT202272 AND J901625)
27	24M7053	WASHER	1	17 X 30 X 3 mm
42	425175	PLUG	4	(SUB FOR AT132013)




TP66846

KEY	PART NO.	PART NAME	QTY	REMARKS	
0	8068378	STEP	4	(SUB FOR TH8068378)	
1	8068391	STEP	4	(SUB FOR TH8068391)	
37	19M7409	CAP SCREW	32	M16 X 50	
39	4114405	WASHER	32	17 X 32 X 4.500 mm (0.669" X 1.260" X 0.177"), (SUB FOR TH101105)	
40	12H294	LOCK WASHER	32	5/8"	



TP66841

KEY	PART NO.	PART NAME	QTY	REMARKS	
0	7037194	GUARD	4	(SUB FOR 7027836)	
1	J932701	BOLT	16	(SUB FOR THJ932701)	
2	4277804	SPACER	16	(SUB FOR TH4277804)	
3	J912735	BOLT	20	(SUB FOR THJ912735)	
4	12H318	LOCK WASHER	20	1-1/8"	



TP66843

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com