






KEY	PART NO.	PART NAME	QTY	5303	5403	5503	REMARKS	
1	R56463	O-RING	1	X	X	X	SUB FOR AT18904	
2	R92154	ELBOW FITTING	1	X	X	X		
3	TY22467	CLAMP	1	X	X	X		
4	R516895	HOSE	1	X	X	X		




PY50072

KEY	PART NO.	PART NAME	QTY	5303	5403	5503	REMARKS	
1	RE32140	SCREW WITH WASHER	6	X	X	X		
2	RE515827	VALVE COVER	1	X	X	X		
3	R106796	O-RING	1	X	X	X		





PY50838

KEY	PART NO.	PART NAME	QTY	5303	5403	5503	REMARKS	
1	R54565	PLUG	2	X	X	X		
2	R501532	SHAFT	1	X	X	X		
3	T20316	WASHER	2	X	X	X		
4	T20314	SPRING	2	X	X	X		
5	R504813	SELF-LOCKING SCREW	3	X	X	X	HS= 10.9, SAE 8	
6	R123161	SUPPORT	3	X	X	X	SUB FOR R516741	
7	RE62148	ROCKER ARM	6	X	X	X		
8	R515095	PUSH ROD	6	X	X	X		
9	R515092	CAM FOLLOWER	6	X	X	X		
10	R515577	SCREW	3	X	X	X		
11	R125881	LOCK NUT	3	X	X	X		




KEY	PART NO.	PART NAME	QTY	5303	5403	5503	REMARKS	
1	R85363	CAP SCREW	14	X	X	X	SUB FOR R516516	
2	RE65214	CYLINDER HEAD	1	X	X	X	SUB FOR RE507618	
3	CD16284	PLUG	2	X	X	X		
4	R515090	ENGINE CYLINDER HEAD GASKET	1	X	X	X	SUB FOR R515273	



CD37204

KEY	PART NO.	PART NAME	QTY	5303	5403	5503	REMARKS	
1	R91889	RETAINER	12	X	X	X	OD = 11.7 mm, 0.461"	
2	RE60005	ROTATOR	6	X	X	X		
3	R26125	SPRING	6	X	X	X	SUB FOR R504261	
4	RE31617	SEAL	6	X	X	X	SUB FOR RE515329	
5	R515212	VALVE SEAT INSERT	3	X	X	X	OD = 47.22 mm, 1.859"	
6	R98062	INTAKE VALVE	3	X	X	X	SUB FOR R515093	
7	R515213	VALVE SEAT INSERT	3	X	X	X	OD = 43.1 mm, 1.697"	
8	R90692	EXHAUST VALVE	3	X	X	X	SUB FOR R515094	



CDA39115

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com