






KEY	PART NO.	PART NAME	QTY	Tractor Serial No.	REMARKS	
1	ER0504345342	HOUSING	1			
2	ER0504250345	ROCKSHAFT	1	____-104982		
2	ER5801572079	ROCKSHAFT	1	104983-____		
3	ER0016987801	PLUG	2			
4	ER0099454296	SCREW	1			
5	ER0504221915	ROCKER ARM	1	____-104982	(Intake)	
5	ER5801572084	ROCKER ARM	4	104983-____	(Intake)	
6	ER0504221914	ROCKER ARM	4	____-104982	(Exhaust)	
6	ER5801572085	ROCKER ARM	1	104983-____	(Exhaust)	
7	ER0017281681	O-RING	1			
8	ER0004699783	SCREW	8			
9	ER0004338920	NUT	8			
10	ER0016988401	PLUG	1			
11	ER0016586925	CAP SCREW	10		M8 X 50	
12	ER0016673835	BOLT	11		M8 X 30	
13	ER0504163121	GASKET	1			
14	ER0504177226	GASKET	1			
15	ER0504273002	PLUG	4		M12 X 1.5 mm	




PY040246

KEY	PART NO.	PART NAME	QTY	REMARKS	
1	ER0504221916	COVER	3		
2	ER0504349057	COVER	1		
3	ER0504372247	BREATHER	1		
4	ER0504173590	ENGINE CYLINDER HEAD GASKET	4		
5	ER0016586625	BOLT	8	M8 X 35	





PY040342

KEY	PART NO.	PART NAME	QTY	REMARKS	
1	ER0504187090	PULLEY	1		
2	ER0016675835	BOLT	6	M10 X 30 mm	
3	ER0504253015	V-BELT	1		




PY040749


KEY	PART NO.	PART NAME	QTY	REMARKS	
1	ER0504180348	FLYWHEEL	1		
2	ER0016678034	BOLT	6	M8 X 1.25 X 25	
3	ER0016673735	BOLT	2	M12 X 40	
4	ER0002992544	ADHESIVE	1		
5	ER0504265766	CONNECTING ROD	1		
6	ER0504351177	SCREW	2	M8 X 1.25	




KEY	PART NO.	PART NAME	QTY	REMARKS	
1	ER201677	HOSE GUARD	1		
2	ER136575	CLAMP	1		
3	ER202960	DOWEL PIN	2		
4	ER372511	FLYWHEEL	1		
5	ER383846	HOSE	1		
6	ER021143	BOLT	6	M12 X 50	
7	ER021148	BOLT	2	M12 X 60	
8	ER021155	BOLT	2	M12 X 80	
9	ER021157	BOLT	2	M12 X 90	
10	ER022861	WASHER	12		
11	ER024502	DOWEL PIN	1		
12	ER026017	BEARING	1		
13	ER393149	BOLT	8	M8 X 12	




KEY	PART NO.	PART NAME	QTY	REMARKS	
1	ER020781	BOLT	2	M8 X 25	
2	ER405140	BRACKET	1		
3	ER020778	SCREW	1	M8 X 20	
4	ER023109	WASHER	5		
5	ER389183	HEAT SHIELD	1		
6	ER020775	BOLT	2	M8 X 12	
7	ER021419	SCREW	1	M12 X 20	
8	ER023113	WASHER	1		




KEY	PART NO.	PART NAME	QTY	REMARKS	
1	ER0504385659	FUEL INJECTION PUMP	1		
2	ER0504240405	GEAR	1		
3	ER0504315405	STUD	1		
4	ER0504083433	GASKET	3		
5	ER0500368408	NUT	3	M8	
6	ER0017095401	WASHER	1		
7	ER0016980331	NUT	1	M14	
8	ER0093160151	SENSOR	1		
9	ER0042533181	SOLENOID	1	12V	



KEY	PART NO.	PART NAME	QTY	REMARKS	
1	ER0504380241	FUEL PUMP	1		
2	ER0002830156	O-RING	1		
3	ER0504218933	HOLLOW SCREW	1		
4	ER0504218931	FUEL SUPPLY BANJO FITTING	1		
5	ER0017750480	GASKET	2		
6	ER0504197289	UNION FITTING	1		
7	ER0004894721	WASHER	1		
8	ER0016586925	BOLT	1	M8 X 50 mm	



KEY	PART NO.	PART NAME	QTY	REMARKS	
1	ER0504275234	INJECTION NOZZLE	4		
2	ER0008097589	NOZZLE	4		
3	ER0504174745	BRACKET	4		
4	ER0504315404	STUD	4		
5	ER0500353601	WASHER	4		
6	ER0017044735	NUT	4	M8	
7	ER0004899689	WASHER	4		
8	ER0001118641	WASHER	8		
9	ER0093190600	SCREW	4		
10	ER0017278281	O-RING	4		



PY040197

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com