






010 COMPLETE ENGINE

Pos.	Part No.	Description	Dimension	Quantity	Conditions
1	00 1151 400 0	ENGINE		1	1)
1	00 1151 401 0	ENGINE		1	2)
1	00 1151 402 0	ENGINE		1	3)
1	00 1151 403 0	ENGINE		1	4)
1)	Equipment				
	Remarks	NE_P02_0510	75 hp max. output, 75 hp type-approved rated output, ECE R 120 F5C 75Ch		
2)	Equipment				
	Remarks	NE_P02_0520	85 hp max. output, 83 hp type-approved rated output, ECE R 120 F5C 84Ch		
3)	Equipment				
	Remarks	NE_P02_0530	92 hp max. output, 91 hp type-approved rated output, ECE R 120 F5C 92Ch		
4)	Equipment				
	Remarks	NE_P02_0540	103 hp max. output, 98 hp type-approved rated output, ECE R 120 F5C 103Ch		




100 CRANKCASE

Pos.	Part No.	Description	Dimension	Quantity	Conditions
1	00 1151 412 0	CASING		1	




100 CRANKCASE

Pos.	Part No.	Description	Dimension	Quantity	Conditions
1	00 1139 576 0	BUSHING		14	
2	00 1139 577 0	PLUG		3	
3	00 1151 413 0	PLUG		4	
4	60 0502 536 5	PLUG		5	
5	00 1151 414 0	PLUG		1	
6	00 1151 415 0	NOZZLE		4	
7	60 0503 098 5	SCREW		10	
8	00 1139 579 0	PLUG		1	
9	60 0503 098 1	BUSHING		1	
10	00 1139 580 0	PLUG		1	
11	00 1139 581 0	SEALING RING		1	
12	00 1151 416 0	UNION CONNECTOR		1	




120 TIMING CASE

Pos.	Part No.	Description	Dimension	Quantity	Conditions
1	00 1151 421 0	COVER		1	
2	00 1151 428 0	SEALING RING		1	
3	00 1151 427 0	PLUG		1	
4	00 1151 426 0	STUD		3	
5	00 1151 422 0	CASING		1	
6	00 1139 396 0	PLUG		1	
7	00 1151 430 0	PLUG		1	
8	00 1151 429 0	PLUG		1	
9	00 1151 425 0	SCREW	M8X25-B=18	3	
10	00 1140 887 0	SCREW		1	
11	00 1151 423 0	FLAT SEAL		1	
12	00 1139 401 0	SCREW	M08X35	15	
13	00 1139 409 0	SCREW		4	
14	00 1151 424 0	STUD		3	
15	00 1144 777 0	SCREW	M8X45	7	




140 FLYWHEEL HOUSING

Pos.	Part No.	Description	Dimension	Quantity	Conditions
1	00 1139 505 0	HOUSING		1	
2	00 1139 409 0	SCREW		2	
3	00 1139 526 0	SCREW		6	
4	00 1151 664 0	SCREW		2	
5	00 1139 511 0	PLUG		1	




160 OIL PAN

Pos.	Part No.	Description	Dimension	Quantity	Conditions
1	00 1139 524 0	HOUSING		1	
2	00 1139 550 0	SCREW		2	
3	60 0503 101 0	SCREW PLUG		1	
4	60 0503 101 1	O-RING		1	
5	00 1139 527 0	SCREW		8	
6	00 1139 551 0	SCREW		4	
7	00 1139 562 0	SCREW		8	
8	00 1139 564 0	FLAT GASKET		1	
9	00 1139 566 0	SCREW PLUG		1	
10	00 1139 567 0	TUBE		1	
11	00 1139 305 0	LEVEL TRANSMITTER		1	
12	00 1138 789 0	SCREW PLUG		1	
13	00 1151 669 0	GASKET		1	




100 CYLINDER LINER, PISTON

Pos.	Part No.	Description	Dimension	Quantity	Conditions
1	00 1151 691 0	PLUNGER		4	
2	00 1139 605 0	INT RETAINING RING		8	
3	00 1139 606 0	AXLE		4	
4	00 1151 692 0	ENGINE PISTON RING		4	




120 CONNECTING ROD, CONNECTING ROD BEARINGS

Pos.	Part No.	Description	Dimension	Quantity	Conditions
1	00 1151 693 0	ROD (ENGINE)		4	
2	00 1139 609 0	SCREW		8	
3	00 1151 694 0	BEARING BUSH	STD	4	
4	00 1151 696 0	BEARING BUSH	-0.254MM	4	
5	00 1151 697 0	BEARING	-0.508MM	4	



140 CRANKSHAFT

Pos.	Part No.	Description	Dimension	Quantity	Conditions
1	00 1151 699 0	CRANKSHAFT	90X112X10.60	1	
2	00 1151 700 0	WHEEL		1	
3	00 1139 668 0	SCREW		3	
4	00 1139 669 0	CENTRING PIN		1	
5	00 1151 535 0	SEALING RING		1	
6	00 1151 701 0	BEARING BUSH		1	
6	00 1151 702 0	BEARING BUSH		1	1)
6	00 1151 703 0	BEARING BUSH		1	2)
7	00 1139 308 0	BEARING		1	
1)	Remarks				-0,254
2)	Remarks				-0,508



160 CRANKSHAFT PULLEY WHEEL

Pos.	Part No.	Description	Dimension	Quantity	Conditions
1	00 1151 741 0	PULLEY		1	
2	00 1139 678 0	SCREW	M10X30	6	

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com