





9822/0955 E390-30-1 OTHER VALVES RETURN LINE,MANIFOLD,ASSEMBLY




332-X7684-1

Item	Part #	Change No	Description	Usage Code	QTY
1	332/X4992		Manifold return		1

2	332/X2754		Adaptor SAE ORB -6/LPXDT		1
3	332/X2481		Adaptor ORFS M-12 SAE		2
4	1754/0808		Orifice Adaptor		2
5	1420/0007Z		Washer (M8)		2
6	1315/3315Z		Bolt Star Drive M8 x 65mm		2
7	816/90632		Plug		1

JCB 9822/0955 E390-35-1 OTHER VALVES FAN
REVERSING,ASSEMBLY,GL




333-X5453-2

Item	Part #	Change No	Description	Usage Code	QTY
1	332/X9325		Valve Fan, Reversing		1

2	1751/0808		Adaptor ORFS M /SAE		2
3	1754/0808		Orifice Adaptor		1
4	1317/3316Z		Bolt M8 x 70 flange reduced hex		2
5	333/X5893		Adaptor WEO F-08/SAE ORB		1



9822/0955 E390-40-1 OTHER VALVES REVERSING FAN




332-X9325-1

Item	Part #	Change No	Description	Usage Code	QTY
1	335/D3782		Valve Spool		1
2	335/D3783		Coil		1
3	335/D3785		Valve Relief		1

4	335/D3786		Coil		1
5	335/D3787		Valve Relief		1



9822/0955 E415-5-1 RAMS SHOVEL (CLAM/SIDE TIP) ASSEMBLY




332-L6021-1

Item	Part #	Change No	Description	Usage Code	QTY
A	332/L6021		Cylinder Hydraulic Assembly		1

1	332/L5991		Nipple Grease		2
2	332/L6189		Nut Hexagonal Torque to 150-200 ft.lbs		1
3	332/L6190		Piston		1
4	332/L6191		Tube Cylinder		1
5	332/L6192		Gland Cylinder		1
6	332/L6193		Rod Cylinder		1
7	332/L6194		Bushing Self Aligning		2
8	332/L6195		Seal Kit		1



9822/0955 E420-10-1 RAMS LOADER CROWD/TILT TILT
RAM BLACK, 4.0 INCH X 2.0 INCH



335-F5192-1


Item	Part #	Change No	Description	Usage Code	QTY
A	333/X5184		Cylinder Tilt		1

1	:336/A0549		Kit Seal		1
2	:336/A0550		Retainer Retainer Sub Assembly		1
3	:336/A0551		Piston Sub Assembly		1
4	:336/A0552		Rod Assembly		1
5	:336/A0553		Shell Assembly		1
6	:336/A0554		Head Bushing Head		1
7	:336/A0555		Seal Dust		1
8	:334/P2771		Bush Rod		1
9	:334/P2717		Seal Dust		1



50.8

9822/0955 E425-1-1 RAMS LOADER LIFT BLACK,88.9 X




335-F5210-1

Item	Part #	Change No	Description	Usage Code	QTY
1	333/X5186		Cylinder Boom Lift		1

2	:336/A0544		Kit Seal		1
3	:336/A0545		Retainer Sub-Assembly		1
4	:336/A0546		Piston Sub Assembly		1
5	:336/A0547		Rod Piston		1
6	:336/A0548		Shell Assembly		1
7	:334/P2772		Bush Cylinder		1
8	:334/P2771		Bush Rod		1
9	:334/P2717		Seal Dust		1



9822/0955 E520-1-1 FILTER OTHER HYDRAULIC CHARGE ASSEMBLY, GL




333-X0738-2

Item	Part #	Change No	Description	Usage Code	QTY
1	333/X0740		Filter Charge 5 Micron		1

2	1751/0808		Adaptor ORFS M /SAE		1
3	1754/0808		Orifice Adaptor		1
4	1317/3305Z		Bolt Flanged M8 x 20 lg		4

9822/0955 F0-10-1 TRANSMISSION INSTALLATION ASSEMBLIES DRIVE ASSEMBLY,WHEELED, LP



Item	Part #	Change No	Description	Usage Code	QTY
1	****		Hub Assembly Front		2

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com