




9802/9800 B1-1-1 CHASSIS SIDESHIFT 2WS 7'4"

REARFRAME



393330


Item	Part #	Change No	Description	Usage Code	QTY
1	335/03198	<M938429	Chassis 7'4" sideshift gear pump		1

1	335/05207	<Dec 2003	Chassis 2 WS, 7'4" rearframe		1
1	335/06515	>Jan 2004	Chassis 2ws,7'4"sideshift Tier 2		1
1A	:809/00102		Bearing Liner <i>Loader arm pivot & level link pivot.</i>		4
1B	:809/00093		Bearing Liner <i>Lift ram pivot.</i>		2
2	:125/00198		Frame 7'4" sideshift rear		1
2A	::125/00195		Housing right hand stabiliser		1
2B	::125/00194		Housing left hand stabiliser		1
2C	::125/00196		Crossrail 7'4" sideshift		1
2D	:123/06409		Housing wear pad		2
4	:829/01215		Boss <i>Front</i>		1
5	:331/18852		Pad yoke axle pivot		1
6	826/01712		Bolt 1"unf X 9" long <i>Axle mount</i>		4
6	826/01665		Bolt 1"unf X 10 1/2"long <i>3CX Contractor use with items 10 & 11</i>		4
7	823/00578		Washer (ID=1")		4
8	826/01714		Nut (1" UNF)		4
9	835/10026		Plug plastic		17
10	123/06350		Spacer rear axle 25mm		2
11	331/17737		Spacer rear axle 20mm <i>Use with item 10 when fitting 20" dia tyres</i>		2



9802/9800 B1-1-5 CHASSIS SIDESHIFT 2WS 7'8"

REARFRAME




393330

Item	Part #	Change No	Description	Usage Code	QTY
1	335/03199	<M938429	Chassis 7'8" sideshifts gear pump		1

1	335/05208	<Dec 2003	Chassis 7'8" sideshift,2 WS	1
1	335/06516	>Jan 2004	Chassis 2ws,7'8"sideshift Tier 2	1
1A	:809/00102		Bearing Liner <i>Loader arm pivot & level link pivot.</i>	4
1B	:809/00093		Bearing Liner <i>Lift ram pivot.</i>	2
2	:125/00199		Frame 7'8.5 sideshift rear	1
2A	::125/00195		Housing right hand stabiliser	1
2B	::125/00194		Housing left hand stabiliser	1
2C	::125/00197		Crossrail 7'8.5 sideshift	1
4	::829/01215		Boss <i>Front</i>	1
5	:331/18852		Pad yoke axle pivot	1
6	826/01712		Bolt 1"unf X 9" long <i>Axle mount</i>	4
6	826/01665		Bolt 1"unf X 10 1/2"long <i>3CX Contractor use with items 10 & 11</i>	4
7	823/00578		Washer (ID=1")	4
8	826/01714		Nut (1" UNF)	4
9	835/10026		Plug plastic	17
10	123/06350		Spacer rear axle 25mm	2
11	331/17737		Spacer rear axle 20mm <i>Use with item 10 when fitting 20" dia tyres</i>	1



9802/9800 B1-2-1 TANK, HYDRAULIC




392450

Item	Part #	Change No	Description	Usage Code	QTY
1	128/11533	Superseded	Tank hydraulic as supplied		1
1	128/12649	<M939716	Tank hydraulic,assembly toolbox compatible		1

1	128/13686		Tank hydraulic assembly toolbox compatible	1
1	128/12770	<M939716	Tank hydraulic assembly step compatible	1
1	128/13687	<Dec 2003	Tank hydraulic step compatible	1
1	128/14330		Tank hydraulic step compatible	1
2	****		'See Remark' <i>Hyd filter see E3-7-1</i>	1
3	:32/925390		Plug Drain G1A	1
3A	::2401/0510		O Ring	1
4	:32/920300		Element Filter 125 micron	1
4A	:32/920301		O Ring	1
5	:125/00579		Cover tank inspection	1
6	:123/06717		Cover plate	1
7	:813/00466		Gasket	1
8	:1315/0307Z		Setscrew M8 X 25	16
9	:1420/0007Z		Washer (M8)	16
10	:826/10381		Rivet nut M8 closed	16
11	:32/925334	Superseded	Cap hydraulic filler breather	1
11	32/925421		Cap filler/breather Lockable	1
11A	::123/04056		Seal cap	1
11B	701/45501		Key Door/Ignition <i>not supplied with cap</i>	1
12	:123/08053		Gauge Sight 50mm	1
13	::25/700013		O Ring	1
14	1315/0510Z		Bolt M12x40	4
15	826/01717		Nut rivet M12	4
16	823/00589		Washer (13mm x 40mm x 5mm)	4
17	123/09018		Gasket hydraulic tank	1



9802/9800 B1-3-1 TANK, DIESEL FUEL 150 LITRES




392440

Item	Part #	Change No	Description	Usage Code	QTY
1	128/11126		Tank diesel fuel 150 ltr standard		1
1	128/12595		Tank diesel fuel 150 ltr power tool circuit		1

2	:123/08086		Plug drain		1
3	:1406/0026		Washer Seal		1
4	:331/26782		Cap diesel filler lockable <i>For key see ignition switch.</i>		1
4A	:904/20230		Seal fuel cap		1
5	1315/0510Z		Bolt M12x40		4
6	826/01717		Nut rivet M12		4
7	823/00589		Washer (13mm x 40mm x 5mm)		4
8	331/13063		Plate clamp		1



9802/9800 B1-3-2 TANK, DIESEL FUEL 150 LITRES




Item	Part #	Change No	Description	Usage Code	QTY
1	128/13690		Tank diesel fuel 150 ltr standard		1
1	128/13691		Tank diesel fuel,150 ltr power tool circuit		1

2	:32/925390		Plug Drain G1A		1
3	::2401/0510		O Ring		1
4	:331/33064	Superseded	Cap filler, diesel lockable <i>For key use 701/45501</i>		1
4	:331/45908		Cap filler, diesel lockable <i>For key use 701/45501</i>		1
4A	:904/20230	Superseded	Seal fuel cap		1
4A	:904/20333		Seal fuel cap		1
5	1315/0510Z		Bolt M12x40		4
6	826/01717		Nut rivet M12		4
7	823/00589		Washer (13mm x 40mm x 5mm)		4
8	:826/00520		Screw		6
9	:716/30146		Sensor fuel level AR,AK engine builds		1
10	:103/77101		Gasket Fuel Level Sensor		1
11	:331/13063		Plate clamp		1



9802/9800 B1-3-3 TANK, DIESEL FUEL 150 LITRES TIER 2




719750

Item	Part #	Change No	Description	Usage Code	QTY
1	128/14088		Tank diesel fuel 150 ltr standard		1
1	128/14493	>M948647	Tank diesel fuel 150 ltr standard		1

1	128/14089		Tank diesel fuel 150 ltr power tool circuit		1
1	128/14502	>May 2004	Tank diesel fuel 150 ltr power tool circuit		1
2	:32/925390		Plug Drain G1A		1
3	::2401/0510		O Ring		1
4	:331/33064	Superseded	Cap filler, diesel lockable <i>For key use 701/45501</i>		1
4	:331/45908		Cap filler, diesel lockable <i>For key use 701/45501</i>		1
4A	:904/20230	Superseded	Seal fuel cap		1
4A	:904/20333		Seal fuel cap		1
5	1315/0510Z		Bolt M12x40		4
6	826/01717		Nut rivet M12		4
7	823/00589		Washer (13mm x 40mm x 5mm)		4
8	:826/00520		Screw		6
9	:716/30202		Sensor fuel level		1
10	:103/77101		Gasket Fuel Level Sensor		1
11	:331/13063		Plate clamp		1



9802/9800 B1-3-4 TANK, DIESEL FUEL 150 LITRES TIER 2




719751

Item	Part #	Change No	Description	Usage Code	QTY
1	128/15223		Tank diesel fuel 150 ltr standard		1
1	128/15224		Tank diesel tank 150 ltr power tool circuit		1

2	:32/925390		Plug Drain G1A		1
3	::2401/0510		O Ring		1
4	:331/45908		Cap filler, diesel lockable <i>For key use 701/45501</i>		1
4A	:904/20333		Seal fuel cap		1
5	1315/0510Z		Bolt M12x40		4
6	826/01717		Nut rivet M12		4
7	823/00589		Washer (13mm x 40mm x 5mm)		4
8	:1315/0105Z		Setscrew M5 x 20		6
8A	:826/11361		Rivet nut M5		6
9	:716/30202		Sensor fuel level		1
10	:103/77101		Gasket Fuel Level Sensor		1
11	:331/13063		Plate clamp		1



9802/9800 B1-4-1 STABILISER SIDESHIFT




266132

Item	Part #	Change No	Description	Usage Code	QTY
1	125/00193	<M952167	Leg inner sideshift		1
1	335/08022		Leg inner sideshift		2

2	811/50530	Superseded	Pin Pivot		2
2	811/90590		Pin pivot		2
3	1315/3420Z		Bolt (M10 X 100)		2
4	1370/0303Z		Nut lock M10		2
5	123/06022		Foot sideshift stabiliser		2
6	123/06012		Spacer		2
7	811/70108	Superseded	Pin pivot		2
7	811/90587		Pin pivot		2
8	128/10850		Pad assembly wear stabiliser leg		4
9	123/07295		Pad wear,5mm upper colour green		8
9	123/07296		Pad wear,6mm upper colour red		8
9	123/07297		Pad wear,7mm upper colour blue		8
10	2203/0060		Circlip 45mm		4
11	556/60078		Ram sideshift stabiliser 40mm rod x 70mm cyl		2
12	123/06023		Cap Sideshift Stabiliser		2
13	123/06014		Pad wear, lower 6mm thick, colour black		4



9802/9800 B1-5-1 BONNET 2WS




Item	Part #	Change No	Description	Usage Code	QTY
1	331/26667	<M932938	Bonnet 2ws as supplied		1
1	331/30548		Bonnet 2ws as supplied		1

1A	128/13684	>May 2003	Bonnet soundproofed,2ws as supplied <i>Used with nat.asp/aircon build</i>		1
1B	:331/34961		Panel soundproofing,bonnet		1
1C	:826/10539		Fastener Bighead		4
2	331/26669	<M932938	Cover loader tower		1
2	331/30546	<M944729	Cover loader tower		1
2	331/40569	Superseded	Cover loader tower		1
2	346/00168		Cover loader tower		1
2	331/29450	<M932938	Cover loader tower with pre cleaner		1
2	331/30921	<M944854	Cover loader tower with pre cleaner		1
2	331/40571	Superseded	Cover loader tower with pre-cleaner		1
2	346/00169		Cover loader tower pre-cleaner		1
3	335/03677	<M930653	Mounting latch		1
3	335/03973		Mounting latch		1
4	1315/3423Z	<M930653	Bolt M10 x 130		2
4	1315/0307Z		Setscrew M8 X 25		2
5	1370/0303Z	<M930653	Nut lock M10		2
5	1370/0203Z		Nut Nut M8		2
6	1420/0008Z	<M930653	Washer (M10)		4
6	1420/0007Z		Washer (M8)		4
7	910/60104		Cable bonnet release		1
8	331/27126		Latch Bonnet		1
9	826/01814		Screw Countersunk M8x35		2
10	1370/0203Z		Nut Nut M8		2
11	1420/0007Z		Washer (M8)		2
12	331/28666		Mounting bump stop		1
13	1315/0207Z	<M932938	Screw M6x25		2
13	1315/0307Z		Setscrew M8 X 25		1
14	1370/0103Z	<M932938	Nut Self Lock M6		2
14	1370/0203Z		Nut Nut M8		2
15	1420/0006Z	<M932938	Washer (M6)		4
15	1420/0007Z		Washer (M8)		4
16	123/07243		Buffer		1
17	1370/0202Z		Nut Thin (M8)		2
18	826/10892		Hinge bonnet		1
19	1315/0305Z		Setscrew M8 x 20		4
20	1315/3313Z		Bolt M8 x 55		2
21	1420/0007Z		Washer (M8)		12
22	1370/0203Z		Nut Nut M8		6
22	826/10826		Nut Nyloc M8 <i>bonnet hinge stud</i>		1
23	823/00185		Washer large		2
24	128/11779	Superseded	Strut door stay		2
24	128/13052		Strut gas assembly		2
25	331/26981		Catch bonnet		1
26	1315/0303Z		Setscrew M8 x 16		2
27	1420/0007Z		Washer (M8)		2
28	331/31173		Spacer 100x15x8		2
29	826/10979		Screw button head		4
30	1370/0203Z		Nut Nut M8		4
31	1420/0007Z		Washer (M8)		8



9802/9800 B1-5-2 BONNET,2WS TIER 2



706221

Item	Part #	Change No	Description	Usage Code	QTY
1	331/37341		Bonnet 2WS,as supplied Tier 2		1
1A	128/14115		Bonnet 2ws,soundprfd,Tier 2 as supplied		1

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com