




Item	Part #	Change No	Description	Usage Code	QTY
A	990/71300		Differential assembly		1
B	:990/98300		Kit-gear differential		1
1	:990/71301		Housing		1
2	::N.S.P.		None serviced part		2
3	::808/00180		Washer		2
4	::N.S.P.		None serviced part		2
6	::808/00181		Washer		2
7	::451/08103		Pin		1
8	:451/08105		Pin lock		1
9	451/02000		Gear crownwheel/pinion 35T/8T		1
10	907/05500		Bearing		1
11	921/00601		Shim 0.15		0
11	921/00602		Shim 0.20		1
11	921/00603		Shim 0.25		0
11	921/00604		Shim 0.50		0
11	921/00605		Shim 1.00		0
14	826/00439		Dowel		2
15	823/00194		Washer tab		6
16	1315/0508		Bolt M12 x 30mm		12
16A	826/00921		Bolt <i>use when bolt is not drilled for dowel</i>		12
17	907/07400		Bearing		1



9802/2220 F1-6-1 AXLE PIVOT REAR




249890

Item	Part #	Change No	Description	Usage Code	QTY
9	260/39502		Clamp pivot 412		1
9	260/39501		Clamp pivot		1

			415		
10	1305/3634Z		Bolt 412		2
10	826/00826		Stud 415		2
11	823/00352	Superseded	Washer		2
11	823/00603		Washer hardened M16		2
12	1340/0603Z		Nut lock 415 (Item not illustrated)		2
20	811/60001		Pin pivot		1
21	1305/0610		Bolt		2
22	120/16902		Plate Rebound		2
23	823/00365		Washer special		2
23A	2401/0030		O Ring		2
24	813/00248		Seal V		2
25	819/00033		Shim		0
26	1410/0007		Washer		0




9802/2220 F1-7-1 PROPSHAFTS TRANSMISSION



Item	Part #	Change No	Description	Usage Code	QTY
1	914/32600		Shaft propeller front <i>412/415</i>		1
1	:914/32603		Joint universal, double with centring device		1
2	914/23002		Kit-spider		1
2A	914/31701		Kit-spider cap D=42mm		2
3	1340/0403		Nut		8
4	826/00737		Stud		4
4	1315/0511		Setscrew (M12 x 45) <i>Metric use with item 14</i>		4
5	1315/0511		Setscrew (M12 x 45)		4
6	914/34000		Propshaft <i>412/415 Standard</i>		1
7	914/30901		Kit-spider cap D=35mm x 125		2
8	1340/0403		Nut		8
9	1305/0410		Bolt		8
10	914/34200		Propshaft <i>412/415 Disconnect</i>		1
10A	:914/47901		Yoke flange		2
11	914/30901		Kit-spider cap D=35mm x 125		2
12	1340/0403		Nut		8
13	1305/0410		Bolt		8
14	1370/0401		Nut <i>Metric use with item 4</i>		8




9802/2220 F1-8-1 WHEELS & TYRES



Item	Part #	Change No	Description	Usage Code	QTY
1	259/25400		Wheel & tyre assembly Michelin XRA <i>415</i>		4
1	259/33200		Wheel & tyre assembly Michelin XRDNA <i>415</i>		1
1	190/29100		Wheel & tyre assembly Goodyear <i>412/415</i>		1
1	259/24700		Wheel & tyre assembly 15.5 x 25 - 12 ply <i>415</i>		1
1	259/47900		Wheel & tyre assembly Goodyear <i>415</i>		1
1	259/50700		Wheel & tyre assembly Firestone <i>415</i>		1
2	42/102100		Tyre 15.5-25 1 star Michelin XRA <i>415</i>		1
2	42/102800		Tyre L3 15.5-25 1star XRDNA <i>415</i>		1
2	42/404000		Tyre Goodyear Sure Grip 15.5/80-24x10pr <i>412/415</i>		1
2	42/405700		Tyre 15.5 x 25 x 12 PLY L2T/ LESS <i>415</i>		1
2	42/303600		Tyre 15.5-25x12 ply Firestone <i>415</i>		1
2	42/303300		Tyre 15.5x25 12pr Firestone <i>415</i>		1
3	41/903200		Wheel 12 x 25 8 stud <i>415</i>		1
3	41/906300		Wheel centre W14Lx24 <i>412/415 use with 15.5-80-24 only</i>		1
4	151/05201		Valve Tyre		1
5	832/00035		Tube inner <i>412/415</i>		1



9802/2220 F1-9-1 AXLE BREATHER, FRONT OPTIONAL




101800

Item	Part #	Change No	Description	Usage Code	QTY
1	816/00094		Adapter		1
2	4101/0602		Fluid locking		0
3	816/00464		Adapter elbow - male/female		1
4	649/08800	Superseded	Hose breather		1
4	631/11100		Hose		1
5	259/42900		Bracket		1
6	450/00101		Cap breather metal, 5mm hole		1
7	1305/0206Z		Setscrew (3/8" UNF x1")		1
8	1340/0203Z		Nut Lock 3/8" UNF		1
9	926/08300		Strip Edging <i>160mm</i>		0



9802/2220 F2-1-1 TRANSMISSION & CONVERTER HOUSING GROUP



084341


Item	Part #	Change No	Description	Usage Code	QTY
1	04/104300		Transmission 6 speed, disconnect		1
1A	801979		Kit gasket converter		1
1B	801981		Kit gasket transmission		1
2	****		'See Remark' <i>See Index F Converter housing</i>		1
3	:5C/620		Bolt with washer		4

4	:234908		Ring location		1
5	:234327		Bracket bearing		2
6	:223878		Ring retaining		1
7	:710047		Bearing		1
8	:234908		Ring location		1
9	:237276		Gear drive auxiliary pump		1
10	****		'See Remark' <i>See Index F Charging pump</i>		1
11	:234908		Ring location		1
12	:223878		Ring retaining		2
13	:236583		Gear idler pump drive		1
14	:710047		Bearing		2
15	:223878		Ring retaining		2
16	:234908		Ring location		2
17	:234248		Shaft stub		1
17A	:10J/08		Ball lock		1
18	:240598		Shaft turbine		1
18A	:240617		Ring retaining		1
19	:239742		Bearing		1
20	:234230		Washer location		1
21	:231776		Ring retaining		1
22	:223085		Ring piston		1
23	:234229		Ring snap		1
24	:1C/616		Screw		6
24A	:4E/06		Washer		6
25	:241038	Superseded	Bracket stator		1
25	:246842		Stator support		1
26	:237378		Spring expanding		1
27	:237377		Ring piston		1
28	:235593	Superseded	Seal oil		1
28	:4204710		Seal		1
29	:234362		Baffle assembly oil		1
30	:231624		Bearing		1
31	:236582		Gear		1
32	:234973		O Ring		1
33	:235217		Impellor 11.6		1
34	:234210		Washer tab lock		4
35	:18C/612		Bolt		8
36	:234226		Spacer		1
37	:239774		Converter reaction member 11.2		1
38	:1300688		Ring retaining		1
38A	:664141		Ring retaining		1
39	:239775		Turbine complete 11.2		1
40	:239627		Hub turbine		1
41	:215909		Washer		4
42	:209313		Bolt		12
43	:215909		Washer		6
44	:234216		Ring location		1
45	:234215		Bearing		1
46	:235591		Washer retaining		1
47	:234237		O Ring		1

48	****		None serviced part <i>Use 239576 & 1321234</i>		1
49	:1300688		Ring retaining		1
50	:60K/30114		O Ring		1
51	:223015		Plug		1
52	:1321234	Superseded	Ring retaining		1
52	:246354		Ring retaining		1
54	:235333		Plate drive		3
55	:234286		Ring backing		1
56	:5C/612		Bolt with washer		10
57	:5C/516		Bolt assembly		24
58	:240487		Drive freewheel assembly		1
59	:237555		Ring snap		1
60	:816/60100		Adapter T		1
61	:04/800297		Switch transmission pressure		1
62	:45/902100		Coupling Quick release male		1
63	:1406/0011		Washer Bonded (1/4")		1



9802/2220 F2-2-1 TORQUE CONVERTER HOUSING



084350

Item	Part #	Change No	Description	Usage Code	QTY
1	243556		Housing converter assy <i>Including items 13-17</i>		1
2	4E/05		Washer		1
3	1C/510		Bolt		1
4	237441		Tube lower		1
5	60K/30016		O Ring		1
6	237515		Clip		1
7	219373		Gasket		1
8	231390		Strainer		1
9	234265		Sleeve		1
10	239244		Plug		1
11	11F/08		Plug		1
12	239244		Plug		1
13	1C/720		Bolt		16
14	4E/07		Washer		16
15	11F/08		Plug		1
16	239245		Plug		1
17	238535		Breather air		1
18	****		'See Remark' <i>See Index F2 Control valve</i>		1



9802/2220 F2-3-1 TRANSMISSION HOUSING & REAR COVER GROUP

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com