




9812/3300 B120-5-1 FUEL TANK FUEL FILLER




335-C3722-2

Item	Part #	Change No	Description	Usage Code	QTY
1	335/C3062		Filler neck		1
2	2201/0016		Clip Worm Drive 91-114mm		2
3	332/G0879		Cap Vented Diesel Filler		1

4	1315/0411D		Setscrew M10X45		2
7	335/C7187		Hose fuel filler		1
8	335/G9394		Seal plate LH		1
9	335/G9569		Strip edge 170mm		1

JCB 9812/3300 B130-1-1 HYDRAULIC TANK FITTINGS & MOUNTINGS




335-F4477-1

Item	Part #	Change No	Description	Usage Code	QTY
1	269/10052		Cover Access Assembly		1

2	813/00434		Gasket Access Cover		1
3	274/01052		Cap Hydraulic		1
4	32/925390		Plug Drain G1A		1
5	581/18071		Filter Assembly Hydraulic		1
6	332/P3040		Breather		1
7	1315/0407D		Setscrew M10 x 25		4
8	1406/0008		Seal Washer		4
9	32/901100		Strainer Suction		2
10	1315/3520D		Bolt M12x100 dacromet		2
11	1420/0009D		Washer (M12)		2
12	123/08053		Gauge Sight 50mm		1
13	333/U7228		Sender temperature c/w O Ring (9/16"-18UNF)		1
13	333/S7007		Sender temperature <i>Replaces 333/U7228</i>		1
14	1315/0208D		Setscrew (M6 X 30)		10
15	1420/0006D		Washer (M6)		10



9812/3300 B150-1-1 FENDERS STANDARD ASSEMBLIES




335-F6328-2

Item	Part #	Change No	Description	Usage Code	QTY
1	****		Assembly front fender LH		1
2	****		Assembly front fender LH		1
3	****		Assembly mid fender LH		1

4	****		Assembly mid fender RH		1
5	****		Assembly fender edge trim		1
6	****		Assembly rear fender		1
7	335/H3180		Mudflap Front Upper		2
8	****		Assembly front mudflap LH		1
9	****		Assembly retention chain		1
10	****		Assembly rear mudflap LH		1
11	****		Assembly rear mudflap RH		1
12	****		Assembly rear extension mudflap LH		1
13	****		Mudflap Assembly, Rear RH		1
14	333/J4829		Label no step		2
15	****		Assembly - Front Mudflap		1



9812/3300 B150-2-1 FENDERS STANDARD WIDE,
ASSEMBLIES




Item	Part #	Change No	Description	Usage Code	QTY
1	****		Assembly front fender LH		1

2	****		Assembly front fender LH	1
3	****		Assembly mid fender LH	1
4	****		Assembly mid fender RH	1
5	****		Assembly standard wide fender edge trim	1
6	335/H3254		Mudflap upper front	2
7	****		Assembly front wide mudflap LH	1
8	****		Assembly retention chain	1
9	****		Assembly wide mid mudflap LH	1
10	****		Assembly wide mid mudflap RH	1
11	****		Assembly bonnet hole fixings	1
12	335/G0609		Fender front (Wide option)	2
13	335/G0588		Fender middle (Wide option)	2
14	1412/0002D		Washer (5/16" Large)	48
15	1370/0202D		Nut Thin	24
16	1315/0308D		Setscrew M8 x 30 mm	24
17	****		Assembly front mudflap RH	1



9812/3300 B150-3-1 FENDERS STANDARD ASSEMBLIES




334-R5785-3

Item	Part #	Change No	Description	Usage Code	QTY
1	****		Assembly front fender LH		1
2	****		Assembly front fender LH		1
3	****		Assembly mid fender LH		1

4	****		Assembly mid fender RH		1
5	****		Assembly fender edge trim		1
6	335/H3180		Mudflap Front Upper		2
7	****		Assembly front mudflap LH		1
8	****		Assembly retention chain		1
9	****		Assembly rear mudflap LH		1
10	****		Assembly rear mudflap RH		1
11	****		Assembly bonnet hole fixings		1
12	****		Assembly - Front Mudflap		1



9812/3300 B150-4-1 FENDERS FULL WIDE, ASSEMBLIES




335-G0738-1

Item	Part #	Change No	Description	Usage Code	QTY
1	****		Assembly front fender LH		1
2	****		Assembly front fender LH		1
3	****		Assembly mid fender LH		1

4	****		Assembly mid fender RH	1
5	****		Assembly full wide fender	1
6	****		Assembly rear fender	1
7	335/H3254		Mudflap upper front	2
8	****		Assembly front wide mudflap LH	1
9	****		Assembly retention chain	1
10	****		Assembly wide mid mudflap LH	1
11	****		Assembly wide mid mudflap RH	1
12	****		Assembly rear wide mudflap	2
13	335/G0609		Fender front (Wide option)	2
14	335/G0588		Fender middle (Wide option)	2
15	335/G0942		Fender extension WA	2
16	1370/0202D		Nut Thin	35
17	1412/0002D		Washer (5/16" Large)	70
18	1315/0308D		Setscrew M8 x 30 mm	35
19	****		Assembly front mudflap RH	1
20	333/J4829		Label no step	2



9812/3300 B150-5-1 FENDERS ASSEMBLIES STANDARD WITH CHEVRON




334-U5230-2

Item	Part #	Change No	Description	Usage Code	QTY
1	****		Assembly front fender LH		1

2	****		Assembly front fender LH		1
3	****		Assembly mid fender LH		1
4	****		Assembly mid fender RH		1
6	****		Assembly rear fender		1
7	335/H3180		Mudflap Front Upper		2
8	****		Assembly front mudflap LH		1
9	****		Assembly retention chain		1
10	****		Assembly rear mudflap LH		1
11	****		Assembly rear mudflap RH		1
12	****		Assembly rear extension mudflap LH		1
13	****		Assembly fender trim extension with chevron		1
14	****		Assembly - Front Mudflap		1
15	333/J4829		Label no step		2
16	****		Mudflap Assembly, Rear RH		1



9812/3300 B150-6-1 FENDERS ASSEMBLIES FULL WIDE WITH CHEVRON



335-G2264-2

Item	Part #	Change No	Description	Usage Code	QTY
1	****		Assembly front fender LH		1

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com