




9802/9770 P1-2-2 ENGINE, SHORT AK BUILD




Item	Part #	Change No	Description	Usage Code	QTY
1	02/201860		Engine short turbo		1
2	****		'See Remark' <i>See frame P1-3-2, Block assembly</i>		1
3	****		'See Remark' <i>See frame P1-4-2, Crankshaft assembly</i>		1
4	****		'See Remark' <i>See frame P1-4-2, Con-rod assembly</i>		4
5	****		'See Remark' <i>See frame P1-4-2, Piston assembly</i>		4
6	****		'See Remark' <i>See frame P1-4-2, Piston ring kit</i>		4
7	****		'See Remark' <i>See frame P5-2-2, Oil pump</i>		1



9802/9770 P1-2-5 ENGINE, LONG AK BUILD 100 BHP 72

AMP



342071


Item	Part #	Change No	Description	Usage Code	QTY
			Engine engine short		

1	02/202537		<i>For use with 72 amp alternator only</i>		1
2	****		'See Remark' <i>See frame P1-3-4, Block assembly</i>		1
3	****		'See Remark' <i>See frame P1-4-2, Crankshaft assembly</i>		1
4	****		'See Remark' <i>See frame P1-4-2, Con-rod assembly</i>		4
5	****		'See Remark' <i>See frame P1-4-2, Piston assembly</i>		4
6	****		'See Remark' <i>See frame P1-4-2, Piston ring kit</i>		4
7	****		'See Remark' <i>See frame P2-1-3, Cylinder Head</i>		1
8	****		'See Remark' <i>See frame P1-6-2, Timing Case</i>		1
9	****		'See Remark' <i>See frame P5-2-2, Oil Pump</i>		1
10	****		'See Remark' <i>See frame P5-2-2, Oil relief valve</i>		1
11	****		'See Remark' <i>See frame P8-1-2, Gasket set top</i>		1
12	****		'See Remark' <i>See frame P8-2-1, Gasket set bottom</i>		1



9802/9770 P1-2-6 ENGINE, LONG AK BUILD 100 BHP 85

AMP




342071

Item	Part #	Change No	Description	Usage Code	QTY
			Engine short		

1	02/202536		<i>For use with 85 amp alternator only</i>		1
2	****		'See Remark' <i>See frame P1-3-4, Block assembly</i>		1
3	****		'See Remark' <i>See frame P1-4-2, Crankshaft assembly</i>		1
4	****		'See Remark' <i>See frame P1-4-2, Con-rod assembly</i>		4
5	****		'See Remark' <i>See frame P1-4-2, Piston assembly</i>		4
6	****		'See Remark' <i>See frame P1-4-2, Piston ring kit</i>		4
7	****		'See Remark' <i>See frame P2-1-3, Cylinder Head</i>		1
8	****		'See Remark' <i>See frame P1-6-2, Timing Case</i>		1
9	****		'See Remark' <i>See frame P5-2-2, Oil Pump</i>		1
10	****		'See Remark' <i>See frame P5-2-2, Oil relief valve</i>		1
11	****		'See Remark' <i>See frame P8-1-2, Gasket set top</i>		1
12	****		'See Remark' <i>See frame P8-2-1, Gasket set bottom</i>		1



9802/9770 P1-3-2 BLOCK ASSEMBLY AK BUILD




Item	Part #	Change No	Description	Usage Code	QTY
1	02/201660		Block cylinder assembly		1
2	:02/201706		Dowel		2
3	:02/201141		Liner press-fit <i>See Note 1</i>		4
3	02/201142		Liner slip-fit		0
3	02/202226		Liner cylinder oversize - 0.010"		0
4	:02/100134		Plug		2
5	:02/100396		Plug core D=32mm		6
6	:02/201304		Plug		1
7	:02/200003		Plug core" D=26mm		1
8	:02/100132		Plug drain		2
9	:02/100101		Thimble		10
10	:02/100102		Bolt		10
11	:02/192094		Bush camshaft		1
12	:02/200454		Plug core D=38mm		6
13	:02/201361		Plug core D=38mm		3
14	:02/101827		Plug		1
15	:02/200454		Plug core D=38mm		2
16	:02/100108		Plug		1
17	:02/101756		Plug		4
18	:823/00287		Washer spacer		4
19	:02/201362		Plug core D=50mm		1
20	:02/200827		Plug		1
21	:02/200828		Washer		1
22	:02/201734		Jet piston cooling		1
23	:02/201731		Pin roll		1
24	::02/101898		Valve		1
25	::02/200099		Ball		1
26	::02/200098		Spring		1
27	::02/200097		Retainer		1
28	:02/200826		Plate		1
29	:02/200484		Gasket		1
30	:02/291042		Bolt		4
31	:02/200958		Housing rear seal		1
32	:02/101436		Seal rear oil		1
33	02/201092		Gasket rear seal housing		1
34	826/00869		Screw flange head		12
35	02/291185		Capscrew		2
36	02/100308		Dowel		2
37	02/200004		Plate		1
38	02/200475		Gasket		1
39	02/291031		Bolt		2
40	701/41500		Switch oil pressure		1
41	1315/0402Z		Setscrew		1
42	823/00273		Washer		1
43	02/100134		Plug		1

Note 1: SPECIAL TOOLS FOR FITTING, BORING AND HONING REQUIRED, FOR GENERAL SERVICE USE SLIP-FIT




9802/9770 P1-3-4 BLOCK ASSEMBLY AK BUILD



Item	Part #	Change No	Description	Usage Code	QTY
1	02/201660		Block cylinder assembly		1
2	****		None serviced part		1

			<i>Block & Bearing Caps</i>	
3	:02/201141		Liner press-fit	4
3	02/201142		Liner slip-fit	0
4	:02/100134		Plug	2
5	:02/100396		Plug core D=32mm	6
6	:02/201304		Plug	1
7	:02/200003		Plug core" D=26mm	1
8	:02/100134		Plug	1
9	:02/100101		Thimble	10
10	:02/100102		Bolt	10
11	:02/192094		Bush camshaft	1
12	:02/200454		Plug core D=38mm	4
13	:02/201361		Plug core D=38mm	3
14	:02/101827		Plug	1
15	:02/200454		Plug core D=38mm	2
16	:02/100108		Plug	1
17	:02/101756		Plug	4
18	:823/00287		Washer spacer	4
19	:02/201362		Plug core D=50mm	1
20	:02/200827		Plug	1
21	:02/200828		Washer	1
22	:02/201734		Jet piston cooling	1
23	:02/201731		Pin roll	1
24	::02/101898		Valve	1
25	::02/200099		Ball	1
26	::02/200098		Spring	1
27	::02/200097		Retainer	1
28	:02/200826		Plate	1
29	:02/200484		Gasket	1
30	:02/291042		Bolt	4
31	:02/202370		Housing & rear oil seal assembly	1
32	:826/10721		Bolt torx head drive	10
33	02/100308		Dowel	2
34	02/202422		Sleeve speedy	1
35	02/202369		Piece bridge	1
36	02/100132		Plug drain	1
37	02/200004		Plate	1
38	02/200475		Gasket	1
39	02/291031		Bolt	2
40	701/41500		Switch oil pressure	1
41	1315/0402Z		Setscrew	1
42	823/00273		Washer	1

JCB 9802/9770 P1-4-2 CRANKSHAFT, BEARINGS PISTONS & CON-RODS AK BUILD



Item	Part #	Change No	Description	Usage Code	QTY
1	02/200915		Crankshaft assembly		1

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com