




9822/0930 E540-1-1 FILTER RETURN HAMMER CIRCUIT




333-J9896-1

Item	Part #	Change No	Description	Usage Code	QTY
1	****		Filter		1
2	****		Filter element		1
3	:334/D2780		O Ring 3.53 x 91.67mm		1



9822/0930 F430-1-1 SLEW/SWING MOTOR INSTALLATION TURNTABLE BEARING, SPACED BOLTS




334-J0334-1

Item	Part #	Change No	Description	Usage Code	QTY
2	1316/3825D		Bolt M20 x 150mm		31

3	1316/3815D		Bolt M20 X 65		36
4	JHP0044		Washer		67
5	4101/0500		Fluid Locking Loctite 262		0
6	KRB0681		Plate Cover		1
7	KRB0682		Packing Cork		1
8	1316/0507D		Setscrew M12 x 25 grade 10.9		3
9	1420/0009D		Washer (M12)		3
10	JHC0001		Sealant liquid packing, Gasket		0
11	****		Circuit grease line, assembly		1
12	333/K9983		Spacer		31



9822/0930 F430-5-1 SLEW/SWING MOTOR INSTALLATION GEARBOX COMPONENTS, 333/K0684




333-K0684-KIT-1

Item	Part #	Change No	Description	Usage Code	QTY
A	333/K0684		Motor Track, Assembly		1

1	:334/D1837	Cover Cover Reduction	1
2	:334/D1838	Kit Seal Kit	1
3	:334/D1840	Kit Screw Kit	1
4	:334/D1842	Reducer REDUCTION ASSEMBLY	1
5	:334/D1843	Gear Planetary Assembly	1
6	:332/H3933	Housing & bearing	1
7	:332/H3935	Motor hydraulic	1



9822/0930 F430-10-1 SLEW/SWING MOTOR INSTALLATION TURNTABLE BEARING (J903)




9G0RB333-5

Item	Part #	Change No	Description	Usage Code	QTY
1	JRB0017		Ring slew		1

2	332/P6830		Bolt High Strength M20 x105mm		31
3	1316/3815D		Bolt M20 X 65		36
4	JHP0044		Washer		67
5	4101/0500		Fluid Locking Loctite 262		0
6	KRB0681		Plate Cover		1
7	KRB0682		Packing Cork		1
8	1316/0507D		Setscrew M12 x 25 grade 10.9		3
9	1420/0009D		Washer (M12)		3
10	JHC0001		Sealant liquid packing, Gasket		0
11	****		Circuit grease line, assembly		1



9822/0930 F430-15-1 SLEW/SWING MOTOR INSTALLATION TRACK




Item	Part #	Change No	Description	Usage Code	QTY
A	332/H3935		Motor hydraulic		1

1	****		None serviced part		1
1-1	:25/222665		Valve relief		2
2	:332/H5576		Kit-valve assembly		1
3	:332/H5577		Kit-plunger		1
4	:332/H5579		Kit orifice		1
5	:332/H5580		Kit-plug assembly		1
6	:332/H5578		Kit-plug & o ring		1
7	****		None serviced part		1
8	:332/H5581		Kit-plug & o ring		1
9	:20/925674		Shaft motor drive		1
10	:332/H5585		Seal ring		1
11	:20/951604		Bearing Bearing Kit Track Motor/Gearbox		1
12	:332/H5586		Kit-repair brake assembly		1
13	:332/H5587		Kit-seal		1
14	****		None serviced part		1
15	:05/903833		Screw		10



9822/0930 F440-1-1 GEARBOX SLEW/SWING SWING EQUIPMENT




332-K9465-5

Item	Part #	Change No	Description	Usage Code	QTY
1	333/K3452		Gearbox Swing		1

2	333/K7185		Motor Swing		1
2A	:334/D3787		Seal oil		1
3	1316/3817D		Bolt		11
5	KRC0105		Pin headed		1
6	C4E9301		Adapter Plug		1
7	JBC0004		Pipe assembly		1
8	JHP0044		Washer		11
10	4101/0500		Fluid Locking Loctite 262		0



9822/0930 F440-5-1 GEARBOX SLEW/SWING ASSEMBLY



333-K3452-KIT-1

Item	Part #	Change No	Description	Usage Code	QTY
A	333/K3452		Gearbox Swing		1
1	:333/Y3141		Shaft Out put, Assembly		1
2	:334/D1858		Kit Seal Kit		1

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com