




9822/0930 E390-45-1 OTHER VALVES LOW FLOW




333-K3176-1

Item	Part #	Change No	Description	Usage Code	QTY
1	335/D1385		Body Valve		1
2	335/D1395		Plug		1
3	335/D1396		Valve Check		2

4	928/06004		Cartridge Non Return Valve		2
5	335/D1397		Valve Relief		1
6	335/D1398		Valve Relief		1



9822/0930 E390-50-1 OTHER VALVES LOW FLOW TOOL SELECT




332-K5287-1

Item	Part #	Change No	Description	Usage Code	QTY
1	25/987007		Cover inlet		1

2	335/D1451		Valve Spool Section		1
3	25/606811		Cover outlet		1



9822/0930 E390-60-1 OTHER VALVES DIRECTIONAL
CONTROL LOW FLOW




332-K6304-1

Item	Part #	Change No	Description	Usage Code	QTY
A	332/K6304		Valve directional control		1

2	:332/H1165		Valve directional		1
4	:332/H1169		Valve system relief		1



9822/0930 E390-65-1 OTHER VALVES DIRECTIONAL CONTROL LOW FLOW, GEAR PUMP DRIVEN, CLOSED CENTRE




332-K2446-1

Item	Part #	Change No	Description	Usage Code	QTY
A	332/K2446		Valve directional control		1

2	:332/H1163		Valve directional		1
3	:332/H1166		Valve cross line relief		1
4	:332/H1169		Valve system relief		1



9822/0930 E390-70-1 OTHER VALVES LOW FLOW




332-K5287-1

Item	Part #	Change No	Description	Usage Code	QTY
1	25/987007		Cover inlet		1
2	332/D1152		Valve slice		1
3	25/606811		Cover outlet		1



9822/0930 E390-75-1 OTHER VALVES AUXILIARY HAMMER




Item	Part #	Change No	Description	Usage Code	QTY
1	25/222731		Valve hammer auxiliary		1
2	:6900/0917		Cartridge Pilot		2
3	::25/978502		Kit-seal		1

4	:25/223566		Valve Cartridge		1
5	::25/221594		Kit seal		1



9822/0930 E390-85-1 OTHER VALVES SHUTTLE VALVE




334-J7985-3

Item	Part #	Change No	Description	Usage Code	QTY
1	334/J8559		Valve Shuttle		1
2	1316/0405D		Screw M10 x 20		2
3	1420/0008D		Washer (M10)		2

4	1620/0003		Adapter		2
5	816/90548		Adaptor elbow M/M		2
6	332/K2242		Adapter		1
7	1620/0002		Adapter		4
8	JHP0204		Washer back up		1



9822/0930 E390-90-1 OTHER VALVES 8 STATION VALVE ASSEMBLY




334-J7054-2

Item	Part #	Change No	Description	Usage Code	QTY
1	332/J4523		Valve 8 station solenoid inc. accumulator		1

2	1316/0305D		Screw M8 X 20		4
3	1420/0007D		Washer (M8)		4
4	KNJ0758		Adapter		9
5	KHJ0363		Plug		4
6	KHJ0349		Adapter elbow		2
7	KNJ0759		Adapter		1
8	JHJ0105		Adapter extended		1



9822/0930 E390-95-1 OTHER VALVES CUSHION VALVE



334-J7065-3

Item	Part #	Change No	Description	Usage Code	QTY
1	25/220041		Valve Cushion		1
2	1316/0405D		Screw M10 x 20		2
3	1420/0008D		Washer (M10)		2

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com