





Item	Part #	Change No	Description	Usage Code	QTY
0	JBV0510		Ram bucket 135mm cyl x 90mm rod		1
1	****		None serviced part		1
1-2	::331/11840		Bush pin bushing		1
1-3	::6900/0728		Wiper pin bushing		2
2	****		None serviced part		1
2-2	::331/11842		Bush pin bushing		1
2-3	::331/11837		Wiper pin bushing		2
3	****		None serviced part		1
4	****		None serviced part		1
5	****		None serviced part		1
6	****		None serviced part		1
7	****		None serviced part		1
9	****		None serviced part		1
10	****		None serviced part		1
11	****		None serviced part		1
12	:6900/0738		Screw		12
13	:331/11768		Cushion ring		1
14	****		None serviced part		1
15	:331/11763		Piston bucket ram 135/90MM		1
16	****		None serviced part		1
18	****		None serviced part		2
19	****		None serviced part		2
20	****		None serviced part		1
21	****		None serviced part		1
22	****		None serviced part		1
23	****		None serviced part		1
28	:6900/0723		Nipple grease		1
29	:998/10023		Kit bucket ram seal kit 135MM CYL X 90MM ROD <i>Includes item 4,6,7,9,10,11,16,18,19,20.</i>		1
30	:998/10076		Kit cylinder tube repair <i>Repair kit for item 1.</i>		1
31	:998/10069		Kit piston rod repair <i>Repair kit for item 2.</i>		1
32	:998/10061		Kit cylinder head repair <i>Repair kit for item 3,also includes item 4,5.</i>		1
34	:6900/0759		Kit repair nut <i>Includes items 21,22,23.</i>		1

JCB 9802/5860 E4-3-7 RAM, BUCKET PIPEWORK




Item	Part #	Change No	Description	Usage Code	QTY
1	KBV0816	<M 708625	Ram bucket	P/Ex	1
1	JBV0510	>M 708626	Ram bucket 135mm cyl x 90mm rod		1
2	JBV0518		Pipe bucket		1

3	KRV0548		Clamp		1
4	JRV0291		Clamp assembly		1
5	JRV0292		Clamp		1
6	2400/0205	Superseded	O Ring		1
6	2407/0205		O Ring		1
7	1391/3409Z		Capscrew M10 x 35mm		4
8	1316/3410Z		Bolt M10x40		9
9	1316/3511Z		Bolt		1
10	1425/0008Z		Spring Washer		2
11	1425/0009Z		Washer Spring M12		1
12	JHV0285	Superseded	Pipe bucket		1
12	335/07916		Pipe bucket ram Dump end		1
13	2400/0205	Superseded	O Ring		1
13	2407/0205		O Ring		1
14	1391/3409Z		Capscrew M10 x 35mm		4
15	1371/0301Z		Nut High Strength, M10		2



9802/5860 F4-1-1 GEARBOX ASSEMBLY & SPROCKET




552060

Item	Part #	Change No	Description	Usage Code	QTY
1	JBA0167		Motor & track gearbox	P/Ex	2
2	JRA0113		Sprocket drive 21 teeth & 22 holes		2
3	1316/3715Z		Bolt		44
4	1316/3714Z		Bolt		52
5	JHP0043		Washer M16		96




9802/5860 F4-2-1 GEARBOX, TRACK



Item	Part #	Change No	Description	Usage Code	QTY
A	JBA0167		Motor & track gearbox	P/Ex	2
B	:JRA0121		Gearbox	P/Ex	1
1	::05/901963		Capscrew		10
2	::05/903821		Cover assembly		1
3	::05/903822	Superseded	Plug breather		2
3	::05/903802		Plug breather		2
4	::05/903803		Washer		2
5	::05/903820	Superseded	Pad		1
5	::05/901926		Pad thrust		1
6	::05/903819		O Ring		1
7	::05/903804		Gear sun		1
8	::05/903805		Gear reduction set 1st planet		1
9	::05/903806		Gear reduction set 2nd planet		1
10	::05/903807		Circlip		5
11	::05/903808		Gear planet		5
12	::05/903809		Nut		1
13	::05/903859		Housing with bearing		1
14	::05/903811		Seal assembly		1
15	::05/903812		Ring centering		1
16	::05/903813		Hub		1
18	::05/903854		Coupling		1
19	::05/903855		Circlip		1
20	:JBA0055		Motor track	P/Ex	1
21	:1391/3520Z		Capscrew M12X100		4
22	:05/903814	Superseded	O Ring		1
22	:2400/0258		O Ring		1
23	::05/903838		Spacer		5



9802/5860 F4-3-1 SWING ASSEMBLY




556230

Item	Part #	Change No	Description	Usage Code	QTY
1	KRB0681		Plate Cover		1
2	KRB0682		Packing Cork		1

3	1316/0507Z		Screw		3
4	6060/0009R	Superseded	Washer spring		3
4	6060/0009Z		Washer M12 spring		3
5	KBB0413	Superseded	Ring swing		1
5	JBB0001	Superseded	Ring slew		1
5	M.S.S.		Multi Supersession		1
5	916/10029		Ring slew <i>Fit Insert 826/11216 in 3 unused holes.</i>		1
5	826/11216		Insert bung counterweight lift point		3
5-1	KBB0418	<M	Ring seal <i>Used with KBB0413.</i>		1
5-1	KBB0419	Superseded	Ring seal <i>Used with KBB0413.</i>		1
5-1	KBB0646		Ring seal		1
5-1	6900/0035	>M	Seal <i>Used with JBB0001.</i>		1
6	1316/4021Z		Bolt		26
7	1316/4018Z		Bolt		45
8	JHP0063		Washer		45
9	KBC0085		Motor gearbox assembly		1
10	1316/0709Z		Screw		2
11	C4E9301		Adapter Plug		1
12	KBC0084		Pipe assembly		1
13	KRC0105		Pin headed		1
14	JHP0037		Nipple Grease Straight		1
15	KBC0079		Spacer		1
16	KBC0073		Gear pinion		1
17	KBC0075		Plate end		1
18	BRC0002	Superseded	Washer keeper		1




9802/5860 F4-4-1 GEARBOX SWING



Item	Part #	Change No	Description	Usage Code	QTY
A	LNMO444		Gearbox swing		1
1	:LJM0081		Shaft		1
2	:LMM0555		Collar		1
3	:LZM0342		Plate		1
4	:LMM0546		Ring snap		1
5	:LTM0203		Bearing roller		1
6	****		None serviced part		1
7	:LAM0062		Seal oil		1
8	:LTM0202		Bearing roller		1
9	:LMM0341		Pin		4
10	:LDM0182		Gear ring		1
11	****		None serviced part		1
12	:LDM0181		Gear		1
13	****		None serviced part		1
14	:LKM0109		Plate thrust		1
15	:LDM0185		Gear sun		1
16	:1391/3716Z		Capscrew		12
17	:UBJ0383		Plug		1
18	:UBJ0381		Plug		2
19	:LMM0556		TBA å+_		1



9802/5860 F4-4-2 GEARBOX SWING




702750

Item	Part #	Change No	Description	Usage Code	QTY
A	05/202200		Gearbox swing		1
1	:20/951550		Circlip Slew gearbox		1
2	:20/951547		Gear sun Swing gearbox		1

3	:20/951551		Dipstick kit Swing gearbox	1
4	:20/951546		Gear reduction assembly Swing gearbox	1
5	:20/951548		Capscrew m16 x 120 Swing gearbox	11
6	:20/951545		Ring toothed Swing gearbox	1
7	:20/951549		Capscrew M12 x 35 Swing gearbox	8
8	:20/951544		Gear sun Swing gearbox	1
9	:20/951542	Superseded	O Ring Slew gearbox	2
9	:05/903840		O Ring	2
10	:20/951543		Ring toothed Swing gearbox	1
11	:20/951541		Gear reduction assembly Swing gearbox	1
12	:20/951538		Gear output assembly Swing gearbox	1
13	::20/951540		Nut special Swing gearbox	1
14	::20/950974		Spacer	1
15	::20/950973		Bearing	1
16	::20/950972		Seal ring	1
17	::20/951539		Gearbox housing Swing gearbox	1
18	::20/950970		Bearing	1
19	::20/951537		Ring nilos Pinion shaft	1
20	::20/951536		Spacer Pinion shaft Slew gearbox	1
21	::20/951535		Shaft pinion Slew gearbox	1



9802/5860 F4-5-1 CIRCUIT SWING RING GREASING




556790

Item	Part #	Change No	Description	Usage Code	QTY
1	KBB0424		Pipe assembly grease line		1
2	KBB0423		Pipe assembly grease line		1
3	KMJ0985		Adapter elbow		2
4	JHP0037		Nipple Grease Straight		3
5	KMJ0964		Connector		2
6	KRR0173	to 04/09/2011	Clamp PVC coated		1
6	333/J2458		Clamp Zinc plated		1
7	1425/0006Z	to 04/09/2011	Washer Spring (M6)		2
7	1425/0006D		Washer Spring M6		2
8	1316/0201D		Screw		2
9	KRR0170	to 04/09/2011	Clamp PVC coated		1
9	333/J2461		Clamp Zinc plated		1
10	JRB0055		Plate block <i>Welded to frame.</i>		1



9802/5860 J1-1-1 UNDERCARRIAGE




Item	Part #	Change No	Description	Usage Code	QTY
------	--------	-----------	-------------	------------	-----

1	JG0BA025		Frame undercarriage standard <i>JS240/260 SC. 47 Links 7 rollers per side.</i>		1
1	JG0BA011		Frame undercarriage long <i>JS240/260 LC. 51 Link 9 rollers per side.</i>		1
1	JG0BA031		Frame undercarriage <i>JS240/260 NLC. 51 Links 9 rollers per side.</i>		1
2	KRA1107		Cover		2
3	KRA1246		Cover track motor left hand		1
4	KRB0681		Plate Cover		1
5	KRB0682		Packing Cork		1
6	1316/0505Z		Screw M12x20		3
7	6060/0009R	Superseded	Washer spring		11
7	6060/0009Z		Washer M12 spring		11
8	KRA1247		Cover track motor right hand		1
9	JHN0048		Bolt		4
10	1316/0509Z		Setscrew		8
11	JHP0042		Washer M12		8
12	JG0RA026	<M 17-4-01	Guard		2
12	331/22432	>M 18-4-01	Guide track <i>Round leading edge</i>		2
13	1316/9512Z		Bolt		8
14	KHN1323	Superseded	Washer high strength		8
14	JHP0079		Washer (19mm x 36mm x 4.5mm)		8
15	JBA0087		Block top roller		2



9802/5860 J1-2-1 IDLER WHEEL



Item	Part #	Change No	Description	Usage Code	QTY
1	KBA0877	Superseded	Wheel track idler assembly		2
1	KBA1030		Roller track idler assembly		2
1-1	:KBA0878		Wheel track idler		1

1-2	:KBA0876		Bush		2
1-3	:KBA0431		Seal oil, floating		2
1-4	:KBA0879		Hub		2
1-5	:BRA0047		O Ring		2
1-6	:KBA0439		Clip wire		2
1-7	:KBA0766		Shaft idler		1
1-8	:KHJ0300		Plug		1

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.
You can download the most
perfect and complete manual in
the world immediately.

Our support email:
ebooklibonline@outlook.com