





9822/0330 F400-5-1 TRACK SLEW GEARBOX INSTALLATION ASSEMBLIES TURNTABLE BEARING



Item	Part #	Change No	Description	Usage Code	QTY
2	916/10029		Ring slew		1

3	1316/4021D		Bolt		26
4	1316/4018D		Bolt M24 x 80mm		36
5	JHP0063		Washer		36
6	4101/0500		Fluid Locking Loctite 262		0
7	KRB0681		Plate Cover		1
8	KRB0682		Packing Cork		1
9	1316/0507D		Setscrew M12 x 25 grade 10.9		3
10	1425/0009Z		Washer Spring M12		3
11	JHC0001		Sealant liquid packing, Gasket		0
12	826/11216		Insert bung counterweight lift point		3


9822/0330 F430-1-1 SLEW/SWING MOTOR INSTALLATION & GEARBOX



Item	Part #	Change No	Description	Usage Code	QTY
1	05/202200		Gearbox swing		1

2	20/925266		Motor swing		1
3	1391/3509D		Capscrew M12x35mm		8
4	1316/3817D		Bolt		9
5	JHP0044		Washer		9
6	KRC0105		Pin headed		1
7	JBC0004		Pipe assembly		1
8	C4E9301		Adapter Plug		1
9	4102/1203		Sealant		0
10	4102/2700		Loctite		0

JCB 9822/0330 F490-1-1 OTHER SLEW/SWING PARTS GREASE
LINE (J904) TTB




9G0BB063-4

Item	Part #	Change No	Description	Usage Code	QTY
2	JHP0037		Nipple Grease Straight		3

3	KMJ0964		Connector		2
4	KBB0423		Pipe assembly grease line		1
5	KBB0424		Pipe assembly grease line		1
6	KMJ0985		Adapter elbow		2
7	333/J2461		Clamp Zinc plated		1
8	333/J2458		Clamp Zinc plated		1
9	1316/0201D		Screw		2
10	1420/0006D		Washer (M6)		2

9822/0330 J100-20-1 UNDERCARRIAGE INSTALLATION ASSEMBLIES LC




215-11355-4

Item	Part #	Change No	Description	Usage Code	QTY
1	****		Frame lower assembly		1

2	****		Roller lower assembly		1
3	****		Roller upper assembly		1
5	****		Joint centre assembly		1
6	****		Traction equipment assembly		1
7	****		Roller take-up assembly		1
9	****		Circuit traction motor line assembly		1

JCB 9822/0330 J100-35-1 UNDERCARRIAGE INSTALLATION ASSEMBLIES FULL GUARD




333-K1372-1

Item	Part #	Change No	Description	Usage Code	QTY
1	****		Frame lower assembly, LC XD		1

2	****		Roller lower assembly		1
3	****		Roller upper assembly		1
4	****		Guide track assembly		1
5	****		Joint centre assembly		1
6	****		Traction equipment assembly		1
7	****		Roller take-up assembly		1
8	****		Circuit traction motor line assembly		1



9822/0330 J110-1-1 UNDERCARRIAGE ASSEMBLY CENTRE JOINT




Item	Part #	Change No	Description	Usage Code	QTY
1	JHP0042		Washer M12		5

2	KRA0999		Retainer Seal		1
3	KRA1000		Packing Rubber		1
4	1316/0508D		Screw M12 X 30		11
5	1406/0011		Washer Bonded (1/4")		6
6	331/14076		Bracket stop		1
8	45/920115		Coupling rotary		1
9	904/20126		Ring Seal		1
10	****		Fluid Locking		1



9822/0330 J110-30-1 UNDERCARRIAGE LOWER FRAME LC




JG0BA010-5

Item	Part #	Change No	Description	Usage Code	QTY
1	****		Covers lower		1
3	KRB0682		Packing Cork		1
4	1316/0505D		Bolt M12 x 20mm		3

6	1316/0507D		Setscrew M12 x 25 grade 10.9		4
7	4101/0500		Fluid Locking Loctite 262		0
8	1316/0509D		Screw M12x35 long		8
9	JHP0042		Washer M12		12
10	335/10532		Frame undercarriage		1



9822/0330 J120-1-1 RECOIL AND IDLER ASSEMBLY TENSION DEVICE




931220

Item	Part #	Change No	Description	Usage Code	QTY
1	JBA0129		Wheel track idler assembly		1

2	JBA0130		Yoke spring and fork assembly		1
3	1316/3712D		Bolt M16 x 50mm		4
4	JHP0043		Washer M16		4



9822/0330 J130-1-1 RECOIL UNIT & YOKE ASSY




292731

Item	Part #	Change No	Description	Usage Code	QTY
A	JBA0130		Yoke spring and fork assembly		2
2	:JHP0043		Washer M16		4
3	:1316/3712Z		Bolt M16 X 50MM		4

7	****		None serviced part		1
7-1	:JBA0140		Piston		1
7-2	:JBA0142		Seal		1
7-3	:JBA0141		Seal		1
7-6	:JBA0143		Bracket		1
7-8	:1316/0403Z		Screw		2
7-9	:JRA0233		Valve check		1
8	:6011/0707Z		Capscrew		1
9	****		'See Remark' <i>KTA0870</i>		1



9822/0330 J140-1-1 IDLER ASSEMBLY FRONT



Item	Part #	Change No	Description	Usage Code	QTY
1	JBA0129		Wheel track idler assembly		2
1-1	:JBA0133		Wheel idler		1
1-2	::JBA0135		Bush		2

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com