




9822/0505 F410-1-5 GEARBOX ASSEMBLY & SPROCKET TRACTION EQUIPMENT




333-J6711-1

Item	Part #	Change No	Description	Usage Code	QTY
1	331/42742		Sprocket		2

2	333/K1153		Motor Drive, Track		2
3	JHP0044		Washer		48
4	1316/3818D		Bolt		48
5	JHP0063		Washer		36
6	1316/4016D		Bolt		36
7	4101/0500		Fluid Locking Loctite 262		0



9822/0505 F420-1-1 GEARBOX TRACK




298920

Item	Part #	Change No	Description	Usage Code	QTY
A	:JSA0073		Motor track gearbox		2
B	::05/202500		Gearbox assembly		2

1	:::05/903839		Bolt	20
2	:::05/903803		Washer	2
3	:::05/903802		Plug breather	2
4	:::05/903840		O Ring	1
5	:::05/903841		Pad	1
6	:::05/903842		Cover set <i>includes items 2,3,4 & 5</i>	1
7	:::05/903843		Gear sun	1
8	:::05/903844		Gear reduction set 1st planet	1
9	:::05/903845		Gear reduction set 2nd planet	1
10	:::05/903846		Bolt	4
11	:::05/903847		Gear planet	1
12	:::05/903848		Bush	4
13	:::05/903849		Hub <i>Includes bearing.</i>	1
14	:::05/903850		Seal assembly	1
15	:::05/903851		Retainer	1
16	:::05/903852		Hub	1
17	:::05/903853		Spacer	301
18	:::2400/0258		O Ring	1
19	:::05/903854		Coupling	1
20	:::05/903855		Circlip	1
21	:::05/903857		Motor hydraulic	1
22	:::05/903856		Screw	4



9822/0505 F420-5-1 GEARBOX TRACK MOTOR FIG.1




Item	Part #	Change No	Description	Usage Code	QTY
A	:05/903857		Motor hydraulic		1
1	****		None serviced part		1
2	::20/951027		Plate base assembly <i>Includes items 20 & 35</i>		1
2-1	****		None serviced part		1
3	:::20/951028		Valve assembly		1
4	:::20/951029		Plunger assembly		1
5	:::20/951030		Kit-plug		2
6	:::20/951031		Orifice assembly <i>Includes items 6A to 6F</i>		1
6A	****		None serviced part		2
6B	****		None serviced part		2
6C	****		None serviced part		2
6D	****		None serviced part		2
6E	****		None serviced part		2
6F	****		None serviced part		1
7	:::20/951032		Spool assembly		1
8	:::20/951033		Plug assembly		1
8A	****		None serviced part		10
8B	****		None serviced part		3
8C	****		None serviced part		1
8D	****		None serviced part		5
8E	****		None serviced part		2
8F	****		None serviced part		2
9	:::20/951034		Valve relief assembly		2
10	::20/951035		Cylinder block		1
10A	****		None serviced part		1
10B	****		None serviced part		1
10C	****		None serviced part		9
10D	****		None serviced part		1
10E	****		None serviced part		1
10F	****		None serviced part		1
10G	****		None serviced part		1
10H	****		None serviced part		1
10I	****		None serviced part		1
10J	****		None serviced part		3
11	::20/951036		Plate swash assembly		1
11A	****		None serviced part		1
11B	****		None serviced part		2
11C	****		None serviced part		2
11D	****		None serviced part		2
12	::20/951037		Motor shaft		1
13	::20/951038		Seal motor shaft		1
14	::20/951039		Bearing kit		1
14A	****		None serviced part		1
14B	****		None serviced part		1
15	::20/951026		Brake assembly		1
15A	****		None serviced part		1
15B	****		None serviced part		3
15C	****		None serviced part		3
15D	****		None serviced part		2

15E	****		None serviced part		8
15F	****		None serviced part		8
99	20/951040		Kit seal		1



9822/0505 F420-6-1 GEARBOX TRACK MOTOR FIG.2




403060

Item	Part #	Change No	Description	Usage Code	QTY
A	:05/903857		Motor hydraulic		1
1	****		None serviced part		1
2	::20/951027		Plate base assembly <i>Includes items 20 & 35</i>		1
2-1	****		None serviced part		1
3	:::20/951028		Valve assembly		1
4	:::20/951029		Plunger assembly		1
5	:::20/951030		Kit-plug		2
6	:::20/951031		Orifice assembly <i>Includes items 6A to 6F</i>		1
6A	****		None serviced part		2
6B	****		None serviced part		2
6C	****		None serviced part		2
6D	****		None serviced part		2
6E	****		None serviced part		2
6F	****		None serviced part		1
7	:::20/951032		Spool assembly		1
8	:::20/951033		Plug assembly		1
8A	****		None serviced part		10
8B	****		None serviced part		3
8C	****		None serviced part		1
8D	****		None serviced part		5
8E	****		None serviced part		2
8F	****		None serviced part		2
9	:::20/951034		Valve relief assembly		2
10	::20/951035		Cylinder block		1
10A	****		None serviced part		1
10B	****		None serviced part		1
10C	****		None serviced part		9
10D	****		None serviced part		1
10E	****		None serviced part		1
10F	****		None serviced part		1
10G	****		None serviced part		1
10H	****		None serviced part		1
10I	****		None serviced part		1
10J	****		None serviced part		3
11	::20/951036		Plate swash assembly		1
11A	****		None serviced part		1
11B	****		None serviced part		2
11C	****		None serviced part		2
11D	****		None serviced part		2
12	::20/951037		Motor shaft		1
13	::20/951038		Seal motor shaft		1
14	::20/951039		Bearing kit		1
14A	****		None serviced part		1
14B	****		None serviced part		1
15	::20/951026		Brake assembly		1
15A	****		None serviced part		1
15B	****		None serviced part		3
15C	****		None serviced part		3
15D	****		None serviced part		2

15E	****		None serviced part		8
15F	****		None serviced part		8
99	20/951040		Kit seal		1



9822/0505 F430-1-1 SLEW/SWING MOTOR INSTALLATION




332-K4687-1

Item	Part #	Change No	Description	Usage Code	QTY
1	KRC0079		Pin headed		1
2	1609/0004		Adapter		1

3	332/J0679		Pipe slew gearbox drain		1
4	KSC0186		Clamp pipe		1
5	1316/0305D		Screw M8 X 20		1
6	1316/4018D		Bolt M24 x 80mm		12
7	JHP0063		Washer		12
8	4101/0500		Fluid Locking Loctite 262		0
9	332/K3065		Cap Pipe G1/2"		1
10	****		Swing Gearbox Assembly		1
11	JHP0080		Washer (M8)		1
12	BHJ0967		Socket		1



9822/0505 F440-1-1 GEARBOX SLEW/SWING




215-13801-2

Item	Part #	Change No	Description	Usage Code	QTY
1	05/205900		Gearbox swing		1
2	333/J2160		Motor hydraulic		1

3	1391/3812D		Capscrew M20 x 50mm		12
4	4101/0500		Fluid Locking Loctite 262		0
5	****		Fluid Locking		0



9822/0505 F440-5-1 GEARBOX SLEW/SWING




951980

Item	Part #	Change No	Description	Usage Code	QTY
A	05/205900		Gearbox swing		1
1	:332/F1067		Shaft pinion		1

2	:20/950968	Spacer	1
3	:20/950969	Ring nilos	1
4	:332/F1073	Bearing	1
5	:332/F1075	Gearbox output assembly	1
6	:20/950971	Gearbox housing	1
7	:20/950972	Seal ring	2
8	:20/950973	Bearing	1
9	:20/950974	Spacer	1
10	:20/950976	Nut	1
11	:20/950975	Seal O ring	2
12	:05/202700	Ring toothed	1
13	:05/202600	Gear reduction assembly	1
14	:05/202601	Gear sun	1
15	:05/202602	Ring toothed	1
16	:332/F1078	Capscrew	12
17	:05/202603	Gear reduction assembly	1
18	:05/202605	Gear sun	1
19	:05/903807	Circlip	1
20	:332/F1079	Filler lubrication kit	1
21	:05/202604	Screw	20



9822/0505 F480-1-1 CIRCUIT SLEW/SWING GREASING TURNTABLE BEARING



215-12534-2

Item	Part #	Change No	Description	Usage Code	QTY
1	JSB0022		Bearing turntable		1

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com