




9822/0510 B210-35-1 OPERATOR ENCLOSURE CAB

ASSEMBLY



334-P1145-1


Item	Part #	Change No	Description	Usage Code	QTY
1	1423/0009Z		Washer lock,toothed		4
2	1423/0007Z		Washer lock,toothed		1
3	1315/0205D		Setscrew M6 x 20		2
4	1370/0201D		Nut Plain M8		4
6	1420/0006D		Washer (M6)		5
7	1315/0509D		Screw M12x35mm		2
8	1420/0009D		Washer (M12)		2
9	1420/0007D		Washer (M8)		3
10	1315/0207D		Setscrew M6 x 25mm		4
11	823/10578		Washer M6 Black		2
12	1315/0303D		Setscrew M8 x 16mm		3
13	229/01495		Nut cap (tim-100830)		2
14	1316/0205D		Screw set		5
15	1315/0307D		Setscrew M8 x 25 mm		4
16	826/10651		Nut U type		2
17	826/01099		Rivet Nut M6		2
18	332/P8518		Grommet Blind		1
19	334/P1492		Washer tube		1
20	1391/3303D		Capscrew		4
21	6900/0523		Clip axle		1
23	6900/0569		Washer		4

24	821/10267		Clip		8
25	828/00320		Grommet		1
26	331/19929		Knob		1
27	333/J8919		Buffer spacer		1
28	332/C6303		Rivet pop 4mm diameter		2
29	332/L1522		Plate identity		1
30	826/11591		Screw button head		2
31	334/P1486		Seal - 2.2m anti drip		2
32	6900/0562		Stopper		2
33	331/41517		Grommet		4
34	334/P2542		Nut cap M5		2
35	6900/0605		Spacer plastic		1
36	6900/0603		Screw		1
37	826/10887		Screw button head torx		6
38	6900/0541		Guide		1
39	332/L1580		Cab connection		1
40	823/00521		Washer rubber		2
41	826/11069		Screw M6x20 button head Black		4
42	1430/1002		Screw self tap		8
43	6900/0627		Joint ball		1
44	6900/0587		Light roof		1
45	6900/0543		Latch		1
46	6900/0604		Spacer		1
47	332/L1592		Wire speaker		1
48	6900/0606		Spring		1
50	826/01077		Screw		2
51	1410/0005D		Washer 1/2in small		1
52	334/P2541		Switch		1
53	331/37333		Washer foam		2
54	827/80219		Glass cab l/hand rear		1
55	331/36359		Rod axle		1
56	331/37334		Grommet		1
57	331/36334		Striker		1
58	331/36335		Guard		1
59	1371/0401D		Nut M12		1
60	331/36346		Cover		1
61	333/P9202		Grommet		2
62	334/P2522		Grommet		1
63	332/L8736		Speaker loud		2
64	331/19926		Stop cab roof		2
65	334/P1417		Bumper window		2
66	334/P1162		Lock window,lower		2
67	333/J3865		Window right side		1
68	333/J3869		Window rear		1
69	334/P2528		Cab antenna		1
70	334/P2527		Harness		1
71	334/P0610		Cover wiper motor		1
73	826/11459		Screw c/sk M5x12		8
74	334/P1416		Guide		4
75	334/P1415		Cab protector		1
76	333/J3863		Window roof		1

77	334/P2530		Motor wiper 24V left		1
78	334/P2531		Arm wiper		1
79	334/P2532		Blade wiper		1
80	334/P1414		Cab headliner		1
81	334/P1413		Retainer		2
82	334/P1412		Seal window,front		1
83	334/P1411		Retainer		2
84	334/P1410		Grommet		2
85	334/P1161		Support glass,rear		2
86	334/P1163		Washer lower window		2
87	334/P1160		Lever		1
88	334/P1159		Bracket wiper blade		1
89	826/11430		Nut nyloc M5		8
90	334/L8565		Cover		1
91	331/36343		Cover rear		1
92	334/L8476		Frame cab		1
93	1420/0005Z		Washer (M5)		4
94	1315/0105Z		Setscrew M5 x 20		4
95	828/10333		Plug Blanking		2
96	334/P3059		Roller assembly		1
97	334/P4613		Bracket sunscreen left side		1
98	334/P2999		Bracket sunscreen right side		1
100	1370/0101D		Nut Plain M6		1
102	334/P3635		Cable M4-M6 earth strap		1
103	334/P3902		Washer 50-11-1		1



9822/0510 B220-1-1 MOUNTINGS CAB FASTENERS




215-11563-5

Item	Part #	Change No	Description	Usage Code	QTY
1	1316/3514D		Bolt M12 x 60		6
2	JHP0042		Washer M12		8
3	KHN1256		Bolt		2

4	826/01649		Bolt Dome Head Tuf-lock		1
5	1371/0401D		Nut M12		2



9822/0510 B220-5-1 MOUNTINGS CAB




333-J1848-3

Item	Part #	Change No	Description	Usage Code	QTY
1	333/J5301		Rubber mount		6
2	JHP0043		Washer M16		6
3	1371/0603D		Nut M16 self locking		6

4	JHP0046		Washer M10		24
5	1316/0408D		Setscrew		24
6	4101/0500		Fluid Locking Loctite 262		0



9822/0510 B220-10-1 MOUNTINGS MIRROR




333-J4510-1

Item	Part #	Change No	Description	Usage Code	QTY
1	332/J7749		Mirror		1
2	333/J1496		Bracket		1
3	835/10070		Plug Blanking		1

4	1316/0510D		Screw		2
5	1420/0009D		Washer (M12)		2



9822/0510 B220-15-1 MOUNTINGS COMPRESSOR ASSEMBLY




Item	Part #	Change No	Description	Usage Code	QTY
1	332/K3830		Belt V-Belt Drive 1010LG		1

2	333/J2299		Pulley Assembly	1
3	332/K3327		Bolt Slider	1
4	823/00377		Washer Plain	1
5	1371/0301D		Nut High Strength	7
6	331/40447		Cap Pulley Protection	1
8	826/11085		Bolt	1
9	333/K9148		Mount Engine/AC	1
11	1391/3413D		Capscrew	4
14	1422/0008D		Washer Hardened (M10)	9
15	1316/3416D		Bolt	6
16	JHP0046		Washer M10	6
17	4101/0500		Fluid Locking Loctite 262	0
18	332/K3536		Spacer 30mm	6
19	332/K1964		Clamp Clip P	1
20	1316/0203D		Screw	1
21	1411/0001D		Washer (1/4" Medium)	1
22	823/10261		Washer Nord Lock	1



9822/0510 B230-1-1 ROOF ROPS GUARD




334-L7052-4

Item	Part #	Change No	Description	Usage Code	QTY
1	333/J6574		Guard Frame ROPS		1
2	333/K2302		Frame Mounting ROPS		1
3	JHP0063		Washer		8

4	JHP0044		Washer		24
5	1316/3816Z		Bolt M20x70		8
6	1316/4018Z		Bolt		8
7	1371/0703Z		Nut self lock		8
8	1371/0903Z		Nut self locking		8
9	1316/3813Z		Bolt		8
10	333/K1219		Bracket Mirror		1
11	1316/0410Z		Screw M10 x 40 High Tensile		2
12	1371/0303Z		Nut		2
13	1420/0008Z		Washer (M10)		4
14	333/K0708		Bracket Light		2
15	1316/0509Z		Setscrew		2
16	JHP0042		Washer M12		2
17	333/K3453		Plate Shim		1
18	331/48889		Buffer		1



9822/0510 B230-5-1 ROOF FOPS GUARD




334-L9417-1

Item	Part #	Change No	Description	Usage Code	QTY
1	333/J7320		Guard Top		1
2	333/J7331		Guard Front		1
3	JHP0042		Washer M12		8

4	1316/3514D		Bolt M12 x 60		6
5	1316/3512D		Bolt M12X50		2



9822/0510 B240-1-1 DOORS ASSEMBLY




Item	Part #	Change No	Description	Usage Code	QTY
1	333/J0057		Door front LH		1
2	333/J0055		Door rear, left side		1
3	333/J0056		Door rear RH		1

4	333/K1511		Plate Mounting Hinge		1
5	333/J0201		Mounting plate hinge		2
6	333/J1865		Latch paddle (Yellow)		3
7	332/K7311		Bracket Support		2
8	333/J1293		Bracket latch		1
9	333/J3188		Block Door Buffer ABI		3
10	KHN1395		Stop Rubber		6
11	333/J1800		Stay bar		2
12	333/J1825		Stay bar		1
13	332/K5635		Panel soundproofing LH front door		1
14	331/42293		Panel soundproofing cab rear		1
15	826/11430		Nut nyloc M5		12
16	1420/0005D		Washer (M5)		12
17	1316/0305D		Screw M8 X 20		6
18	1370/0201D		Nut Plain M8		6
19	1420/0007D		Washer (M8)		20
20	1391/3309D		Capscrew M8 X 35		6
21	1370/0301D		Nut (M10)		6
22	1316/0508D		Screw M12 X 30		21
23	1420/0009D		Washer (M12)		9
25	826/01308		Button Fastener		10
26	KRJ1588		Pin		3
27	1411/0005D		Washer		12



9822/0510 B240-1-5 DOORS ASSEMBLY




Item	Part #	Change No	Description	Usage Code	QTY
1	334/L7150		Door Front Left Side		1
2	334/L7122		Door Rear Left Side		1
3	334/L7133		Door Rear Right Side		1

4	333/K1511		Plate Mounting Hinge		1
5	333/J0201		Mounting plate hinge		2
6	333/K1035		Latch paddle yellow		3
7	334/L7442		Bracket Support		2
8	334/L8030		Bracket Latch		1
9	333/J3188		Block Door Buffer ABI		3
10	KHN1395		Stop Rubber		6
11	333/J1800		Stay bar		2
12	333/J1825		Stay bar		1
13	332/K5635		Panel soundproofing LH front door		1
14	331/42293		Panel soundproofing cab rear		1
15	1370/0103Z		Nut Self Lock M6		12
16	1420/0006Z		Washer (M6)		12
17	1316/0305D		Screw M8 X 20		6
18	1370/0201D		Nut Plain M8		6
19	1420/0007D		Washer (M8)		20
20	1391/3309D		Capscrew M8 X 35		6
21	1370/0301D		Nut (M10)		6
22	1316/0508D		Screw M12 X 30		21
23	1420/0009D		Washer (M12)		9
25	826/01308		Button Fastener		10
26	KRJ1588		Pin		3
27	1411/0005D		Washer		12



9822/0510 B240-10-1 DOORS COMPONENTS



333-E3358-1

Item	Part #	Change No	Description	Usage Code	QTY
A	333/E3358		Door assembly		1
1	:333/E3359		Frame door		1
2	:333/J3903		Door glass assembly (3 pieces)		1

2A	::333/J3904	Glass sliding	1
2B	::333/J3902	Glass lower door	1
4	:331/36385	Screw handle support	8
5	:6900/0574	Nut	4
6	:6900/0571	Nut	2
7	:6900/0550	Washer	8
8	:6900/0644	Washer	2
9	:6900/0570	Washer	2
10	:331/36379	Cap nut M12	2
11	:6900/0992	Washer	4
12	:331/37557	Screw	5
13	:821/10267	Clip	5
14	:333/E3361	Clip	1
15	:6900/0554	Screw	2
16	:331/41504	Washer	2
17	:331/36382	Washer lock rod	2
18	:331/36392	Screw	4
19	:331/36378	Hook door lock back	1
20	:331/36390	Seal handle	1
21	:331/36391	Key cab door	1
23	:334/L0064	Seal circular rubber	2
24	:332/F8659	Screw M8 x 35 (DIN 7991)	2
25	:333/E3363	Cover lower	1
26	:333/E3364	Cover upper	1
27	:333/E3365	Rod lock	1
28	:333/E3366	Latch door	1
29	:333/E3367	Handle outer door	1
30	:333/E3368	Nut M4	2
31	:333/E3369	Bracket door latch	1
32	:333/E3370	Seal door	1

This exploded view diagram illustrates the assembly of a vehicle door. The main components shown are the inner door panel (1) and the outer door skin (2). The diagram includes various hardware such as screws (4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 17, 18, 19, 20, 23, 24, 29, 30, 31), nuts (16), washers (17), and specialized fasteners (18, 19). Key sub-assemblies like the door hinge mechanism (21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31) and the door latch (12) are also depicted. The diagram is labeled with the part number 334-P0604-1.

Item	Part #	Change No	Description	Usage Code	QTY
1	334/L8487		Door		1
2	334/P1061		Door sliding bay		1
3	334/P1045		Seal door		1

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com