




9822/0435 L100-2-10 ENGINE INSTALLATION ASSEMBLIES




333-W3173-3

Item	Part #	Change No	Description	Usage Code	QTY
1	333/V8632		Engine PSI LPG 49kw 3.0L L4 c/w with fuel system		1
2	334/R7454		Adaptor <i>FOR ITEM 1 TO ITEM 3</i>		1

3	333/W2165		Hose oil fill		1
4	332/G4601		Clip Worm Drive 35 to 50 Dia <i>FOR ITEM 3</i>		2
5	331/18342		Bell Housing, Engine Mounting		4
6	1315/0509D		Screw M12x35mm <i>FOR ITEM 5</i>		4
7	1422/0009D		Washer Hardened (M12) <i>FOR ITEM 6</i>		4
8	1315/0408D		Setscrew M10 x 30 <i>FOR ITEM 5 TO CHASSI</i>		8
9	1420/0008D		Washer (M10) <i>FOR ITEM 8</i>		16
10	1370/0303D		Nut Self Lock M10 <i>FOR ITEM 8</i>		8
11	834/10261		Hose <i>FOR ITEM 1</i>		1
12	650/10166		Adaptor Hose Connector 16mm OD <i>FOR ITEM 11</i>		1
13	2201/0006		Clip Jubilee, 17/32mm <i>FOR ITEM 11</i>		2
14	2201/0005		Clip Worm Drive 14/27mm <i>FOR ITEM 15 & 16</i>		2
17	264/36400		Plate Harness Tie <i>TO ENGINE BELL HOUSI</i>		3
18	1410/0003D		Washer <i>FOR ITEM 17</i>		3
19	1403/0004		Washer alluminium		1
20	1340/1701D		Nut Plain 3/8 unc <i>FOR ITEM 17</i>		3
21	333/R1505		Gasket Engine LPG <i>FOR ENGINE EXHAUST</i>		1
22	1315/0308D		Setscrew M8 x 30 mm <i>FOR ITEM 21</i>		3
23	1422/0007D		Washer M8 <i>FOR ITEM 22</i>		3
24	814/00289		Spring <i>FOR ITEM 25</i>		1
25	334/L8822		Cable throttle		1
26	204/07007		Tie cable - 100mm Long		1
27	334/T2744		Switch , Water Temperature		1



9822/0435 L100-5-1 ENGINE INSTALLATION ASSEMBLIES




Item	Part #	Change No	Description	Usage Code	QTY
1	332/S6579		Engine assembly 404D-22 nat/aspirated		1
2	332/T4376		Cable throttle control <i>FIT TO ITEM 4</i>		1

3	814/00289		Spring <i>FIT TO ITEM 2</i>		1
4	332/T5357		Bracket throttle cable <i>FIT TO ITEM 1</i>		1
5	826/01558		Screw M6 x 15mm long <i>FOR ITEM 4</i>		2
6	814/10148		Spring tension <i>FIT TO ITEM 4 & 7</i>		1
7	331/65152		Plate throttle extension <i>FIT TO ITEM 1</i>		1
8	529/38602		Pin Clevis <i>FIT TO ITEM 1 FOR IT</i>		1
9	332/S8896		Clip 'E' for 6mm groove <i>FIT TO ITEM 8</i>		1
10	1420/0007Z		Washer (M8) <i>FIT QTY 2 TO ITEM 8</i>		9
11	913/00031		Pin spring,6mm clevis <i>FOR ITEM 2</i>		1
12	332/T6667		Adapter oil filler <i>FIT TO ITEM 1</i>		1
13	332/T3893		Hose oil filler <i>FIT TO ITEM 12</i>		1
14	2201/0009		Clip Jubilee <i>FOR ITEM 13</i>		2
15	295/20898		Pipe exhaust assembly <i>FIT TO ITEM 1</i>		1
16	331/40878		Pipe exhaust inlet <i>FIT TO ITEM 15 WITH</i>		1
17	261/00202		Clamp 'U' <i>FOR ITEM 16</i>		1
18	1425/0007D		Washer Spring M8 <i>FOR ITEM 19 & 24</i>		6
19	1315/0307D		Setscrew M8 x 25 mm <i>FOR ITEM 15</i>		4
20	204/07006		Tie Cable <i>FOR FUEL HOSES & TEM</i>		3
21	204/07007		Tie cable - 100mm Long <i>STARTER MOTOR HARNES</i>		1
22	821/00481		Clip 'P' <i>ALTERNATOR HARNESS T</i>		1
23	264/36400		Plate Harness Tie <i>FIT TO CYLINDER HEAD</i>		1
24	1315/0305D		Setscrew M8 x 20mm <i>FOR ITEM 22 & 23</i>		2
27	332/U3375		Strip Edging Protection <i>FIT TO DIESEL TANK</i>		2
28	332/L4140		Drive Coupling <i>332/L4140</i>		1
29	1305/1604Z		Screw 5/16-18unc		8
30	1410/0002D		Washer WASHER 5/16in SMALL		8
31	4101/0200		Fluid Locking		1



9822/0435 L110-5-1 ENGINE ASSEMBLIES ENGINE MOUNTINGS




Item	Part #	Change No	Description	Usage Code	QTY
1	332/P0685		Bracket engine mounting left hand		1

2	331/18407		Bracket engine mount right hand		1
3	826/01288		Bolt M14 x 30 <i>FOR ITEM 1 & 2</i>		4
5	1422/0010D		Washer M14 hardened		4
6	331/18398		Mounting engine, front mount		2
7	331/18342		Bell Housing, Engine Mounting		2
8	1315/0408D		Setscrew M10 x 30		12
9	1420/0008D		Washer (M10)		32
10	1370/0303D		Nut Self Lock M10		15
12	1315/0509D		Screw M12x35mm		4
13	1422/0008D		Washer Hardened (M10)		7
14	331/17936		Housing bell contitech mounts		1
15	1315/0405D		Setscrew M10 x 20		2
16	1422/0009D		Washer Hardened (M12)		6
17	1315/3411D		Bolt M10 x 45 mm Long		1
18	1315/3412D		Bolt M10 x 50		4
19	1315/3415D		Bolt M10x65		2
21	1315/0409D		Setscrew M10 x 35mm		3



9822/0435 L190-20-1 OTHER ENGINE RELATED PARTS COUPLING CALOR,ABI




295-20191-4

Item	Part #	Change No	Description	Usage Code	QTY
1	45/915800		Coupling Q.R		1

2	816/17169		Adapter 3/8"SAE/1/4"NPT		1
3	333/T5611		Hose		1

9822/0435 L200-5-1 EXHAUST SYSTEM INSTALLATION ASSEMBLIES GROUND EMISSION




295-21034-1

Item	Part #	Change No	Description	Usage Code	QTY
1	331/45226		Silencer ground		1

2	295/00590		Cover counterweight		1
3	331/26421		Pipe Exhaust Tail		1
4	261/00202		Clamp 'U'		1



9822/0435 L200-10-1 EXHAUST SYSTEM INSTALLATION ASSEMBLIES MOUNTING GROUND EMISSION




295-20283-5

Item	Part #	Change No	Description	Usage Code	QTY
1	331/43560		Mounting Rubber		3

2	1370/0301D		Nut (M10)		6
3	1411/0004D		Washer Plain 7/16"Medium		6
4	295/00658		Bracket Silencer Mounting		1



9822/0435 L200-40-1 EXHAUST SYSTEM INSTALLATION ASSEMBLIES GROUND EMISSION




295-20313-2

Item	Part #	Change No	Description	Usage Code	QTY
1	295/00614		Convertor catalytic cat 2, diesel		1

2	200/77101		Mounting rubber		3
3	1340/0204Z		Nut Philidas Thin		6
4	1412/0003Z		Washer (3/8" Large)		6
5	295/00658		Bracket Silencer Mounting		1
6	331/26421		Pipe Exhaust Tail		1
7	261/00202		Clamp 'U'		1

JCB 9822/0435 L220-2-1 EXHAUST EXTENSION EXHAUST SUB
ASSEMBLY, ABI




Item	Part #	Change No	Description	Usage Code	QTY
1	331/47271		Pipe exhaust connection		1

2	331/44110		Pipe exhaust downpipe		1
3	813/10267		Gasket Spherical		2
4	814/10184		Spring Conical		4
5	826/11213		Bolt Flanged Shoulder		4
6	331/44102		Elbow exhaust flange		1
7	123/07745		Spacer		2



9822/0435 L300-5-1 INDUCTION SYSTEM INSTALLATION ASSEMBLIES




295-20179-2

Item	Part #	Change No	Description	Usage Code	QTY
1	32/917300		Filter Air, Assembly		1

2	32/917400		Bracket Air Cleaner Mounting		1
---	-----------	--	------------------------------	--	---



9822/0435 L300-10-1 INDUCTION SYSTEM INSTALLATION ASSEMBLIES AIR FILTER



Item	Part #	Change No	Description	Usage Code	QTY
A	32/917300		Filter Air, Assembly		1

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com