




9822/0070 B1-6-1 DIESEL TANK




Item	Part #	Change No	Description	Usage Code	QTY
1	346/00431	to AUG2013	Tank fuel		1
1	334/R2361		Tank fuel		1
1A	:816/90702		Plug 1/2"UNF with O-Ring		1

2	716/30254	to SEPT2011	Sender fuel	1
2	333/T5216		Sender fuel	1
2A	:332/C6446		Gasket fuel sender	1
2B	:331/42912		Nut coupling fuel sender	1
3	1315/3308D		Bolt M8x30mm	4
4	1420/0007D		Washer (M8)	4
5	649/51795		Hose diesel fuel <i>To sedimenter</i>	1
6	648/30504		Hose fuel return <i>return</i>	1
7	2201/0001		Clip Worm Drive 8/16mm	4
8	826/01347		Tie Cable 160mm	10
9	649/52093		Hose breather fuel	1
10	2201/0003		Clip Jubilee <i>Breather hose</i>	2
11	816/90939	to AUG2013	Adapter fir tree	1
12	834/11100		Hose Fuel Filler	1
13	2201/0015		Clip Worm Drive 78-102mm	1
14	****		'See Remark' <i>See B1-7-1 for fuel filler</i>	1



9822/0070 B1-7-1 HYDRAULIC TANK



790274


Item	Part #	Change No	Description	Usage Code	QTY
A	332/U5098		Tank hydraulic ABI		1
2	:32/904200		Strainer Suction 1 1/2BSP Thread, 63AF Hexagon		1
3	:335/11013		Plate cover/filler		1

4	:242/00178		Gasket	1
5	:123/08053		Gauge Sight 50mm	1
5A	::25/700013		O Ring	1
6	:1315/0307D		Setscrew M8 x 25 mm	8
7	:1420/0007D		Washer (M8)	8
8	:1425/0007D		Washer Spring M8 <i>No longer fitted</i>	8
9	:826/01828		Nut rivet	8
10	:32/925390		Plug Drain G1A	1
10A	::2401/0510		O Ring	1
15	:826/11316		Nut rivet with seal	4
23	1315/3410D		Bolt M10 x 40mm	2
24	1420/0008D		Washer (M10)	4
25	1370/0303D		Nut Self Lock M10	2
26	1315/3308D		Bolt M8x30mm	2
27	1420/0007D		Washer (M8)	4
28	1370/0203D		Nut Lock M8	2
29	816/90045		Cap Blanking 1/4"BSP Steel	2
30	816/90044		Cap blanking 3/8"BSP Female	1
41	332/T0671		Filler OIL FILLER WA	1
42	834/11101		Hose Hyd Oil Filler	1
43	834/11100		Hose Fuel Filler	1
44	331/17029		Filler Pressurised Breather	1
44A	:123/04056		Seal cap	1
45	265/00455		Cap filler diesel	1
45	123/05892		Cap filler, lockable supplied without key	1
45	123/06343		Seal <i>For both caps</i>	1
45	701/45501		Key Door/Ignition	1
46	2201/0014		Clip Worm Drive	2
47	2201/0015		Clip Worm Drive 78-102mm	2
48	1315/0410D		Setscrew M10 x 40mm	2
49	1420/0008D		Washer (M10)	4
50	1370/0303D		Nut Self Lock M10 <i>With item 48</i>	2
51	649/52093		Hose breather fuel	1
52	2201/0003		Clip Jubilee	2
53	270/00106		Tie Cable 385mm	3

3	1315/0205D		Setscrew M6 x 20		1
4	1420/0006D		Washer (M6)		1



9822/0070 B1-8-1 BATTERY BAY AIR DUCT




781612

Item	Part #	Change No	Description	Usage Code	QTY
1	332/V5049		Tray battery		1
2	332/S4098		Cover air duct engine		1
3	331/52974		Clamp battery		1

4	265/00680		Bolt swing		1
5	1315/0203D		Setscrew M6 x 16mm		6
7	1315/0308D		Setscrew M8 x 30 mm		3
8	1315/0305D		Setscrew M8 x 20mm		5
9	1420/0006D		Washer (M6)		13
10	1420/0007D		Washer (M8)		13
11	1370/0103D		Nut (M6)		7
12	332/T9005		Bracket fuse		1
13	1370/0203D		Nut Lock M8		5
14	926/52100	<18/01/2012	Seal bubble <i>Bottom edge of item 2 (1.35mt approx)</i>		1
14	333/T4159		Seal edge 1070mm <i>Replaces 926/52100. Cut from roll 333/T3400</i>		1
15	926/46800		Seal double bubble <i>RH side edge of item 1 (0.75mt. approx)</i>		0
16	926/19900	<18/01/2012	Seal Bubble End 2320mm		1
16	333/T4142		Seal edge 350mm <i>Replaces 926/19900. Cut from roll 333/T3400</i>		1
17	926/18900		Foam 140mm long		1
18	333/T4160	>19/01/2012	Seal edge 230mm <i>Cut from roll 333/T3400</i>		1



9822/0070 B1-9-1 FENDERS FRONT




333-R2439-1

Item	Part #	Change No	Description	Usage Code	QTY
1	835/10035		Plug Black Plastic		4
2	332/S4520		Mounting bracket		4
3	332/S4517		Fender front		2

4	265/00533		Plate back		4
5	265/00532		Plate saddle		4
6	1420/0007D		Washer (M8)		12
7	1411/0004D		Washer Plain 7/16"Medium		16
8	1370/0303D		Nut Self Lock M10		16
9	1315/0408D		Setscrew M10 x 30		16
10	1315/0307D		Setscrew M8 x 25 mm		12
11	1420/0008D		Washer (M10)		16



9822/0070 B1-10-1 FENDERS REAR AND STEPS




922872

Item	Part #	Change No	Description	Usage Code	QTY
1	332/S2629		Fender rear left side		1
2	332/S2633		Fender rear right side		1
3	332/S3016		Bracket LH fender		1

4	332/T3244	to 30/11/2010	Step left side		2
4	333/S4744		Step left side		2
5	1315/0308D		Setscrew M8 x 30 mm		4
6	1315/0309D		Setscrew M8 x 35 mm		9
7	1315/0409D		Setscrew M10 x 35mm		2
8	1315/0509D		Screw M12x35mm		5
9	1315/0510D		Setscrew M12 x 40mm		3
10	1370/0203D		Nut Lock M8		4
11	1370/0403D		Nut Lock M12		6
12	1420/0008D		Washer (M10)		2
13	1420/0009D		Washer (M12)		10
14	1411/0002D		Washer 5/16in medium		4
15	1412/0002D		Washer (5/16" Large)		13
16	1412/0005D		Washer (1/2" Large)		4
17	926/43207		Foam strip 25 x 25 x 135 long <i>Cut from 926/43201 - 420mm long</i>		2



9822/0070 B1-10-2 FENDERS REAR AND STEPS




Item	Part #	Change No	Description	Usage Code	QTY
1	332/S2629		Fender rear left side		1
2	332/S2633		Fender rear right side		1
3	332/S3016		Bracket LH fender		1

4	333/S3218		Step left side (Aluminium)		2
5	1315/0308D		Setscrew M8 x 30 mm		4
6	1315/0309D		Setscrew M8 x 35 mm		9
7	1315/0409D		Setscrew M10 x 35mm		2
8	1315/0509D		Screw M12x35mm		1
9	1315/0510D		Setscrew M12 x 40mm		5
10	1370/0203D		Nut Lock M8		4
11	1370/0403D		Nut Lock M12		6
12	1420/0008D		Washer (M10)		2
13	1420/0009D		Washer (M12)		10
14	1411/0002D		Washer 5/16in medium		4
15	1412/0002D		Washer (5/16" Large)		13
16	1412/0005D		Washer (1/2" Large)		4
17	926/43207		Foam strip 25 x 25 x 135 long <i>Cut from 926/43201 - 420mm long</i>		2
18	1315/0511D		Setscrew M12 x 45mm		2



9822/0070 B1-12-1 COUNTERWEIGHT REAR




922880

Item	Part #	Change No	Description	Usage Code	QTY
1	332/T6006		Counterweight		1
2	332/S5552		Plate light mounting		2
3	332/U6627		Bracket mounting		1

4	332/W0227		Plate WA		2
5	703/05800		Reflector red		2
6	1315/4031D		Bolt M24 x 220		4
7	1315/4030D		Bolt		1
8	1420/0014D		Washer (M24)		5
9	1315/0307D		Setscrew M8 x 25 mm		6
10	1420/0007D		Washer (M8)		8
11	826/00872		Screw M5 x 16		2
20	332/S8682		Pin assembly		1



9822/0070 B1-14-1 MOUNTINGS FRONT LIGHTS




333-R2450-1

Item	Part #	Change No	Description	Usage Code	QTY
1	332/T5349	to 03/07/2011	Mounting front light right side		1
1	333/T8145		Mounting front light right side		1
2	332/T5348	to 03/07/2011	Mounting front light left side		1

2	333/T8143		Mounting front light left side		1
3	332/S8155		Plug light mounting tube		2
4	1420/0007D		Washer (M8)		6
5	1315/0307D		Setscrew M8 x 25 mm		6



9822/0070 B1-15-1 ENGINE COVER



790484

Item	Part #	Change No	Description	Usage Code	QTY
A	332/W3467	to NOV2010	Cover engine ABI (w/o JCB logo recess)		1
A	333/S1436		Cover engine ABI <i>Additional fasteners for soundproofing</i>		1

1	1315/0408D		Setscrew M10 x 30	4
2	1370/0203D		Nut Lock M8	8
3	1412/0003D		Washer (3/8" Large)	4
4	1420/0007D		Washer (M8)	8
5	1420/0008D		Washer (M10)	16
6	331/55321		Strut gas	2
7	332/R2619		Screw shoulder	8
8	332/R3411		Hinge bonnet mounting	1
9	332/R3428		Link	2
10	332/R3429		Link	2
11	332/S4277		Bracket mounting left side	1
12	332/S5849		Bracket mounting right side	1
13	332/S6120		Plate support	1
14	1315/0305D		Setscrew M8 x 20mm	8
15	1420/0007D		Washer (M8)	8
21	1315/0303D		Setscrew M8 x 16mm	4
22	1315/0309D		Setscrew M8 x 35 mm	4
23	1370/0203D		Nut Lock M8	2
24	1420/0007D		Washer (M8)	4
25	1420/0007D		Washer (M8)	10
26	290/00812		Lock left side,	1
27	332/U8713		Panel bonnet rest beam <i>Includes tool stowage bracket</i>	1
28	335/10086		Bracket latch mounting	1
29	123/04067		Handle Barrel Lock Only	1
30	826/11118		Screw M8 x 35 C/Sunk Hex Head-Black	2
31	701/45501		Key Door/Ignition	1
32	4101/0251		Sealant Threadlock 50ml	0
33	331/53222		Bracket striker mounting	1
34	1315/3418D		Bolt M10 x 80	1
35	265/00589		Buffer Rubber	2
36	926/19900		Seal Bubble End 2320mm <i>4100mm long (replaces 904/20360)</i>	0
36A	926/46800		Seal double bubble <i>520mm long</i>	0
37	904/20360		Seal <i>require 1 x 940mm long (approx)</i>	0
40	1315/0212D		Screw	2
40A	1420/0006D		Washer (M6)	2
41	1315/0408D		Setscrew M10 x 30	2
42	1370/0302D		Nut thin	2
43	1420/0008D		Washer (M10)	4
44	826/11491		Screw panhead M6 x 40	1

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com