




9802/4710 U42-1-1 ENGINE MOUNTINGS




846590

Item	Part #	Change No	Description	Usage Code	QTY
1	7222/50111		Bracket		2
2	4033/26103		Washer		2
3	7242/50181		Washer		1

10	2622/50035		Pad		3
11	2021/10020		Screw Hexagon M10x20		12
12	2201/00010		Washer M10		12
16	2020/16100		Screw		3
18	2201/00016		Washer M16		8
20	2021/12035		Screw Hex M12x35		8
21	2201/00012		Washer M12		8
22	2118/31600		Nut M16		2
30	4029/69097		Strap		1
31	2021/06016		Screw M6 x 16		1



9802/4710 U42-2-1 ENGINE FRONT SUPPORT




846970

Item	Part #	Change No	Description	Usage Code	QTY
1	7242/50812		Screw		2
2	7242/50813		Screw		2
3	7242/50815		Mounting front engine support		1



9802/4710 U43-1-1 AIR FILTERS




Item	Part #	Change No	Description	Usage Code	QTY
A	7222/50250		Filter air		1
1	****		'See Remark' <i>Housing</i>		1

2	:7222/50252		Element Outer		1
3	:7222/50253		Element Inner		1
4	:7222/50255		Ring		1
5	:4011/22043		Valve dust		1
6	:7222/50251		Cap filter		1



9802/4710 U43-2-1 FILTER PRE-CLEANER




949140

Item	Part #	Change No	Description	Usage Code	QTY
0	8722250340		Cleaner Air Pre-Cleaner Kit Use On VM75-VM115 <i>Includes Items 1,4,5,10,11 & 15</i>		1
1	:7242/50341		Filter pre-cleaner assembly		1

4	:7242/50344		Screw Thread Border		2
5	:7222/50345		Cover hood		1
10	:2021/08030		Screw Hex M8 x 30		6
11	:2201/00008		Washer M8		6
15	:9602/00020		Sealant Transparent		0



9802/4710 U44-1-1 AIR INDUCTION HOSES & MOUNTINGS




846600

Item	Part #	Change No	Description	Usage Code	QTY
1	7222/50250		Filter air <i>For components see U43-1-1</i>		1
2	7222/50260		Bracket		1

4	7242/50263		Switch		1
5	7232/50325		Bracket		1
6	7221/53123		Sleeve		1
7	7232/50315		Elbow rubber		1
8	7232/50316		Hose		1
11	7221/50041		Bracket		1
12	7232/50312		Spacer tube		1
15	2322/00080		Clamp		5
20	2021/10040		Screw M10 x 40		3
21	2201/00010		Washer M10		3
24	2021/08025		Screw Hexagon M8x25		2
25	2021/08040		Screw Hexagon M8 x 40		2
26	2118/30800		Nut M8		4
27	2201/00008		Washer M8		8



9802/4710 U45-1-1 EXHAUST SYSTEM




845520

Item	Part #	Change No	Description	Usage Code	QTY
1	7222/50363		Silencer Muffler		1
2	7232/50334		Pipe Exhaust		1
5	7222/50335		Bracket air cleaner mounting		1

10	7232/50331		Hose		1
14	7250/60037		Clamp		1
15	2503/10083		Clamp		2
20	2027/10040		Screw		3
21	2209/00010		Washer M10		3
25	2021/08030		Screw Hex M8 x 30		4
26	2201/00008		Washer M8		4



9802/4710 U48-1-1 COOLER,INSTALLATION




846550

Item	Part #	Change No	Description	Usage Code	QTY
10	7222/51275		Cooler		1
11	7232/51150	Superseded	Box cooler < s/n 1802118		1

11	7232/51160	Frame Cooler > s/n 1802119	1
16	7242/51160	Baffle intermediate wall	1
17	7232/51165	Bracket	1
18	7232/51166	Bracket	1
19	4033/26103	Washer	2
20	7242/51167	Strip sealing	2
21	7242/51168	Strip sealing	1
22	7242/51169	Strip sealing	1
25	2622/07025	Buffer	2
26	2622/21050	Bumper Rubber	2
34	2028/08020	Screw Countersunk M8 x 20mm	2
35	2021/10025	Screw Hexagon M10x25	2
36	2200/00010	Washer	8
37	2118/31000	Nut M10	6
38	2021/12025	Screw	8
39	2200/00013	Washer M12	8
41	2021/08020	Screw Hexagon M8x20	5
43	2201/00008	Washer M8	8
50	4034/40508	Seal 2500mm long	1
51	2782/01015	Seal 2000mm long	1
55	2779/03029	Plug	2



9802/4710 U48-1-2 COOLER,INSTALLATION




332-N2038-2

Item	Part #	Change No	Description	Usage Code	QTY
10	332/N1140		Cooler		1
15	7232/51160		Frame Cooler		1
16	7242/51160		Baffle intermediate wall		1

17	7232/51165		Bracket		1
18	7232/51166		Bracket		1
19	4033/26103		Washer		2
20	7232/51224		Strip Rubber		2
21	7232/51225		Strip Rubber 24x40x620		1
22	7232/51226		Strip Rubber 24x60x230		2
23	7232/51227		Strip Rubber 24x60x760		1
25	2622/07025		Buffer		2
26	2622/21050		Bumper Rubber		2
34	2028/08020		Screw Countersunk M8 x 20mm		2
35	1315/0407Z		Setscrew M10 x 25 mm		2
36	2200/00010		Washer		8
37	2118/31000		Nut M10		6
38	1315/0507Z		Setscrew M12 x 25		8
39	2200/00013		Washer M12		8
41	1315/0305Z		Setscrew M8 x 20		5
43	2200/01508		Washer		5
50	7232/51249		Hose Radiator, Right		1
51	7232/51248		Hose Hose, Left		1
52	7232/51252		Hose		1
55	7232/51255		Pipe		1
56	7232/51258		Pipe		1
60	2201/0012	Superseded	Clip Jubilee, 46/70mm		10
60	2201/0012		Clip Jubilee, 46/70mm	3	6
61	2201/0014	Superseded	Clip Worm Drive		2
61	2205/0004		Clamp T-Bolt Spring Loaded	3	2
62	2205/0002		Clamp 'T' bolt Spring Loaded	3	4
70	332/N1989		Hose air		1
71	7232/51271		Hose		1
72	332/N1988		Hose air		1
100	4034/40508		Seal		2
101	2782/01015		Seal		2
102	2779/03029		Plug		2



9802/4710 U48-2-1 RADIATOR HOSES




846570

Item	Part #	Change No	Description	Usage Code	QTY
25	7242/50144		Hose		1
26	7242/50145		Hose		1
27	7242/50146		Hose		1

28	7232/50148		Pipe		1
29	2322/00064		Clamp		6
30	2503/10550		Clamp		2
31	2021/10012		Screw Hex M10x12		2
32	2200/00510		Washer		2



9802/4710 U48-3-1 WATER TANK



846620

Item	Part #	Change No	Description	Usage Code	QTY
1	7242/51290		Tank		1
1A	:2612/00008		Indicator oil level Sight Glass		2
2	2021/08020		Screw Hexagon M8x20		2

3	2201/00008		Washer M8		2
4	2021/10021		Screw <i>2021/10021</i>		2
5	2200/00010		Washer		2
6	2880/51080		Hose <i>1700mm long</i>		1
7	2322/01209		Clamp		9
8	2503/06115		Clamp		1
9	2021/06016		Screw M6 x 16		1
10	2118/30600		Nut M6		1
11	2201/00006		Washer M6		1
12	2883/00080		Hose 1100mm <i>1000mm long</i>		1
14	2514/09602		Adapter		1
15	2322/00021		Clip		10
16	2880/51100		Hose <i>35mm long</i>		1
20	4010/40510		Cap		1
21	332/H3564		Indicator water level		1

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com