

Tractors

60-94 65-90

72-94 82-94

88-94 Turbo

06910269

Reprinted

OPERATOR'S MANUAL



NEW HOLLAND

New Holland. One exclusive vocation: Agriculture.

New Holland stands today for the most complete and exhaustive line of agricultural machinery products on the market.

New Holland sums up all the image and prestige of the trademarks representing it out in the field: tractors, combine harvesters, hay and forage harvesting machines

and grape harvesters.

That is why New Holland, with the most complete and advanced full-line in Europe, is a real specialist, responsible for the design, engineering, manufacturing and marketing of all of its product lines.

Experience, tradition and

constant innovation are the major features which have made possible for the New Holland products to become undisputed, foreline protagonists on the world scene, with the achievement of outstanding records and leading positions which are best witnessed by the constant preference accorded by farmers.

FIATAGRI 60-94 65-94 72-94 82-94
88-94 Turbo

OPERATION

MAINTENANCE

SPECIFICATIONS



WORK SAFELY – ALWAYS



This symbol alerts you about important messages involving your safety.

Read these messages carefully and strictly follow suggested precautions, designed to prevent any potential danger and safeguard your health and personal safety.

You will find, throughout this manual, the above symbol associated with the following keywords:

CAUTION – A warning intended to avoid any potential damage to the machine with possible repercussions on the operator' safety.

DANGER – Associated with warnings of specific potential danger for the operator or to the personal safety of other people, directly or indirectly involved.



IMPORTANT NOTICES




Your tractor was designed and manufactured specifically and solely for agricultural use.

Any other application will be considered not compatible with the use envisaged by the Manufacturer, who consequently cannot be held responsible for any damage to things or to the machine itself or for any physical injury to people deriving from uses other than agricultural ones. It should be considered that with the improper use one would also assume the personal responsibility for the consequences associated with it. The respect of the rules of tractor operation, maintenance and repairs described in this manual is the essential element qualifying the use of the machine as envisaged by its Manufacturer.


This machine must be used, serviced or repaired only by people previously instructed on its features as a working tool and associated safety rules and duly authorized to operate it. The user of the machine is always responsible for the strict observance of the general safety and accident prevention rules as well of the traffic regulations if driving on public or open roads.

Any un-authorized and arbitrary modification made on this machine will relieve the Manufacturer of all responsibilities for any deriving damage or physical injury. The Manufacturer and all the Organisations associated with its distribution network, including but not limited to national, regional or local distributors, decline any and all responsibilities for damages that may derive from the abnormal operation and performance of machine parts and/or components not specifically authorized for use by the Manufacturer, including the ones used for the maintenance and/or repair of products fabricated and distributed by the Manufacturer. In any case, no warranty of any sort is issued or prescribed, regarding products fabricated or distributed by the Manufacturer, covering damages deriving from the abnormal operation and performance of unauthorized parts and/or components.



A. Lift lever from ground (location: rear, on the right fender).



B. P.T.O. shaft (location: rear, on the left fender).



SAFETY DECALS


The decals on the side were installed on the tractor as shown in the picture here below.

Keep the decals clean and well legible. If they are not, obtain replacement from your authorized dealer.



C. P.T.O. clutch control lever (location: inside the cab, on the left fender).

D. Tractor in parking version HI-LO (location: inside the cab, on the left fender).





23679

Service

An extended network of **Dealers**, equipped with all the necessary means to perform servicing, repair and overhauling work, is at your disposal.

Call on your Fiatagri Dealer in full confidence. You will find a specialized and experienced service staff fully prepared to help you solve any problem related to the operation and use of your tractor.

Spare parts

Use genuine NEW HOLLAND spare parts only to ensure optimum operation of all of your tractor's parts and components.

When ordering, please always quote the following machine identification data (page 7):

- Tractor Model and Chassis serial Number.*

- Engine Type and serial Number.*

- Catalog Part Number of the spare on order.*

Maintenance

Your tractor was designed with its future owner in mind and all efforts were made to simplify its maintenance.

Indications given in this manual are for your guidance, to remind you of minor interventions necessary to ensure proper operation of your tractor.

Remember that time spent on maintenance extends the life of your machine.

Pay special attention to instructions covering fuel filters, air cleaner maintenance and lubrication in general.


Poorly filtered fuel leads to quick deterioration of the injection system and poor air cleaner maintenance can result in premature engine wear; as for lubrication, it should be noted that the oil change at 200 work hours corresponds to an oil change every 8000 to 9000 km (5000 to 5500 miles) for a highway truck or lorry.

Spares and after-sales service always close at hand


When you buy a Fiatagri agricultural machine, you also get something that does not catch the eye, but may well prove its worth in the future: the New Holland's large and efficient after-sales service and spare parts Organization, one of the largest in the agricultural machinery industry. At the central distribution warehouse, at San Matteo (Modena), a highly modern installation extending over 32,000 square meters under roof

and equipped with advanced electronic handling and retrieval systems, a total of 21 million spare parts and more than 220,000 line items are held in store. The Centre can handle up to 6,000 orders per day.


Together with efficient organization and prompt service, the superior quality of genuine New Holland spare parts assure a permanent value in time for all Fiatagri's agricultural machines.




Tractor identification data




A = Chassis type and serial number.



B = Chassis identification and engine type data plate.



C = Engine type and serial number.



Safety precautions

GENERAL

■ Your tractor was designed with safety very much in mind. However, there is no real substitute for caution and attention in preventing accidents. Once an accident has happened it is too late to think about what you should have done.

■ Read this manual carefully before attempting to start, operate, service, refuel and supply or proceed to any other action on the tractor. A few minutes dedicated to reading will save time and trouble later.

■ Read completely all the safety decals on your machine and make sure to abide to and apply all the rules thereof before starting, operating, refueling and supplying or carrying on maintenance operations on the machine. Promptly replace any damaged or missing decals.

■ Some of the parts installed on your machine, such as engine gaskets, may contain asbestos-base materials.

Packagings containing spares of these parts are labelled with this warning signal:




Inhaling asbestos powder is dangerous to health. When handling and working on parts containing asbestos, always take the following precautions:

- Work in open premises.
- Any asbestos powder found on the machine or produced when working on the same must be eliminated by extraction methods, never by dusting, blowing or brushing.
- Asbestos powder residues must be completely dampened and put inside properly identified containers to make sure of their safe disposal.
- Should parts containing asbestos require processing by cutting, drilling or grinding, they should be dampened in the first place and then processed using exclusively hand tools or power tools operated at low speed.

■ Remember that your tractor was designed and built for agricultural use only. Any other application must be preventively authorized by the Manufacturer.

■ It is advisable to keep a first aid kit handy.

■ Do not wear loose garments that could be caught in moving parts. Check that all turning parts connected to the power take-off shaft are well shielded.



Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com