


Cougar Tiger Tractor

Operator's Manual

Reprinted

37-002




CASE III



If Safety Decals on this machine use the words **Danger, Warning or Caution**, which are defined as follows:

- **DANGER:** Indicates an immediate hazardous situation which if not avoided, will result in death or serious injury. The color associated with Danger is RED.
- **WARNING:** Indicates a potentially hazardous situation which if not avoided, will result in serious injury. The color associated with Warning is ORANGE.
- **CAUTION:** Indicates a potentially hazardous situation which if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices. The color associated with Caution is YELLOW.

If Safety Decals on this machine are ISO two panel Pictorial, decals are defined as follows:

- The first panel indicates the nature of the hazard.
- The second panel indicates the appropriate avoidance of the hazard.
- Background color is YELLOW.
- Prohibition symbols such as   and  if used, are RED.



WARNING

IMPROPER OPERATION OF THIS MACHINE CAN CAUSE INJURY OR DEATH. BEFORE USING THIS MACHINE, MAKE CERTAIN THAT EVERY OPERATOR:

- Is instructed in safe and proper use of the machine.
- Reads and understands the Manual(s) pertaining to the machine.
- Reads and understands ALL Safety Decals on the machine.
- Clears the area of other persons.
- Learns and practices safe use of machine controls in a safe, clear area before operating this machine on a job site.

It is your responsibility to observe pertinent laws and regulations and follow Case Corporation instructions on machine operation and maintenance.



Warranty

Steiger Tractor, Inc. (Steiger) warrants, to the original purchaser only, each new Steiger Tractor to be free from defects in material and workmanship under normal use and service, subject to the conditions and qualifications herein set forth. The obligation of Steiger hereunder is limited to the repair or replacement of those parts which Steiger, in its sole discretion, determines to have failed as a result of defects in material or workmanship within twelve months or 1500 hours of use, whichever occurs first, after delivery to the original purchaser. Steiger's obligation hereunder shall in no case be greater than the cost of the necessary parts and labor which Steiger, in its sole discretion, determines to have failed as a result of defect in material or workmanship.

Steiger shall not be liable for any costs other than those specified herein, specifically excluding damage to crop, loss of use, transportation expense to an authorized Steiger dealer, service calls, normal maintenance and upkeep cost, overtime labor cost, and any and all other injuries, damages or expenses incidental or consequential to the defects covered by this warranty. Also this warranty does not extend to tires, tubes, radios, batteries, air conditioners and like accessories not manufactured by Steiger.

NO WARRANTY of MERCHANTABILITY or FITNESS for USE is made. This is the sole warranty applicable to Steiger Tractors, exclusive of any and all other warranties, whether written, oral or implied. No dealer, salesman or agent has any authority to alter or amend this warranty nor does any dealer, salesman or agent make any warranty for himself unless the same is reduced to writing and delivered to the purchaser at the time of purchase.

This warranty shall be effective only if the purchaser requests warranty repairs to be made by an authorized Steiger dealer at his place of business and, if requested by such dealer, the purchaser presents evidence of the date of delivery of the equipment. This warranty shall not apply unless Steiger or one of its dealers is promptly notified of claimed defect and the allegedly defective part is preserved for inspection.

This warranty shall immediately become void if any service, other than normal maintenance, is performed by anyone other than an authorized Steiger dealer; or if any alteration or modification is made without the prior written consent of Steiger; or if, in Steiger's sole discretion, the failure is due to abuse of neglect in the operation or Maintenance of the tractor or due to failure to follow the provisions of the operator's manual.

IMPORTANT

THIS WARRANTY SHALL IMMEDIATELY BECOME VOID IF DELIVERY NOTIFICATION FOR WARRANTY IS NOT MAILED IMMEDIATELY UPON COMPLETION OF SALE.

Pre-Delivery Check

Date _____

Dealer Name _____

Customer's Name _____

Address _____

Address _____

Model _____

Engine Model _____

Serial No. _____

Serial No. _____

CAB APPEARANCE

- _____ Window glass
- _____ Door latches
- _____ Weather stripping
- _____ Vinyl covering
- _____ Seat
- _____ Floor carpet

ENGINE

- _____ Coolant level
- _____ Oil level
- _____ Oil filters
- _____ Fuel filters
- _____ Fuel lines
- _____ Throttle linkage
- _____ Idle speed
- _____ Belts

DRIVE SHAFTS

- _____ U-Joints

INSTRUMENTATION

- _____ Engine Temperature gauge
- _____ Engine oil pressure gauge
- _____ Ammeter
- _____ Light switches
- _____ Tachometer
- _____ Fuel gauge
- _____ Transmission Temperature gauge
- _____ Hour meter
- _____ Fuel pressure gauge
- _____ Windshield Wipers
- _____ Safety Shut-down
- _____ Cab air switch
- _____ Cab air vent
- _____ Cab light
- _____ Air conditioner
- _____ Radio

CLUTCH

- _____ Operation
- _____ Adjustment

ELECTRICAL SYSTEM

- Alternator
- Battery
- Wiring
- Lights
- Safety-shut-down
- Battery Connections

TRANSMISSION

- Operation (gear & range selector)
- Oil level
- Oil filter
- Oil leaks
- Flange bolts
- Mounts

POWER DIVIDER

- Oil level
- Flange bolts
- Mounts
- Swing Mounts

AXLES

- Oil level (differential)
- Oil level (Planetary hubs)
- Wheel lug bolts & nuts
- Tire pressures and size

BRAKES

- Operation
- Park brake
- Fluid level
- Fluid lines

HYDRAULICS

- Fluid level
- Filters
- Operation
- Valves
- 3-Points hitch operation
- Cylinders, Implement
- Cylinders, Steering
- Hose Couplers
- Pump
- Hose Connections

UPON COMPLETION, MAIL TO THE SERVICE DEPARTMENT OF STEIGER TRACTOR INC.

Comments:

250 Hour Check

Dealer Name _____

Customer's Name _____

Address _____

Address _____

Model _____

Serial No. _____

Engine Model _____

Serial No. _____

Hours _____

Date _____

ENGINE:

- ____ Engine idle
- ____ Engine RPM
- ____ Timing
- ____ Throttle linkage
- ____ Throttle lever
- ____ Oil pressure
- ____ Fuel pump
- ____ Fuel pressure
- ____ Head Bolts
- ____ Temp. gauge
- ____ Fuel lines
- ____ Clutch adjustment
- ____ Fuel filters

BRAKES:

- ____ Line leaks
- ____ Fluid

TRANSMISSION:

- ____ Leaks
- ____ Filter
- ____ Oil level
- ____ Transmission Mount
- ____ U joints
- ____ Drive shaft
- ____ Flange bolts

POWER DIVIDER:

- ____ Oil level
- ____ Seal leaks
- ____ U joints

DIFFERENTIAL:

- ____ Oil level
- ____ Mount bolts
- ____ Drive line joints

HYDRAULIC SYSTEM:

- ____ Pump operation
- ____ Control valves
- ____ Pump couplers
- ____ Pump mount
- ____ Steering cylinders

ELECTRICAL SYSTEM:

- ____ Battery performance
- ____ Alternator performance
- ____ Amp. gauge
- ____ Hour meter
- ____ Lights and wires
- ____ Fuel gauge
- ____ Fuel sender

FRAME:

- ____ Hinge pins

UPON COMPLETION MAIL TO THE SERVICE DEPARTMENT OF STEIGER TRACTOR INC.

Failure to complete this form will result in a void warranty.

Customers Signature _____

COMMENTS _____

Buy Now



Our support email:

ebooklibonline@outlook.com