


Page Number	Page Title	Page Reference
01-0001	ENGINE INSTALLATION	LC03L008-1
01-0002	ENGINE INSTALLATION	LC03L012-1
01-0003	ENGINE INSTALLATION - FAN	LC03L011-1
01-0004	ENGINE INSTALLATION - BELT TENSIONER	LC03L010-1
01-0005	ENGINE INSTALLATION - ENGINE BRACKET	LC03L009-1
01-0006	ENGINE	LC03L007-1
01-0007	ENGINE	HB01L001-1
01-0008	ENGINE - CYLINDER-BLOCK - 74CTA-4V ENGINE - UP TO ENGINE NUMBER S1630	HB02L001-1
01-0009	ENGINE - CYLINDER-BLOCK - 74CTA-4V ENGINE - FROM ENGINE NUMBER S1631	HB02L004-1
01-0010	ENGINE - TIMING GEAR HOUSING - 74CTA-4V ENGINE - UP TO ENGINE NUMBER S1630	HB03L001-1
01-0011	ENGINE - TIMING GEAR HOUSING - 74CTA-4V ENGINE - FROM ENGINE NUMBER S1631	HB03L004-1
01-0012	ENGINE - FLYWHEEL & FLYWHEEL HOUSING	HB04L001-1
01-0013	ENGINE - CRANKSHAFT, PISTONS & PISTON ROD - 74CTA-4V ENGINE - UP TO ENGINE NUMBER S1630	HB05L001-1
01-0014	ENGINE - CRANKSHAFT, PISTONS & PISTON ROD - 74CTA-4V ENGINE - FROM ENGINE NUMBER S1631	HB05L004-1
01-0015	ENGINE - INTAKE VALVE, EXHAUST VALVE & CAMSHAFT - 74CTA-4V ENGINE - UP TO ENGINE NUMBER S1630	HB06L001-1
01-0016	ENGINE - INTAKE VALVE, EXHAUST VALVE & CAMSHAFT - 74CTA-4V ENGINE - FROM ENGINE NUMBER S1631	HB06L002-1
01-0017	ENGINE - CYLINDER HEAD - 74CTA-4V ENGINE - UP TO ENGINE NUMBER S1630	HB08L001-1
01-0018	ENGINE - CYLINDER HEAD - 74CTA-4V ENGINE - FROM ENGINE NUMBER S1631 / UP TO ENGINE NUMBER T9823	HB07L002-1
01-0019	ENGINE - CYLINDER HEAD - 74CTA-4V ENGINE - FROM ENGINE NUMBER T9824	HB07L003-1
01-0020	ENGINE - INTAKE & EXHAUST MANIFOLD - 74CTA-4V ENGINE - UP TO ENGINE NUMBER S1630	0305L001-1
01-0021	ENGINE - INTAKE & EXHAUST MANIFOLD - 74CTA-4V ENGINE - FROM ENGINE NUMBER S1631	HB19L002-1
01-0022	ENGINE - TURBOCHARGER - 74CTA-4V ENGINE - UP TO ENGINE NUMBER S1630	0650L001-1
01-0023	ENGINE - TURBOCHARGER - 74CTA-4V ENGINE - FROM ENGINE NUMBER S1631	0650L003-1
01-0024	ENGINE - OIL SUMP - 74CTA-4V ENGINE - UP TO ENGINE NUMBER S1630	HB10L001-1
01-0025	ENGINE - OIL SUMP - 74CTA-4V ENGINE - FROM ENGINE NUMBER S1631	HB10L003-1
01-0026	ENGINE - OIL COOLER - 74CTA-4V ENGINE - UP TO ENGINE NUMBER S1630	1465L001-1
01-0027	ENGINE - OIL COOLER - 74CTA-4V ENGINE - FROM ENGINE NUMBER S1631	1465L002-1
01-0028	ENGINE - CENTRIFUGAL OIL FILTER	LD98L002-1
01-0029	ENGINE - WATER PUMP - 74CTA-4V ENGINE - UP TO ENGINE NUMBER S1630	HB45L001-1
01-0030	ENGINE - WATER PUMP - 74CTA-4V ENGINE - FROM ENGINE NUMBER S1631	HB45L003-1
01-0031	ENGINE - INJECTION PUMP - 74CTA-4V ENGINE - UP TO ENGINE NUMBER S1630	HB16L001-1
01-0032	ENGINE - INJECTION PUMP - 74CTA-4V ENGINE - UP TO ENGINE NUMBER S1630	HB17L001-1
01-0033	ENGINE - INJECTION PUMP - 74CTA-4V ENGINE - FROM ENGINE NUMBER S1631	HB16L003-1
01-0034	ENGINE - FUEL FILTER - 74CTA-4V ENGINE - UP TO ENGINE NUMBER S1630	HB18L001-1
01-0035	ENGINE - FUEL FILTER - 74CTA-4V ENGINE - FROM ENGINE NUMBER S1631	HB18L004-1
01-0036	ENGINE - ELECTRONIC ENGINE MANAGEMENT (EEM) - 74CTA-4V ENGINE - UP TO ENGINE NUMBER S1630	HB48L001-1
01-0037	ENGINE - ELECTRONIC ENGINE MANAGEMENT (EEM) - 74CTA-4V ENGINE - FROM ENGINE NUMBER S1631	HB48L003-1
01-0038	ENGINE - STARTER MOTOR - 74CTA-4V ENGINE - UP TO ENGINE NUMBER S1630	HB25L001-1
01-0039	ENGINE - STARTER MOTOR - 74CTA-4V ENGINE - FROM ENGINE NUMBER S1631 / UP TO ENGINE NUMBER U1000	HB25L002-1
01-0040	ENGINE - STARTER MOTOR - 74CTA-4V ENGINE - FROM ENGINE NUMBER U1001	HB25L003-1
01-0041	ENGINE - ALTERNATOR & FITTING BRACKET - 74CTA-4V ENGINE - UP TO ENGINE NUMBER S1630	HB24L001-1
01-0042	ENGINE - ALTERNATOR & FITTING BRACKET - 74CTA-4V ENGINE - FROM ENGINE NUMBER S1631	HB24L004-1
01-0043	ENGINE - REPAIR KIT - 74CTA-4V ENGINE - UP TO ENGINE NUMBER S1630	HB31L001-1
01-0044	ENGINE - REPAIR KIT - 74CTA-4V ENGINE - FROM ENGINE NUMBER S1631	HB31L004-1
01-0045	ENGINE - JOINTS AND GASKETS - 74CTA-4V ENGINE - UP TO ENGINE NUMBER S1630	HB28L001-1
01-0046	ENGINE - JOINTS AND GASKETS - 74CTA-4V ENGINE - FROM ENGINE NUMBER S1631	HB28L004-1
01-0047	COOLING SYSTEM	LC60L011-1
01-0048	COOLING SYSTEM	LC60L012-1
01-0049	COOLING SYSTEM	LC60L013-1
01-0050	COOLING SYSTEM - RADIATOR & ATTACHMENTS	LC60L014-1
01-0051	COOLING SYSTEM - RADIATOR (COMPONENTS) - UP TO SERIAL NUMBER 552310048 / 552410026 AL	LC60L001-1
01-0052	COOLING SYSTEM - RADIATOR (COMPONENTS)	LE18L002-1
01-0053	COOLING SYSTEM - RADIATOR (COMPONENTS)	LE18L003-1
01-0054	COOLING SYSTEM - UP TO SERIAL NUMBER 552310048 / 552410026 AL	LC60L015-1
01-0055	COOLING SYSTEM - FROM SERIAL NUMBER 552310049 / 552410027 AL	LC60L023-1
01-0056	COOLING SYSTEM	LC60L016-1
01-0057	COOLING SYSTEM	LC60L017-1
01-0058	COOLING SYSTEM	LC60L018-1


<b>Page Number</b>	<b>Page Title</b>	<b>Page Reference</b>
01-0059	COOLING SYSTEM - ROTARY SCREEN	LC60L010-1
01-0060	DUST ASPIRATOR	LC63L004-1
01-0061	DUST ASPIRATOR	LC63L005-1
01-0062	DUST ASPIRATOR	LC63L006-1
01-0063	ENGINE COMPARTMENT - SERVICE HATCH	1985265
01-0064	ENGINE COMPARTMENT - SERVICE HATCH	1985266
01-0065	ENGINE AIR FILTER	LC57L002-1
01-0066	EXHAUST SYSTEM	LC58L002-1
01-0067	FUEL SYSTEM - FUEL TANK & ATTACHMENTS - UP TO SERIAL NUMBER 552310097 / 552410054 AL	LC59L003-1
01-0068	FUEL SYSTEM - FUEL TANK & ATTACHMENTS - FROM SERIAL NUMBER 552310098 / 552410055 AL	LC59L006-1
01-0069	FUEL SYSTEM - FUEL TANK BRACKET - UP TO SERIAL NUMBER 552310097 / 552410054 AL	LC59L004-1
01-0070	FUEL SYSTEM - FUEL TANK BRACKET - FROM SERIAL NUMBER 552310098 / 552410055 AL	LC59L007-1

8015452-L-A



Item	Part Number	Qty	Description Comments	Technical Specification
1	LA10186490	2	HOSE CLIP	?10-12 MM
2	LA10186690	6	HOSE CLIP	?12-14 MM
3	LA12034571	1	SPRING WASHER	M8
4	LA14457180	1	O-RING	?13,95 X 2,62 MM
5	LA16043221	1	HEXAGONAL HEAD BOLT	M8 X 16 ISO 8.8 IF
6	LA16043421	1	HEXAGONAL HEAD BOLT	M8 X 20 (1.25) ISO 8.8 IF
7	LA16104111	1	LOCKNUT	M8 ISO
8	LA19053182	1	HOSE UP TO SERIAL NUMBER 552310266 UP TO SERIAL NUMBER 552410122 AL	
9	LA300128295	1	PIPE UNION	M22 (1.5)
10	LA300136355	1	FILLER	
11	LA320479650	1	PLUG	
12	LA321806450	1	FILLER	
13	LA321946550	3	FILLER	
14	LA321946650	1	PLUG	
15	LA322303850	2	WATER HOSE UP TO SERIAL NUMBER 552310266 UP TO SERIAL NUMBER 552410122 AL	L = 6600 MM
	LA322303850	1	WATER HOSE FROM SERIAL NUMBER 552310267 FROM SERIAL NUMBER 552410123 AL	L = 6600 MM
	LA322303650	1	WATER HOSE FROM SERIAL NUMBER 552310267 FROM SERIAL NUMBER 552410123 AL	L = 6000 MM
16	LA322310850	2	COCK	
17	LA322327850	1	WATER HOSE	L = 4500 MM
18	LA322638350	1	TANK CAP	
19	LA322731950	1	SEALING WASHER	
20	LA322895650	1	TUBE	
21	LA322895750	1	AIR HOSE	L = 3350 MM
22	LA322895950	1	HYDRAULIC HOSE	L = 2650 MM
23	LA322896150	2	WATER HOSE	L = 3400 MM
24	LA322944150	1	WATER HOSE	L = 1100 MM
25	LA322995200	1	EXPANSION TANK UP TO SERIAL NUMBER 552310266 UP TO SERIAL NUMBER 552410122 AL	
	LA323434400	1	EXPANSION TANK FROM SERIAL NUMBER 552310267 FROM SERIAL NUMBER 552410123 AL	
26	LA322995450	1	WATER HOSE UP TO SERIAL NUMBER 552310266 UP TO SERIAL NUMBER 552410122 AL	L = 900 MM
	LA323013450	1	WATER HOSE FROM SERIAL NUMBER 552310267 FROM SERIAL NUMBER 552410123 AL	L = 1550 MM
27	LA323013550	1	WATER HOSE	L = 500 MM
28	LA323105850	1	TANK CAP	
29	LA323143050	1	UNION	
30	LA340481806	1	CABLE TIE	L = 180 MM
31	LA340481813	1	CABLE TIE	L = 365 MM
32	LA350391518	4	HOSE CLIP	?19-28 MM
33	LA355510820	1	FLAT WASHER	?8,5-24 X 2 MM
34	LA355561430	1	SEALING WASHER	?14,5-22,5 X 3 MM
35	LA355562230	2	SEALING WASHER	?22,5-28,5 X 3 MM
36	LA355571415	2	SEALING WASHER	?14,5-20 X 1,5 MM
37	LA410000794	1	SEALING WASHER	?16,5-22 X 1 MM
38	LA350391526	1	HOSE CLIP	?26-38 MM
39	LA322869150	1	SUPPORT	

8015456-L-A



Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)